

		42			
		43			
		44			
		45			
		46			
		47			
		48			
		49			
		50			
		51			
		52			
		53			
		⊙ 54	X:54	UZ1:4	↗
		⊙ 55	X:55	A1-M4.XB:28	—
	Выходные цепи			X	
		56	X:56	A1-M2.XB:2	—
		57	X:57	A1-M2.XB:4	—
		58	X:58	A1-M2.XB:6	—
		59	X:59	A1-M2.XB:8	—
		60	X:60	A1-M2.XB:10	—
		61			
		62			
		63			
		64			
		65			
		66			
		67			
		68			
		69			
		70	X:70	SA1:4	—
		71	X:71	SA1:6	—
		72	X:72	SA1:8	—
		73	X:73	SA2:4	—
		74	X:74	SA3:4	—
		75			
		76			
		77			
		78			
		79			
		80			
		81			
		82			
		83			
		84			
		85			
	Цепи сигнализации			X	
		⊙ 86	X:86	A1-M1.XP:2	—
		⊙ 87			—
		⊙ 88			—
		⊙ 89			—
		90			—
		91			—
		92			—
		93			—
		94			—
		95			—
		96			—
		97			—
		⊙ 98	X:98	HL1:2	—
		⊙ 99			—
	Цепи регистрации			X	
		⊙ 100	X:100	A1-M1.XP:5	—
		⊙ 101	X:101	A1-M1.XP:15	—
		102			—
		103	X:103	A1-M1.XP:4	—
		104	X:104	A1-M1.XP:14	—

	Цепи освещения			X	
		⊙ 105	X:105	SQ1:11	кч
		⊙ 106			WE2
		⊙ 107	X:107	SQ1:21	с
		⊙ 108			
	Резерв/Транзит			X	
		109			
		110			
		111			
		112			
		113			
		114			
		115			
		116			
		117			
		118			