



MT3 HH2(CH) 0321

TO HH2(CH) 0551



0321.0791.305

MT3-1 HH2(CH) 0531




0321.0651.301

0321.0652.301

1743.5121.302

MT3-2 HH2(CH) 0532



0321.0651.301

0321.0652.301


1743.5121.302

0321.301


0321.0791.305

MT3 HH2(CH) 0321


ОМ в Т 0651




ОМ в сеть 0652



БНТ 0791



Иср БНТ MT3 HH2(CH)



0321.501

0371.0773.302

3451.6543.301

0371.0774.302

3451.6544.301

0321.0551.302


0321.0531.302

0321.0532.302

0321.0551.303

0321.0531.303

0321.0532.303



0321.301

0321.302

0321.303