





Delta Environmental Products, Inc.

ECOPOD
COMPRESSOR
CONTROL PANEL



SCHEMATIC DIAGRAM
CP22 SERIES

FS1 - HL FLOAT SWITCH (OPTIONAL)
* FUSE SIZE VARIES WITH COMPRESSOR SIZE
PER NATIONAL ELECTRIC CODE.
- A SEPARATE DISCONNECT IS REQUIRED.



SETTING HIGH LEVEL PRESSURE SWITCH

BRING PLANT TO OPERATING WATER LEVEL WITH COMPRESSOR TURNED ON, USING PROPERLY SIZED SCREW DRIVER. TURN HIGH LEVEL ALARM ADJUSTMENT SCREW CLOCKWISE UNTIL ALARM OCCURS. THEN TURN THE SCREW COUNTER-CLOCKWISE UNTIL ALARM STOPS.


NEMA 3R
PAINTED STEEL
ENCLOSURE

A rectangular box containing two parallel horizontal lines, with a small circle at the bottom right corner.

L11

1

ENCL.



FRONT VIFW

DOOR OPEN

FSI = H.L. FLUID SWITCH, OPTIONAL

*
HOUSE SIZE VARIES WITH COMPRESSOR SIZE
PER NATIONAL ELECTRIC CODE.

- A SEPARATE DISCONNECT IS REQUIRED