



120
240VAC
SOURCE



CLOCK 1 – PINS OUT = TIME THAT COMPRESSORS WILL BE ON
PINS IN = TIME THAT COMPRESSORS WILL BE OFF
CLOCK 2 – MOVE ONE PIN OUT AT THE TIME THAT THE COMPRESSORS
ARE TO ALTERNATE
ON BOTHCLOCKS MAKE SURE THAT THE MANUAL-AUTO-OFF LEVER
IS IN THE CENTER POSITION (AUTO).

— DENOTES PANEL TERMINAL
— DENOTES FIELD WIRING



SCHEMATIC DIAGRAM