


120/230V 3WIRE
SOURCE



CLOCK – PINS OUT= TIME THAT COMPRESSOR WILL BE ON
PINS IN= TIME THAT COMPRESSOR WILL BE OFF

ON CLOCK MAKE SURE THAT THE MANUAL-AUTO-OFF LEAVER
IS IN THE CENTER POSITION (AUTO).

DENOTES PANEL TERMINAL
— — DENOTES FIELD WIRING

Cox Research and Technology, Inc.
14697 S. Harrells Ferry Road
Baton Rouge, LA. 70816
(225) 756-3271 Fax (225) 755-1030
CP-1940