


SCHEMATIC DIAGRAM  
 CP1312R1



## EXTERNAL CONNECTIONS

CP1312R1

### NOTES:

1. EXTERNAL DISCONNECT IS REQUIRED
2. PUMP MUST HAVE INTERNAL THERMAL OVERLOAD PROTECTION.
3. PUMP FLOAT MUST BE CAPABLE OF CARRYING FULL MOTOR CURRENT. (MAX PUMP CURRENT MUST NOT EXCEED 16 AMPS)