

VIEWING THE INPUTS

WITH CLOCK AND DATE SHOWING ON DISPLAY PRESS RIGHT ARROW ► KEY ONCE. INPUTS ARE SHOWN (SEE FIGURE 1). TO RETURN TO CLOCK AND DATE, PRESS LEFT ARROW ◀ KEY.




FIGURE 1

VIEWING THE OUTPUTS

WITH CLOCK AND DATE SHOWING ON DISPLAY PRESS LEFT ARROW ◀ KEY ONCE. INPUTS ARE SHOWN (SEE FIGURE 2). TO RETURN TO CLOCK AND DATE, PRESS RIGHT ARROW ► KEY.




FIGURE 2