




BLOCK SETTINGS

B01 = SV1 ON TIME
 B02 = SV2 ON TIME
 B03 = SV3 ON TIME
 B04 = SV4 ON TIME
 B05 = SV1 DRAIN TIME AFTER PUMP TURNS OFF
 B06 = SV2 DRAIN TIME AFTER PUMP TURNS OFF
 B07 = SV3 DRAIN TIME AFTER PUMP TURNS OFF
 B08 = SV4 DRAIN TIME AFTER PUMP TURNS OFF

PROGRAM: 8000AUX4r1



	Drawing Title					
	CONTROL DIAGRAM					
DATE 12/13/04	REFERENCE DRAWING S/N	NO. C.C.	REVISION-LOCATION DRAWN BY C. RACHAL	ECN	DATE	BY
	Sales Engineer	Application Engineer R.C.			APPROVED	
	Project Title 8000 SERIES AUXILIARY PANEL FOR CONVERTING ZONER DOSING TO SOLENOID VALVE DOSING	COX Research and Technology, Inc.	P.O. Box 77808 Baton Rouge, LA 70809 Ph. (225)756-3271 Fax (225)755-1030	PURCHASE ORDER NUMBER		
				DRAWING NUMBER CP-1964		
				SHEET NUMBER 1		



	Drawing Title					
	CONTROL DIAGRAM					
DATE 12/13/04	REFERENCE DRAWING S/N	NO. C.C.	REVISION-LOCATION DRAWN BY C. RACHAL	ECN	DATE	BY
	Sales Engineer	Application Engineer R.C.			APPROVED BY	DATE DATE
	Project Title 8000 SERIES AUXILIARY PANEL FOR CONVERTING ZONER DOSING TO SOLENOID VALVE DOSING	COX Research and Technology, Inc.	P.O. Box 77808 Baton Rouge, LA 70809 Ph. (225)756-3271 Fax (225)755-1030	PURCHASE ORDER NUMBER DRAWING NUMBER CP-1964 SHEET NUMBER 2		

8000 AUX4r1
PLC PARAMETERS

<u>BLOCK</u>	<u>DESCRIPTION</u>	<u>FACTORY SETTING</u>	<u>PLC NOMENCLATURE</u>
B01	T = Field 1 Dose Time Ta = Time Elapsed During Dose	12 Minutes 00:00	12:00m 00:00
B02	T = Field 2 Dose Time Ta = Time Elapsed During Dose	12 Minutes 00:00	12:00m 00:00
B03	T = Field 3 Dose Time Ta = Time Elapsed During Dose	12 Minutes 00:00	12:00m 00:00
B04	T = Field 4 Dose Time Ta = Time Elapsed During Dose	12 Minutes 00:00	12:00m 00:00
B05	T = Field 1 drain time after pump turns off Ta = Time Elapsed before field valve 1 closes	2 Minutes 00:00	02:00m 00:00
B06	T = Field 2 drain time after pump turns off Ta = Time Elapsed before field valve 2 closes	2 Minutes 00:00	02:00m 00:00
B07	T = Field 3 drain time after pump turns off Ta = Time Elapsed before field valve 3 closes	2 Minutes 00:00	02:00m 00:00
B08	T = Field 4 drain time after pump turns off Ta = Time Elapsed before field valve 4 closes	2 Minutes 00:00	02:00m 00:00

Note: Minute settings are in minutes and seconds. For example 02:00m is 2 minutes, 02:10m is 2 minutes and 10 seconds.
Hour settings are in hours and minutes. For example 02:00h is 2 hours and no minutes, 02:10h is 2 hours and 10 minutes, and 00:12h is 12 minutes.