TN NET TCP/IP stack sockets API

V. 0.8

(http://www.tnkernel.com/)

Copyright © 2009 Yuri Tiomkin

Document Disclaimer

The information in this document is subject to change without notice. While the information herein is assumed to be accurate, Yuri Tiomkin (the author) assumes no responsibility for any errors or omissions. The author makes and you receive no warranties or conditions, express, implied, statutory or in any communications with you. The author specifically disclaims any implied warranty of merchantability or fitness for a particular purpose.

Copyright notice

TN NET TCP/IP stack sockets API

Copyright © 2009 Yuri Tiomkin All rights reserved.

Permission to use, copy, modify, and distribute this software in source and binary forms and its documentation for any purpose and without fee is hereby granted, provided that the above copyright notice appear in all copies and that both that copyright notice and this permission notice appear in supporting documentation.

THIS SOFTWARE IS PROVIDED BY THE YURI TIOMKIN AND CONTRIBUTORS ``AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL YURI TIOMKIN OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Trademarks

Names mentioned in this manual may be trademarks of their respective companies. Brand and product names are trademarks or registered trademarks of their respective holders.

Document Version:

- 0.8

Acknowledgments:

s socket

Create an endpoint for communication

Function:

int s_socket (int domain, int type, int protocol)

Parameter:

domain In TN NET, domain is always a **AF_INET**

type SOCK_DGRAM - for UDP socket

SOCK_STREAM - for TCP socket SOCK_RAW - for raw socket

protocol IPPROTO_UDP - for SOCK_DGRAM type

for all another types

Return parameter:

A socket descriptor Normal completion
-EPERM (-1) Operation failed

Description:

The *s_socket()* function creates an unbound socket, and returns a socket descriptor that can be used in later function calls that operate on sockets.

s_closeCauses the system to release resources allocated to a socket.

Function:

int s_close (int s)

Parameters:

s Specifies the descriptor of the socket to be close

Return parameter:

0 (TERR_NO_ERR) Normal completion

-EINVAL Input parameter(s) has a wrong value

-EFAULT Operation failed

Description:

This function causes the system to release resources allocated to a socket. In case of TCP socket, the connection is terminated.

s bind

bind a name to a socket

Function:

Parameter:

Specifies the descriptor of the socket to be bound

name Points to a **_sockaddr** structure containing the address to be bound to

the socket. The length and format of the address depend on the address

family of the socket. In TN NET, a _sockaddr is actually a

sockaddr_in structure

namelen Specifies the length of the **sockaddr** structure pointed to by the name

argument

Return parameter:

0 (TERR_NO_ERR) Normal completion

-EINVAL Input parameter(s) has a wrong value

-ENOBUFS Out of memory

-EADDRNOTAVAIL The specified address is not available from the local machine

Description:

The $s_bind()$ function will assign a local socket address name to a socket identified by descriptor s that has no local socket address assigned. Sockets created with the $\underline{s_socket()}$ function are initially unnamed; they are identified only by their address family.

s connect

Connect a socket

Function:

int s_connect (int s,

struct _sockaddr * name,

int namelen)

Parameter:

s Specifies the descriptor of the socket to be connect

name Points to a _sockaddr structure containing the peer address. The length

and format of the address depend on the address family of the socket.

In TN NET, sockaddr is actually a sockaddr in structure.

namelen Specifies the length of the **_sockaddr** structure pointed to by the name

argument.

Return parameter:

0 (TERR_NO_ERR) Normal completion

-EINVAL Input parameter(s) has a wrong value

-EPERM Operation not permitted

-ENOBUFS Out of memory

-EADDRNOTAVAIL The specified address is not available from the local machine

Description:

The *s_connect*() function makes an attempt to set a connection on a socket. If the socket has not already been bound to a local address, *s_connect*() will bind it to an address which is an unused local address.

If the socket is a SOCK_DGRAM or SOCK_RAW, a *s_connect*() function set the socket's peer address, and no connection is made. If *name* is a null address for the protocol, the socket's peer address will be reset.

If the socket is a SOCK_STREAM, then <code>s_connect()</code> will makes an attempt to establish a connection to the address specified by the <code>name</code> argument. If the connection cannot be established immediately, <code>s_connect()</code> will block for up to an unspecified timeout interval until the connection is established. If the timeout interval expires before the connection is established, <code>s_connect()</code> will fail and the connection attempt will be aborted.

s accept

Accept a new connection on a socket

Function:

Parameter:

s Specifies a socket that was created with s_socket() has been bound to

an address with *s bind()* and has issued a successful call to *s listen()*

addr Either a null pointer, or a pointer to a **_sockaddr** structure where the

address of the connecting socket will be returned.

In TN NET, _sockaddr is actually a sockaddr__in structure.

addrlen Points to a variable which on input specifies the length of the supplied

sockaddr structure, and on output specifies the length of the stored

address.

Return parameter:

A descriptor of the accepted socket Normal completion
-EPERM (-1) Operation failed

Description:

This function works only with a SOCK STREAM sockets.

The s_accept() function extracts the first connection on the queue of pending connections, creates a new socket with the same socket type protocol and address family as the specified socket, and allocates a new descriptor for that socket.

If *addr* is not a null pointer, the address of the peer for the accepted connection will be stored in the **_sockaddr_in** structure pointed to by *addr*, and the length of this address will be stored in the variable pointed to by *addrlen*.

If the listen queue is empty of connection requests s_accept() will block until a connection is present.

The accepted socket cannot itself accept more connections. The original socket remains open and can accept more connections.

s listen Listen for socket connections and limit the queue of incoming connections

Function:

int s_listen (int s, int backlog)

Parameter:

Specifies the descriptor of the socket s

The maximum length of the queue of pending connections. backlog

Return parameter:

0 (TERR_NO_ERR) Normal completion

-EINVAL Input parameter(s) has a wrong value

-EPERM Operation not permitted

Description:

This function works only with a SOCK_STREAM sockets. The $s_listen()$ function marks a SOCK_STREAM socket, specified by the socket argument s, as accepting connections, and limits the number of outstanding connections in the socket's listen queue to the value specified by the backlog argument. The socket s is put into 'passive' mode where incoming connection requests are acknowledged and queued pending acceptance by the process.

s recv

Receive a message from a connected socket

Function:

int s_recv (int s, unsigned char * buf, int nbytes, int flags)

Parameter:

s Specifies the socket descriptor.

buf Points to a buffer where the message should be stored

nbytes Specifies the length in bytes of the buffer pointed to by the buf

argument.

flags Specifies the type of message reception. IN TN NET, should be 0.

Return parameter:

The length of the message in bytes Normal completion

-EINVAL Input parameter(s) has a wrong value

-ENOTCONN A receive is attempted on a connection-mode socket that is not

connected

-ENOBUFS Insufficient resources were available in the system to perform

the operation.

Description:

This function works only with a SOCK STREAM sockets in TN NET.

The *s_recv*() function returns the length of the message written to the buffer pointed to by the *buf* argument. For SOCK_STREAM sockets, message boundaries will be ignored. In this case, data will returned to the user as soon as it becomes available, and no data will be discarded.

If no messages are available at the socket and SS_NBIO flag is not set on the socket descriptor (default), $s_recv()$ will block until a message arrives. If no messages are available at the socket and SS_NBIO flag is set on the socket's descriptor (by a $s_ioctl()$ function), $s_recv()$ will fail and returns a value (-EWOULDBLOCK).

In TN NET, in the most cases there is no reason to use non-blocking reception. When $s_recv()$ will block, the task automatically switches to the WAIT state and gives an ability to run for another tasks.

s recvfrom

Receive a message from a socket

Function:

int s recvfrom (int s,

unsigned char * buf,

int len, int flags,

struct sockaddr * from.

int * fromlenaddr)

Parameter:

s Specifies the socket descriptor

buf Points to the buffer where the message should be stored.

len Specifies the length in bytes of the buffer pointed to by the buf

argument.

flags Specifies the type of message reception. IN TN NET, should be 0.

from A null pointer, or points to a _sockaddr structure in which the sending

address is to be stored. In TN NET, _sockaddr is actually a

sockaddr in structure

fromlenaddr Specifies the length of the **sockaddr** structure pointed to by the from

argument.

Return parameter:

The length of the message in bytes Normal completion

-EINVAL Input parameter(s) has a wrong value

-ENOTCONN A socket that is not connected

-ENOBUFS Insufficient resources to perform the operation.

-EWOULDBLOCK No messages at the socket (non-blocking mode only)

-ETIMEOUT Timeout occurred (blocking mode only)

Description:

This function works only with a SOCK_DGRAM and SOCK_RAW sockets in TN NET.

The *s_recvfrom*() function receives a message from a socket. It permits the application to retrieve the source address of received data. The *s_recvfrom*() function returns the length of the message written to the buffer pointed to by the *buf* argument. For SOCK_RAW and SOCK_DGRAM sockets, the entire will be read in a single operation.

If a message is too long to fit in the supplied buffer, the excess bytes will be discarded.

If the *from* argument is not a null pointer, the source address of the received message will be stored in the **_sockaddr** structure pointed to by the *from* argument, and the length of this address will be stored in the variable pointed to by the *fromlenaddr* argument.

If no messages are available at the socket and SS_NBIO flag is not set on the socket descriptor (default), $s_recvfrom()$ will block until a message arrives. If no messages are available at the socket and SS_NBIO flag is set on the socket's descriptor (by a $s_ioctl()$ function), $s_recvfrom()$ will fail and returns a value (-EWOULDBLOCK).

In TN NET, in the most cases there is no reason to use non-blocking reception. When *s_recvfrom()* function will block, the task automatically switches to the WAIT state and gives an ability to run for another tasks. For UDP/RAW sockets, the timeout feature (see *s_setsockopt()* function) sets the timeout value that specifies the maximum amount of time an input function waits until it completes in the blocking mode.

s send

Send a message on a socket

Function:

Parameter:

s Specifies the socket descriptor

buf Points to the buffer containing the message to send.

nbytes Specifies the length of the message in bytes.

flags Specifies the type of message transmission. IN TN NET, should be 0.

Return parameter:

The number of bytes sent. Normal completion

-EINVAL Input parameter(s) has a wrong value

-ENOBUFS Insufficient resources were available in the system to

perform the operation.

-ENOTCONN The socket is not connected or otherwise has not had the

peer pre-specified.

Description:

This function works only with a SOCK_STREAM sockets in TN NET.

The *s send*() function will send a message only when the socket is connected.

The length of the message to be sent is specified by the *nbytes* argument.

If the message is too long to pass through the underlying protocol, *s_send*() will fail and no data will be transmitted.

Successful completion of a call to $s_send()$ does not guarantee delivery of the message. A return error value (if any) indicates only locally-detected errors.

If space is not available at the sending socket to hold the message to be transmitted, and SS_NBIO flag is not set on the socket descriptor (default), *s_send*() will block until space is available. If space is not available at the sending socket to hold the message to be transmitted, and SS_NBIO flag is set on the socket's descriptor (by a *s_ioctl()* function), *s_send()* will fail and returns a value (-EWOULDBLOCK).

In TN NET, in the most cases there is no reason to use non-blocking transmission. When *s_send*() will block, the task automatically switches to the WAIT state and gives an ability to run for another tasks.

s sendto

Send a message on a socket

Function:

Parameter:

s Specifies the socket descriptor

buf Points to a buffer containing the message to be sent.

len Specifies the size of the message in bytes.

flags Specifies the type of message transmission. IN TN NET, should be 0.

dst addr NULL or points to a **sockaddr** structure containing the destination

address. In TN NET, sockaddr is actually a sockaddr in structure

len Specifies the length of the **sockaddr** structure pointed to by the

dst addr argument.

Return parameter:

The number of bytes sent Normal completion

-EINVAL Input parameter(s) has a wrong value

-ENOBUFS Insufficient resources were available in the system to

perform the operation.

-ENOTCONN The socket is not connected or otherwise has not had the

peer pre-specified.

Description:

This function works only with a SOCK_DGRAM and SOCK_RAW sockets in TN NET.

The *s_sendto()* function will send a message through a socket. The message will be sent to the address specified by *dst_addr* argument. The *len* argument specifies the length of the message.

In TN NET if a *dst_addr* argument is NULL, a destination address should be set before *s_sendto()* function using - by the function's *s_connect()* call.

Successful completion of a call to *s_sendto()* does not guarantee delivery of the message. A return value of error (if any) indicates only locally-detected errors.

If space is not available at the sending socket to hold the message to be transmitted, and SS_NBIO flag is not set on the socket descriptor (default), *s_sendto*() will block until space is available. If space is not available at the sending socket to hold the message to be transmitted, and SS_NBIO flag is set on the socket's descriptor (by a *s_ioctl()* function), *s_sendto()* will fail and returns a value (-EWOULDBLOCK).

In TN NET, in the most cases there is no reason to use non-blocking transmission. When *s_sendto()* will block, the task automatically switches to the WAIT state and gives an ability to run for another tasks.

s shutdown

Shut down socket send and receive operations

Function:

int s_shutdown (int s, int how)

Parameter:

s Specifies the socket descriptor

how Specifies the type of shutdown. The values are as follows:

SHUT_RD - Disables further receive operations
SHUT WR - Disables further send operations.

SHUT RDWR - Disables further send and receive operations.

Return parameter:

0 (TERR_NO_ERR) Normal completion

-EINVAL Input parameter(s) has a wrong value

-ENOTCONN The socket is not connected.

Description:

This function works only with a SOCK_STREAM sockets in TN NET.

The *s_shutdown*() function will cause all or part of a full-duplex connection on the socket associated with the descriptor *s* to be shut down.

The $s_shutdown()$ function disables subsequent send and/or receive operations on a socket, depending on the value of the *how* argument.

s ioctl

Control a socket behavior

Function:

```
int s_ioctl (int * s,
int cmd,
void *data)
```

Parameters:

s Specifies the socket descriptor

cmd Specifies the command to the socket s

data Points to the memory in which the cmd data is stored to put into the socket

or will be obtained from the socket after cmd executing

Return parameter:

0 (TERR_NO_ERR) Normal completion

-EINVAL Input parameter(s) has a wrong value

-ENOPROTOOPT Unknown / unsupported cmd

Description:

In TN NET, for a SOCK_STREAM sockets, a parameter *cmd* can has a value:

_FIONBIO - set/remove the socket's SS_NBIO flag

It is a socket source code fragment for the _FIONBIO cmd:

```
if(*((int *)data))
    so->so_state |= SS_NBIO;
else
    so->so_state &= ~SS_NBIO;
return 0;
```

FIONREAD - get actual bytes number in the socket's reception buffer

It is a socket source code fragment for the **_FIONREAD** cmd:

```
*((int *)data) = so->so_rcv.sb_cc;
return (0);
```

In TN NET, for a SOCK DGRAM and SOCK RAW sockets, a parameter cmd can has a value:

- _FIONBIO set/remove the socket's SS_NBIO flag (the same as for a SOCK_STREAM sockets)
- FIORXTIMEOUT set the socket reception timeout value (in milliseconds)

It is a socket source code fragment for the **FIORXTIMEOUT** cmd:

```
unsigned int rc;
bcopy(data,(unsigned char*)&rc, sizeof(int));
so->rx_timeout = rc;
return 0; //-- O.K
```

s getpeername

Get the name of the peer socket

Function:

int s_getpeername (int s,

struct _sockaddr * name,

int * namelen)

Parameters:

s Specifies the socket descriptor

name Points to a **_sockaddr** structure to store the peer socket name.

In TN NET, sockaddr is actually a sockaddr in structure.

namelen The length of name argument in the variable pointed to by the namelen

argument.

Return parameter:

0 (TERR_NO_ERR) Normal completion

-EINVAL Input parameter(s) has a wrong value

-ENOTCONN A receive is attempted on a connection-mode socket that is

not connected

-ENOBUFS Insufficient resources were available in the system to perform

the operation.

Description:

The s_getpeername() function retrieves the peer address of the specified socket, stores this address in the _sockaddr structure pointed to by the *name* argument, and stores the length of this address in the variable pointed to by the *namelen* argument.

If the actual length of the address is greater than the length of the supplied **_sockaddr** structure, the stored address will be truncated.

If the protocol permits connections by unbound clients, and the peer is not bound, then the value stored in the object pointed to by *name* is unspecified.

s setsockopt

Set the socket options

Function:

int s_setsockopt (int s,

int level, int name,

unsigned char * val,

int avalsize)

Parameters:

s Specifies the socket descriptor

level In TN NET, should be 0

name The name argument specifies a single option to set

val Pointed to by the memory buffer that contains a single option data to set

avalsize Size of the option data

Return parameter:

0 (TERR_NO_ERR) Normal completion

-EINVAL Input parameter(s) has a wrong value

-ENOPROTOOPT The option is not supported

Description:

The supported options are as follows:

SO_LINGER (TCP only)

Lingers on a $s_close()$ data is present. This option controls the action taken when unsent messages queue on a socket and $s_close()$ is performed. If SO_LINGER is set, the system will block the calling thread during $s_close()$ until it can transmit the data or until the time expires. If SO_LINGER is not specified, and $s_close()$ is issued, the system handles the call in a way that allows the calling thread to continue as quickly as possible. This option takes a $__linger$ structure, as defined in the "bsd socket.h" header, to specify the state of the option and linger interval.

SO_KEEPALIVE (TCP only)

Keeps connections active by enabling the periodic transmission of messages. This option takes an **int** value. This is a Boolean option.

SO_SNDBUF (TCP only)

Sets send buffer size. This option takes an int value.

SO RCVBUF (TCP only)

Sets receive buffer size. This option takes an int value.

SO RCVLOWAT (TCP only)

Sets the minimum number of bytes to process for socket input operations. The default value for SO_RCVLOWAT is 1. If SO_RCVLOWAT is set to a larger value, blocking receive calls normally wait until they have received the smaller of the low water mark value or the requested amount. (They may return less than the low water mark if an error occurs or the type of data next in the receive queue is different from that returned; for example, out-of-band data.) This option takes an **int** value.

SO RCVTIMEO (UDP/RAW only)

Sets the timeout value that specifies the maximum amount of time an input function waits until it completes. This option takes an **int** value. The timeout value is in milliseconds. The default for this option is TN_WAIT_INFINITE, which indicates that a receive operation will not time out.

SO_SNDLOWAT (TCP only)

Sets the minimum number of bytes to process for socket output operations. Non-blocking output operations will process no data if flow control does not allow the smaller of the send low water mark value or the entire request to be processed. This option takes an **int** value.

For Boolean options, 0 indicates that the option is disabled and 1 indicates that the option is enabled.

s_getsockopt

Get the socket options

Function:

int s_getsockopt (int s,

int level, int name,

unsigned char * val,

int avalsize)

Parameters:

s Specifies the socket descriptor

level In TN NET, should be 0

name The name argument specifies a single option to get

val Pointed to by the memory buffer that will contains a single option data

avalsize Size of the option data

Return parameter:

0 (TERR_NO_ERR) Normal completion

-EINVAL Input parameter(s) has a wrong value

-ENOPROTOOPT The option is not supported

Description:

This function is a "mirror" functions to the *s_setsockopt()* function and lets to obtain an option data/value. A supported options are the same as for the *s_setsockopt()* function.

Appendix A:

This is a _sockaddr and sockaddr__in structures definition:

```
* There are a BSD 'in_addr', 's_addr', 'sockaddr', 'sockaddr__in'
^{\star} structures, extra '_' characther was added to resolve
  a Win32 names conflict only
/* packed */
struct in__addr
  unsigned int s__addr;
} ;
/* packed */
struct _sockaddr
  char sa_data[14];
                              /* actually longer; address value */
} ;
/* packed */
struct sockaddr__in
                    /* Socket address, internet style */
  unsigned char sin_len;
  unsigned char sin_family;
  unsigned short sin_port;
  struct in_addr sin_addr;
  char sin_zero[8];
};
```