ADVANTAGE151 Fitting Guide

Select the initial diagnostic lens dependent upon the amount of corneal cylinder:

 Corneal Cylinder
 Base Curve

 0.00 to 0.75D
 Fit on flat K

 0.87 to 1.50
 Fit 0.25 steeper than flat K

 1.62 to 2.25
 Fit 0.50 steeper than flat K

 2.37 to 3.00
 Fit 0.75 styper than flat K

The diagnostic lens should position centrally without impinging on the limbal conjunctiva and exhibit some movement, though minimal. The fluoroscein pattern should be relatively uniform with mild central pooling and with no seal off or touch. After the proper base curve corneal relationship has been achieved, perform a spherical over-refraction to best acuity. ADVANTAGE151will neutralize as much as 2.50 D cylinder.

A 10.0mm diameter is traditionally used.