## 'UPRITE' AUTOMATICLADDER-LEVELLER


## FITTING INSTRUCTIONS

A. For parallel-rail ladders up to 380 mm (15 ins) O.D., fit ladder retaining brackets as shown in Figure 1.

Ladders wider than 380 mm; fit as in Figure 2.

Extra wide ladders; Figure 3.

Tighten U-clamps securely, but do not over stress brackets.



- B. Place ladder in horizontal position:-using four bolts supplied, attach 'UPRITE' to ladder brackets. Before tightening bolts, make sure centre of leveller and ladder are in line, and base of both rails are butted against top plate of leveller.
- Your 'UPRITE' ladder-leveller is now ready for use.
   Simply place in position, check that bubble in spirit-level is central, and use.
- D. TO REPOSITION. Raise ladder slightly, leaving feet in contact with ground surface, adjust angle until bubble is in central position, lower ladder.

Once fitted with an 'UPRITE' your ladder can be used with confidence on level, sloping, uneven, hard or soft surfaces.

NOTE. Slip on Super Size feet available for soft ground.

The unique automatic locking device incorporated in the 'UPRITE', ensures the utmost safety at all times.

Simplicity of design and durable materials give 'UPRITE' a long and virtually maintenance-free life.

Non-slip feet add to safety and allow use on damage-prone surfaces, such as polished floors, vinyl, carpets, etc.

With the fitting of an 'UPRITE' ladder-leveller you have eliminated a large percentage of danger usually associated with the use of ladders, with the addition of reasonable caution, you ladder can always be a safe, speedy and trusty tool.

**SAFETY HINTS.** Never place base of ladder too close or to far away from building; an angle of approximately 15 degrees is appropriate.

Always remove obstacles (stones, gravel, etc.) from area where ladder is to be used.

If using against spouting, check that spouting is firm enough to withstand the weight of both ladder and operator.

When working on roof, extend ladder three rungs above edge of building.

Never use a ladder on soft ground, such as garden beds or freshly-filled trenches without 'UPRITE' Super feet fitted.

## PATENT NUMBERS

Australia 517,881. • U.S.A. 424,3122 • U.K. 2,037,357. Taiwan 20,066 Others pending.
 GOVERNMENT AUTHORISATION.

Tested and approved for use in the industry by the Department of Labour and Industry, Victoria. Approval Identification SAL157.

Winner of Annual Award, A.B.C. T.V. Inventors 1978.