Normal Operating Checklist



SAFETY INSPECTION	
SURFACES AND CHOCKS	CHECKED
MAINTENANCE STATUS	CHECKED
BATTERY	ON
ELECTRIC HYD PUMPS	ON / OFF
SHIPS LIBRARY	CHECKED

BEFORE TAXI	
GENERATORS	ON
PROBE HEAT	ON
ANTI-ICE	ON
A PUMPS	ON
AIR CONDITIONING	PACKS AUTO
ISOLATION VALVE	AUTO
START SWITCHES	CONT.
APU	OFF
RECALL	CHECKED
FLIGHT CONTROLS	CHECKED
FLAPS	_SELECTED
STAB TRIM	_REQUIRED
START LEVERS	IDLE D-NT

BEFORE TAKE OFF TO THE LINE	
CONFIG	CHECKED
FLAPS	_GR. LIGHT
STAB TRIM	_UNITS SET
TAKEOFF BRIEFING	REVIEWED
CABIN	SECURED

BELOW THE LINE	
MCP (V2, RWY HDG, CLR)	SET
TRANSPONDER	TARA
LANDING LIGHTS	ON
RETRACTS	ON
	•

AFTER TAKEOFF	
AIR CONDITIONING	SET
AUTOBRAKE	OFF
START SWITCHES	OFF
FLAPS	UP
LANDING GEAR	UP
ALTIMETERS	_SET

BEFORE START TO THE LINE		
PHONES	OFF	
IRS MODE SELECTORS	NAV	
GEAR PINS	REMOVED	
LIGHT TEST	CHECKED	
OXYGEN	TESTED	
YAW DAMPER	ON	
DISPLAY SWITCHES	NORMAL	
FUEL	ONBOARD	
CABIN / UTIL / IFE	ON	
EMERGENCY EXIT LIGHTS	ARMED	
PASSENGER SIGNS	ON	
WINDOW HEAT	ON	
HYDRAULICS	NORMAL	
AIR COND & PRESS	SET	
PRESSURIZATION MODE	AUTO	
INSTRUMENTS	X-CHECK	
AUTOBRAKE	RTO	
SPEEDBRAKE LEVER	DOWN	
PARKING BRAKE	CHECKED	
STAB TRIM SWITCHES	NORMAL	
WHEEL WELL FIRE WARNING	CHECKED	
RADIOS, RADAR & XPONDER	SET	
RUDDER & AILERON TRIM	FREE, ZERO	
TAKEOFF BRIEFING	DISCUSSED	
PA	COMPLETE	

Page 1

Normal Operating Checklist



BELOW THE LINE	
A PUMPS	ON / OFF
AIR CONDITIONING PACKS	OFF
ANTI COLLISION LIGHTS	ON
PARKING BRAKE	SET
TRANSPONDER	ALL OFF

DESCENT	
PRESSUARIZATION	LAND ALT_
ANTI ICE	ON / OFF
APPROACH BRIEF AND FUEL	DISCUSSED
IAS AND ALT BUGS	CHECKED

APPROACH	
ALTIMETERS AND	SET,
INSTRUMENTS	X-CHECKED
APPROACH AIDS	CHECKED

GEAR DOWN, FLAPS, LANDING	
ENGINE START SWITCHES	CONT.
RECALL	CHECKED
SPEEDBRAKE	GR. LIGHT
LANDING GEAR	DOWN 3 GR.
AUTOBRAKE	LEVEL_

COMPLETE	
FLAPS	_GR. LIGHT
LANDING LIGHTS	ON

SHUTDOWN	
FUEL	PUMPS OFF
ELECTRICAL (APU, GPU)	ON_
FASTEN BELTS	OFF
WINDOW HEAT	OFF
PROBE HEAT	OFF
ANTI ICE	OFF
ELECTRIC HYD PUMPS	OFF
VOICE RECORDER	ON
AIR CONDITIONING	OFF
EXTERIOR LIGHTS	STEADY / STEADY AND LOGO
START SWITCHES	OFF
AUTOBRAKE	OFF
SPEEDBRAKE	DOWN
FLAPS	UP
PARKING BRAKE	SET
START LEVERS	CUTOFF
WEATHER RADAR	OFF
TRANSPONDER	STANDBY
CVR CB	IN / OUT
COCKPIT DOOR	UNLOCKED

SECURE	
IRS MODE SELECTORS	OFF
CAB / UTIL, IFE	OFF
AIR CONDITIONING PACKS	OFF
EMERGENCY EXIT LIGHTS	OFF
APU / GPU	OFF
BATTERY	OFF