


B E I N S E N

Obrei

Cap press with automatic opening



User Manual and Safety Instructions

Empowering Your Personalization Needs.

Index

01	Introduction and equipment description	3
02	Technical specifications	4
03	Critical safety	5
04	Operation guide	7
05	Maintenance and troubleshooting	9
06	Legal notice and trademarks	11

Page numbers are indicative and may vary slightly depending on the specific length of the sections for this model.

01

Introduction and Equipment Description

The Beinsen Obrei is a semi-automatic cap heat press: closing is manual and opening is automatic at the end of the cycle, preventing the cap from being exposed to heat longer than necessary. With interchangeable heating elements (15 × 15 cm and 10 × 20 cm for caps) and a digital controller, it's the professional choice for workshops producing personalised caps frequently.

Applications

Sublimation, HTV vinyl and transfer on caps of various formats. Compatible with small flat surfaces thanks to the 15 × 15 cm heating element. Suitable for souvenir shops, corporate gifts, sports teams and professional production.

Main components

- Curved lower plate adaptable to the cap forehead
- Interchangeable heating elements (15 × 15 cm flat and 10 × 20 cm for cap)
- Manual closing system with automatic opening
- Reinforced lever arm
- digital controller
- Compact Beinsen orange frame



Fig. 1 · Main components of the Beinsen Obrei.

02

Technical Specifications

Model	Obrei
Press Type	Semi-automatic for caps
Opening Mode	Automatic
Closing Mode	Manual
Heating Element Type	Replaceable
Heating Element Size	15 × 15 cm y 10 × 20 cm (gorra)
Maximum printable thickness	20 mm
Display model	digital controller
Touch screen	No
Timer range	0 – 999 seg.
Maximum temperature	225 °C
Voltage	120 V / 220 V
Power	500 W / 1.000 W
Weight	25 kg
Dimensions	70 × 60 × 35 cm

Technical specifications may vary slightly depending on the manufacturing batch configuration. Refer to the equipment identification label for the exact data of your unit.

03

Critical Safety

Read all warnings carefully before operating the equipment. Failure to follow these instructions may result in serious injury, property damage or void the warranty.

Risk of burns

The heating elements reach 225 °C. Always handle the caps and the elements with thermal gloves.

Risk of entrapment (automatic opening)

The upper plate rises automatically at the end of the cycle. Keep hands out of its path during opening.

Heating element change

Make the change with the machine cold and disconnected. Check the fit and the electrical connection before resuming operation.

Electrical risk

Connect the equipment only to a grounded socket. Verify the configured voltage (120 V or 220 V) before connecting.

04

Operation Guide

The Obrei is a semi-automatic cap press: closing is operated manually and opening is automatic at the end of the cycle. The controller manages temperature and time. The heating elements are interchangeable between 15 × 15 cm and 10 × 20 cm formats.

Power-on and configuration

- 01 Connect the equipment to the mains and turn on the main switch.
- 02 Verify the configured voltage (120 V or 220 V) before first start-up.
- 03 The controller display will light up showing the temperature reading.
- 04 Press SET to enter the configuration menu.
- 05 Adjust the target temperature with the (+) and (–) buttons.
- 06 Press SET again to move to time setting and configure it the same way.
- 07 Press SET to confirm and exit the menu.
- 08 Wait until the heating element reaches the target temperature.

Heating element change

- 01 Turn off the equipment and disconnect it from the mains.
- 02 Wait until the heating element and associated components have cooled completely.
- 03 Loosen the screws or fixing clips of the current heating element.
- 04 Disconnect the electrical connection.
- 05 Fit the heating element of the desired format (15 × 15 cm or 10 × 20 cm for cap).
- 06 Check the correct fit before reconnecting the equipment.

Pressing process with automatic opening

- 01 Place the cap on the lower plate, adjusting it to the support curvature.
- 02 Stretch the front area well where the design will be applied.
- 03 Apply the transfer paper with the printed side facing the fabric.
- 04 Secure the transfer with heat-resistant tape to prevent shifting.
- 05 Close the equipment manually by lowering the arm to its stop.
- 06 The timer will start when closing is detected.
- 07 When the alarm sounds, the equipment will open automatically.
- 08 Remove the cap with thermal gloves and peel off the transfer paper as instructed by the manufacturer.

05

Maintenance and Troubleshooting

Preventive maintenance

- Before each shift, check that the heating element and curved plate are clean.
- Clean the heating element with the machine cold using a microfibre cloth. Never use water or abrasive products.
- Check the operation of the automatic opening mechanism weekly.
- Inspect the electrical connections when changing the heating element.
- Check the temperature reading with a contact thermometer if you notice inconsistency.
- Request a full inspection of the equipment from an Official Technical Service authorised by Beinsen in case of any persistent anomaly.

Troubleshooting

Problem	Probable cause	Solution
The display does not turn on	Loose power cable or incorrect voltage	Check the connection, configured voltage and socket. If it persists, contact Beinsen Technical Service.
The automatic opening does not respond	Jammed mechanism or faulty sensor	Turn off the equipment, let it cool and check the mechanism. If it persists, contact Technical Service.
The heating element does not heat up	Faulty electrical connection or damaged sensor	With the machine cold and disconnected, check the connector fit. If it persists, contact Technical Service.
Uneven transfer on the cap	Cap badly placed or insufficient pressure	Adjust the cap on the curved plate and increase the pressure when closing.

To report any issue, request a repair or purchase genuine spare parts, contact exclusively an Official Technical Service authorized by Beinsen.

06

Legal Notice and Trademarks

Copyright

Copyright © 2025 Beinsen. This guide is protected by international copyright laws. No part of this guide may be reproduced, distributed, translated or transmitted in any form or by any means, electronic or mechanical, including photocopying, recording or any information storage and retrieval system, without the prior written consent of Beinsen.

Trademarks

Beinsen and the Beinsen logo are registered trademarks. All other trademarks and copyrights mentioned in this document are the property of their respective owners.

Warranty and technical service

To report any issue, request a repair or purchase genuine spare parts, contact exclusively an Official Technical Service authorized by Beinsen. Find the nearest technical service point through the official website.

Contact

Beinsen

Avenida Alto de las Atalayas, 18 · 30110 Cabezo de Torres (Murcia), Spain
+34 968 902 300 · info@beinsen.com · beinsen.com