## **Attributes**

```
xbe name=filter_1 integrate=yes
# generic filter (up to order 5)
# This file does not have the actual implementation.
# It will only serve as a block in the GSEIM GUI.
# The GUI python parser will process it and include
# suitable filter elements in the circuit file.
#
     a0 + a1*s + a2*s^2 + a3*s^3 + a4*s^4 + a5*s^5
 y = -----
     b0 + b1*s + b2*s^2 + b3*s^3 + b4*s^4 + b5*s^5
#
Jacobian: constant
input_vars: x
output_vars: y
aux_vars:
iparms: scale_coef=0
sparms:
rparms:
+ a0=0 a1=0 a2=0 a3=0 a4=0 a5=0
+ b0=0 b1=0 b2=0 b3=0 b4=0 b5=0
+ f0=0
stparms:
+ y_sv=0
igparms:
outparms:
```

## **Description**

filter\_1.xbe satisfies the s-domain relationship,

$$y(s) = \frac{a_0 + a_1 s + a_2 s^2 + a_3 s^3 + a_4 s^4 + a_5 s^5}{b_0 + b_1 s + b_2 s^2 + b_3 s^3 + b_4 s^4 + b_5 s^5} x(s).$$

Filters of order 1 to 5 can be implemented with filter\_1.xbe. For example, a first-order low-pass filter can be implemented by making the coefficients  $a_1$ ,  $a_2$ ,  $a_3$ ,  $a_4$ ,  $a_5$ ,  $b_2$ ,  $b_3$ ,  $b_4$ ,  $b_5$  equal to zero. The order of the numerator must less than or equal to the order of the denominator.

If scale\_coef is set to 1, the coefficients given by the user are scaled. The scaling is based on the following assumptions.

- (a) The user has designed the filter for a corner frequency  $\omega = 1$  rad/s, i.e.,  $f = \frac{1}{2\pi}$  Hz.
- (b) The new corner frequency is specified by the user (in Hz) using the f0 parameter.