integrator.xbe

Attributes

```
xbe name=integrator integrate=yes
# y = k int (x dt)
Jacobian: constant
input_vars: x
output_vars: y
aux_vars:
iparms:
sparms:
rparms: k=1
stparms: y_st=0
igparms: y_ig=0
outparms: x y
```

Description

integrator.xbe gives $y = \int x dt$. The parameter y_st provides the start-up value for y in start-up simulation.