

Hi3861V100 / Hi3861LV100 MQTT

开发指南

文档版本 03

发布日期 2020-07-24

版权所有 © 上海海思技术有限公司2020。保留一切权利。

非经本公司书面许可,任何单位和个人不得擅自摘抄、复制本文档内容的部分或全部,并不得以任何形式传播。

商标声明

(HISILICON)、海思和其他海思商标均为海思技术有限公司的商标。本文档提及的其他所有商标或注册商标,由各自的所有人拥有。

注意

您购买的产品、服务或特性等应受海思公司商业合同和条款的约束,本文档中描述的全部或部分产品、服务或特性可能不在您的购买或使用范围之内。除非合同另有约定,海思公司对本文档内容不做任何明示或默示的声明或保证。

由于产品版本升级或其他原因,本文档内容会不定期进行更新。除非另有约定,本文档仅作为使用指导,本文档中的所有陈述、信息和建议不构成任何明示或暗示的担保。

上海海思技术有限公司

地址: 深圳市龙岗区坂田华为总部办公楼 邮编: 518129

网址: https://www.hisilicon.com/cn/

客户服务邮箱: support@hisilicon.com

前言

概述

本文档主要介绍基于MQTT功能开发实现示例。

MQTT基于开源组件paho.mqtt.c-1.3.1实现,详细说明请参考官方说明: https://www.eclipse.org/paho/files/mqttdoc/MQTTClient/html/index.html

产品版本

与本文档相对应的产品版本如下。

产品名称	产品版本
Hi3861	V100
Hi3861L	V100

读者对象

本文档主要适用于以下工程师:

- 技术支持工程师
- 软件开发工程师

符号约定

在本文中可能出现下列标志,它们所代表的含义如下。

符号	说明
▲ 危险	表示如不避免则将会导致死亡或严重伤害的具有高等级风险的危害。
▲ 警告	表示如不避免则可能导致死亡或严重伤害的具有中等级风险的危害。

符号	说明
<u></u> 注意	表示如不避免则可能导致轻微或中度伤害的具有低等级风险的危害。
须知	用于传递设备或环境安全警示信息。如不避免则可能会导致设备 损坏、数据丢失、设备性能降低或其它不可预知的结果。 "须知"不涉及人身伤害。
🖺 说明	对正文中重点信息的补充说明。 "说明"不是安全警示信息,不涉及人身、设备及环境伤害信 息。

修改记录

文档版本	发布日期	修改说明
03	2020-07-24	● 在 "1 API接口描述"中删除 paho.mqtt.c的版本号。
		● 在 " 2.1 开发流程 "中删除paho.mqtt.c 的版本号。
		更新"3.1 支持加密通路"的标题名称 和内容。
02	2020-07-21	更新" <mark>概述</mark> "中paho.mqtt.c的版本号为 paho.mqtt.c-1.3.1。
01	2020-04-30	第一次正式版本发布。
00B01	2020-01-15	第一次临时版本发布。

目录

前言	i
1 API 接口描述	1
1.2 API 列表	1
1.3 配置说明	1
2 开发指南	2
2.1 开发流程	2
2.2 订阅示例代码	
2.3 分发示例代码	4
3 注意事项	6
3.1 支持加密通路	

1 API 接口描述

- 1.1 结构体说明
- 1.2 API列表
- 1.3 配置说明

1.1 结构体说明

paho.mqtt.c详细的结构体说明请参考官方说明文档: https://www.eclipse.org/paho/files/mqttdoc/MQTTClient/html/annotated.html

1.2 API 列表

paho.mqtt.c详细的API说明请参考官方说明文档: https://www.eclipse.org/paho/files/mqttdoc/MQTTClient/html/globals_func.html

1.3 配置说明

paho.mqtt.c详细配置说明请参考官方说明文档: https://www.eclipse.org/paho/files/mqttdoc/MQTTClient/html/globals_defs.html

2 开发指南

- 2.1 开发流程
- 2.2 订阅示例代码
- 2.3 分发示例代码

2.1 开发流程

使用paho.mgtt.c的应用程序通常使用类似的结构:

- 创建一个客户端对象
- 设置选项以连接到MQTT服务器
- 如果正在使用多线程(异步模式)操作,请设置回调函数(请参见官方说明 "https://www.eclipse.org/paho/files/mqttdoc/MQTTClient/html/ async.html")。
- 订阅客户需要接收的任何主题
- 重复直到完成:
 - 发布客户端需要的所有消息
 - 处理任何传入的消息
- 断开客户端
- 释放客户端正在使用的所有内存

具体实现可以参考官方说明中的示例:

- Synchronous publication example: https://www.eclipse.org/paho/files/mqttdoc/MQTTClient/html/pubsync.html
- Asynchronous publication example: https://www.eclipse.org/paho/files/mqttdoc/MQTTClient/html/pubasync.html
- Asynchronous subscription example: https://www.eclipse.org/paho/files/mqttdoc/MQTTClient/html/subasync.html

2.2 订阅示例代码

#include <stdio.h> #include <stdlib.h>

```
#include <string.h>
#include "MQTTClient.h"
                    "tcp://192.168.43.101:1883"
#define ADDRESS
#define CLIENTID "ExampleClientSub"
                  "abc"
#define TOPIC
#define PAYLOAD
                    "Hello World!"
#define QOS
                  1
#define TIMEOUT
                    10000L
extern void hi_watchdog_enable(void);
extern void hi_watchdog_disable(void);
volatile MQTTClient_deliveryToken deliveredtoken;
void delivered(void *context, MQTTClient_deliveryToken dt)
  (void)context;
  printf("Message with token value %d delivery confirmed\n", dt);
  deliveredtoken = dt;
int msgarrvd(void *context, char *topicName, int topicLen, MQTTClient_message *message)
  int i;
  char* payloadptr;
  (void)context;
  (void)topicLen;
  printf("Message arrived\n");
  printf(" topic: %s\n", topicName);
  printf(" message: ");
  payloadptr = message->payload;
  for(i=0; i<message->payloadlen; i++)
     putchar(*payloadptr++);
  }
  putchar('\n');
  MQTTClient_freeMessage(&message);
  MQTTClient_free(topicName);
  return 1;
void connlost(void *context, char *cause)
  (void)context;
  printf("\nConnection lost\n");
  printf("
            cause: %s\n", cause);
int mqtt_002(int argc, char* argv[])
  (void)argc;
  (void)argv;
  MQTTClient client;
  MQTTClient connectOptions conn opts = MQTTClient connectOptions initializer;
  int rc;
  int ch;
  MQTTClient_create(&client, ADDRESS, CLIENTID,
     MQTTCLIENT_PERSISTENCE_NONE, NULL);
  conn_opts.keepAliveInterval = 20;
```

```
conn_opts.cleansession = 1;
MQTTClient_setCallbacks(client, NULL, connlost, msgarrvd, delivered);
if ((rc = MQTTClient_connect(client, &conn_opts)) != MQTTCLIENT_SUCCESS)
  printf("Failed to connect, return code %d\n", rc);
  return rc;
printf("Subscribing to topic %s\nfor client %s using QoS%d\n\n"
    "Press Q<Enter> to quit\n\n", TOPIC, CLIENTID, QOS);
MQTTClient_subscribe(client, TOPIC, QOS);
hi_watchdog_disable();
do
{
  ch = getchar();
} while(ch!='Q' && ch != 'q');
hi_watchdog_enable();
MQTTClient_unsubscribe(client, TOPIC);
MQTTClient disconnect(client, 10000);
MQTTClient_destroy(&client);
return rc;
```

2.3 分发示例代码

```
#include <stdio.h>
#include <stdlib.h>
#include <string.h>
#include "MQTTClient.h"
#define ADDRESS
                    "tcp://192.168.43.101:1883"
#define CLIENTID "ExampleClientPub"
#define TOPIC
                 "abc"
#define PAYLOAD
                   "Hello World!"
#define QOS
#define TIMEOUT
                  10000L
int mqtt_001(int argc, char **argv)
  printf("start mqtt sync publication test.\r\n");
  (void)argc;
  (void)argv;
  MQTTClient client;
  MQTTClient_connectOptions conn_opts = MQTTClient_connectOptions_initializer;
  MQTTClient_message pubmsg = MQTTClient_message_initializer;
  MQTTClient_deliveryToken token;
  int rc;
  MQTTClient_create(&client, ADDRESS, CLIENTID,
     MQTTCLIENT_PERSISTENCE_NONE, NULL);
  conn_opts.keepAliveInterval = 20;
  conn_opts.cleansession = 1;
  if ((rc = MQTTClient_connect(client, &conn_opts)) != MQTTCLIENT_SUCCESS)
     printf("Failed to connect, return code %d\n", rc);
     exit(EXIT_FAILURE);
```

3 注意事项

3.1 支持加密通路

3.1 支持加密通路

 如果需要实现MQTT加密传输,MQTT配置项中需要设置SSL参数。只做单端认证 (客户端对服务端进行认证)时,需要提供认证服务端的根CA证书;做双端认证 (客户端与服务端相互认证)时,除根CA证书外,还需要提供客户端证书与私 钥。具体可参考/src/samples/lt_mqtt_005.c用例。