# EasyWave Install Guide

#### 1 Before Installation

### 1.1 Hardware requirement

- 1GHz or higher processor
- 200M or more hard disk space
- 1024x768 monitor resolution or above
- 256M or more RAM
- USB interface and cable
- LAN interface and cable

# 1.2 System Support


- Microsoft Windows2000, XP system
- Win7 32bit and 64bit system
- Vista 32bit and 64bit system
- Windows 8 32bit and 64bit system.

#### 1.3 Software requirement

#### NI-VISA:

Before using this application, you have to install the NI-VISA runtime library, you can find it in the installation folder or you can download it from <a href="MI-VISA">MI-VISA</a> web site. For example, you can download <a href="MI-VISA Run-Time Engine 5.4">MI-VISA Run-Time Engine 5.4</a> directly to your PC. Follow the steps below to install it:


a. Double click the visa540 runtime.exe, the dialog shows as below:




b. Click Unzip, the install process will launch after unzipping files, and the dialog is as shown below:




c. Click Next, and the dialog is as shown below:




d. Set the install path, default path is "C:\Program Files\National Instruments\", you can change it. Click next, and the dialog is as shown below:




e. Click Next twice, and the dialog is as shown below:



f. Accept the agreements and click Next.



g. Click Next to begin the installation.




h. Now the installation is complete.


#### 2 Installation

a. Double click the EasyWave setup.msi, launch the install process, and the dialog is as


shown below:




b. Click next, and the dialog is as shown below:




c. Set the install path, default path is "C:\Program Files\Siglent\EasyWave\", you can change it. Click Next, and the dialog is as shown below:



d. Click Next to start the installation:




e. Wait a minute, and the installation will be complete:




## 3 Connect Device

For example, connect the device with PC via USBTMC protocol.


a. Launch EasyWave, the application is as shown below.



b. Click Communication>>Read wave, the Device connect setting dialog is as shown below:



c. Choose USBTMC and click OK, the Read wave dialog is as shown below:



d. Click Read wave and then get the returned information, the result is as shown below:

