


FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

Illus No.		DESCRIPTION	Illus No.		DESCRIPTION	Illu: No		DESCRIPTION
1 Fol	W10185985 W10089178	Installation Use & Care Guide Wiring Diagram	10 11 12 13 14 15	697773 3404413 3393008 W10131364 3394083 3392100	Front Panel (2) Foot, Dryer	23 24 25 26 27 28 29 30	3389441 3405246 8066217 342055 3405514 3397659	Clip, Felt Pad (3) Catch, Door Assembly Seal–Door Hinge, Top (2) Screw, 8–18 x 3/8 Hinge, Door Block, Terminal Clamp, Motor
	OO-IT-YOU REPAIR MA				Foot-Optional (Extended Length Package of 2) (Not Included)	31 32		(W/Shield) Clamp, Motor Motor Assembly, 60 HZ.
2 3 4 5 6 7 8	693995 8541400 3396795 3403630 3396805 3400500	Screw, 10–16 x 1/2 Screw, 8–18 x 3/8 Bracket, Cabinet Cover, Block Screw, 10–32 x 3/8 Panel, Rear Bolt, 5/16–18 x 3/4 Base, Motor	17 18 19 20		& Brass (3) (Includes Illus. 39) Cabinet (Includes Illus. 4) Clip, Ground Lock, Front Top (2)	33 34 35 36 37 38 39	8066184 3402341 3402335 3405184	Kit (For
J	340700	Dase, MOIOI	21 22		Panel, Front Idler & Pulley Assembly	40	697776	Terminal Block) Screw, 10–32 x 5/8

TOP AND CONSOLE PARTS

For Models: NED4800VQ1 (White)




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CONSOLE PARTS

Illus. No.	Part No.	DESCRIPTION
1	8274261	Panel, Rear
2	3397269	Console Connector
		(Timer)
3	693995	Screw, Hex Head
4	8271365	Cap, End (L.H.)
5	W10186092	Harness, Wiring
6	388326	Screw, Console
7	694419	Buzzer, Mini
8	8271359	Cap, End (R.H.)
9	3405156	Switch,
		Wrinkle Gaurd
10	8558463	Screen, Lint
11	8536939	Clip, Spring
12	8533971	Screw, 8-18 x 5/16
13	688983	Screw, 8–18 x 5/8
14	8533951	Screw, Grounding
15	3395683	Connector
		(Motor)
16	8557930	Тор
17	W10196503	Knob, Control (2)
18	3394427	Clip-Harness
19	94614	Terminal
20	3401144	Connector,
		(PTS Relay)
21	W10185982	Timer, 60 Hz.
22	W10196507	Timer Knob,
00	257042	Assembly
23	357213	Nut, Push–In (2)
24	3936144	Connector
25	3347243	Connector, 6–Circuit
26	3399639	Switch,
	000000	Temperature
27	8271418	Bracket, Control
28	3398095	Switch,
	22223	Push-To-Start
29	W10086735	Panel Control

BULKHEAD PARTS



BULKHEAD PARTS

Illus No.		DESCRIPTION		
1	348368	Lint Chute		
2	487909	Assembly Screw, 8–15 x 1/2		
2 3 4	3388703			
4	347139	Seal, Lint		
		Chute		
5	90767	Screw, 8-18 x 3/8		
6 7	696302	,		
/ 8	3392519 3387134			
ŏ	3387134	Thermostat, Internal-Bias		
9	3977393	Thermal, Cut-Off		
9	0011000	(Includes		
		Illus. 15)		
10	694089	Wheel, Blower		
11	8577230	Housing, Blower		
12	8066155	Clip		
13 14	343641 8541818	Screw, 10–16 x 1/2		
15	3977767	Box, Heater Thermostat.		
.0	0011101	221°F		
		(105°C)		
16	3977373	Bracket, Drum		
47	0.400505	Light		
17 18	3403585 8066086	Element, Heater		
10	0000000	Drum Hole Plug		
19	279457	Wire Kit, Terminal		
. •		(For Heater		
		Element Wiring		
		Harness Repair)		
20	489463	Screw, 8–18 x 5/8		
21 22	3390647 3406124	Screw, 8–18 x 1/2 Bulb		
23	3402841			
24	690997	Lens, Drum Light Ring, Tri		
25	3399506	Shaft, L.H.		
26	3399507	Shaft, R.H.		
27	3397590	Roller, Support		
28 29	348197 3359452	Washer, Support Nut, 3/8–16		
30	3403493	Bulkhead		
31	W10136369	Socket Assembly		
32	692526	Ring, Bearing (2)		
33	W10219342	Screw, 8-16 x 1/2		
34	3406130	Seal, Rear Drum		
35	695587	Drum Assembly		
36 37	692490 3976434	Baffle, Drum (2) Bracket, Support		
38	90296	Clip		
39	3403636	Baffle, Drum (1)		
40	339956	Seal		

OPTIONAL PARTS (NOT INCLUDED) For Models: NED4800VQ1 (White)

Illus. **Part**

No. No. **DESCRIPTION**

ACCESSORY PARTS

279948 Kit,

Dryer Repair

3406839 Dry Rack

8522199 Kit, Dryer

Vent Testing

PAINT, TOUCH-UP (1/2oz.)

72017 White

PAINT, PRESSURIZED SPRAY

(12 oz.)

350930 White

350938 Primer, Gray

PAINT, BULK (1 qt.)

799344 White (Uncut)