Network Capability – Baseline Declaration : (1) Track and Route Mileage : (2) Line-speeds : London North Western Route (North) This document provides a snap-shot of the capability of the network as at 1 April 2009.

Hence for operational and planning needs during CP4, capability information should be obtained from the National Electronic Sectional Appendix

LOR Seq. Line of Route Description			ELR	Route	Last Updated
NW6005 001 Manchester Victoria East Jn. to Windsor Bridge South Jn.				LNW North	07/10/06
Location	Mileage M Ch	Running lines & speed restrictions		Signalling & Remarks TCB Manchester North SB (MN) 017	
		DRF URF DRS URS To Miles Platting ▲ 40 ▲ 40			
	0 31 0 12	NW7001 seq 1 40 25 25 25 WELLINGS		Line direction from Miles Plat Manchester Victoria Station is	
Manchester Victoria East Jn.	0 09	25 25 QH LINE 25 25 25 CM LINE 25		DRF = Down Rochdale Fast URF = Up Rochdale Fast DRS = Down Rochdale Slow URS = Up Rochdale Slow	
MANCHESTER VICTORIA	0 00 0 00 0 07 *	40 40 40 20 20 20 40 40 40 40 40 40 40 40 40 40 40 40 40	On	Platform Lengths: Mancheste Platform 3 Permissive PP 255m (279yards) Platform 4 Permissive PP 224m (245yards) Platform 5 Permissive PP -A 215m (235yards)	
Manchester Victoria West Jn.	0 16	US 25 25		215m (235yards) Platform 6 Permissive PP -A 215m (235yards)	
	0 32	25 25 25 25 25 LILI		Turnback 171m (561ft)	
	0 32	25 25 DCM		USF = Up Salford Fast DSF = Down Salford Fast USS = Up Salford Slow DSS = Down Salford Slow DCM = Down Chat Moss UCM = Up Chat Moss	
Deal Street Jn.	0 43	To Ordsall L UCM NW6007 se	ane Jn. q 1	U-SAL = Up Salford	
		□25 ▼ U-SAL D-SAL		D-SAL = Down Salford	