



Impact Torque Nm

Impact Tapping Torque			
Thread Diameter	6mm Steel	12mm Steel	25mm Steel
Diameter Ø	Nm Torque		
M3	105	160	N/A
M4	120	180	N/A
M5	135	200	N/A
M6	140	240	400
1/4"	145	255	410
5/16"	145	265	420
M8	150	280	430
3/8"	165	290	440
M10	170	300	480
M12	185	320	512
1/2"	190	330	525
M14	190	340	544
5/8"	195	355	555
M16	200	360	576
3/4"	245	385	615
M20	315	400	640
7/8"	N/A	515	775
M24	N/A	600	960
1"	N/A	695	1050
M27	N/A	740	1184
M30	N/A	800	1200

Revolutions per minute (Rotary)

Revolutions per minute (Rotary)					
Thread Diameter	Structural Steel <500Nm	Structural Steel <1000Nm	Stainless Steel INOX	Aluminium	Cast Iron (Grey)
Diameter Ø	RPM Range				
M3	960	809	650	2700	1295
M4	730	610	490	2060	975
M5	585	485	385	1750	780
M6	485	405	325	1455	650
1/4"	485	405	325	1455	650
5/16"	365	310	245	1095	485
M8	365	310	245	1095	485
3/8"	295	245	195	870	390
M10	295	245	195	870	390
M12	240	200	162	730	330
1/2"	240	200	162	730	330
M14	210	175	140	625	275
5/8"	185	155	125	550	243
M16	185	155	125	550	243
3/4"	145	125	100	440	194
M20	145	125	100	440	194
7/8"	130	115	92	410	180
M24	120	100	85	370	165
1"	120	100	85	370	165
M27	105	90	75	330	145
M30	95	80	60	310	130

Impact Torque recommendations are the minimum required and for most applications additional torque is a benefit


Best Practice Advice

*GUIDELINE PARAMETERS ONLY - Actual parameters may vary depending on operating conditions

1		ImpactaTaps are recommended for through hole applications only.	7		Regularly apply quality cooling lubricant, especially when drilling thick or hardened materials.
2		Pilot drill the exact tapping size hole for best results	8		Hardened or heat-affected materials may require higher torque, reduced RPM and feed rates and extra coolant
3		Select the correct torque power for impact wrench/drivers using the data range above. If exact match is not available select the closest torque setting above the recommendation.	9		Flame cut/punched holes will require more torque to tap than drilled holes due to heat build up. Caution: Sometimes flame cut holes do not have parallel sides meaning risk of tap breakage.
4		Apply firm, steady feed pressure throughout the cut	10		Tap the hole in one pass where possible, applying adequate lubrication before you start.
5		Ensure the Tap is inserted squarely to the hole - poorly aligned or off-centre taps will greatly increase the risk of breakage.	11		If the tap is over-run from the hole once it is tapped, to remove the risk of cross-threading/damage to the tap, remove the tap from the adapter and locate it in the thread by hand, before reversing.
6		When using cordless tools, torque may drop once the battery charge becomes low. Keep batteries well charged. Low battery charge can lead to lower torque which can break or damage taps as point 3.	12		When re-threading an existing thread, use caution to avoid cross-threading which can lead to tap breakage or thread damage. It is advisable to insert/start the tap into the thread by hand before driving it through at the correct torque

Quick Guide

1	For fastest performance use on impact wrenches & impact drivers
2	Check the minimum torque requirement
3	Laser cut holes & Stainless Steel require higher torque
4	Use appropriate lubrication and correct RPM to achieve long tool life



													
	Impact Torque			Impact Torque			Structural Steel <500Nm	Structural Steel <1000Nm	Stainless Steel INOX	Brass	Cast Iron (Grey)	Plastics	Aluminium
	6mm Thick Steel	12mm Thick Steel	25mm Thick Steel	1/4" Thick Steel	1/2" Thick Steel	1" Thick Steel	32m/Min	18m/Min	12m/Min	32m/Min	16m/Min	30m/Min	45m/Min
Diameter Ø	Nm Torque			Ft Lb Torque			RPM Range						
3/16"	120	150	220	89	111	163	2270	1135	750	2215	1290	1910	3340
#7	125	155	240	93	115	178	2250	1100	745	2100	1220	1800	3100
7/32"	135	160	260	100	119	193	2125	1095	730	1980	1125	1710	3020
6MM	140	170	280	104	126	207	2040	1070	710	1820	1045	1630	2850
1/4"	150	180	290	111	133	215	1945	1040	680	1715	940	1540	2625
7MM	160	195	300	119	144	222	1780	1020	625	1560	810	1410	2240
9/32"	175	220	320	130	163	237	1710	985	595	1410	785	1355	2110
5/16"	190	245	350	141	181	259	1695	915	570	1355	760	1290	1940
8MM	220	270	380	163	200	281	1580	840	550	1340	725	1220	1765
11/32"	260	330	470	193	244	348	1390	800	515	1435	660	1200	1660
9MM	295	360	520	219	267	385	1210	750	420	1130	600	1040	1550
3/8"	300	375	545	222	278	404	1140	665	400	1095	590	1020	1510
10MM	320	395	580	237	293	430	1030	520	385	1020	550	990	1480
11MM	325	405	595	241	300	441	980	500	345	960	490	950	1365
27/64"	330	410	610	244	304	452	925	480	330	890	465	915	1320
7/16"	340	420	625	252	311	463	895	455	320	845	430	890	1305
12MM	350	430	635	259	319	470	860	440	310	825	405	860	1280
1/2"	365	440	650	270	326	481	780	410	375	780	400	805	1210
13MM	370	445	675	274	330	500	720	390	260	730	385	745	1160
14MM	375	455	690	278	337	511	660	350	225	665	340	620	950
16MM	455	580	880	337	430	652	535	290	200	610	310	510	875
18MM	580	720	1120	430	533	830	490	245	190	580	275	440	800
20MM	685	845	1245	507	626	922	450	220	175	550	240	350	730
22MM	720	900	1360	533	667	1007	340	180	160	510	210	330	645

Impact Torque recommendations are the minimum required and for most applications additional torque is a benefit

Best Practice Advice

GUIDELINE PARAMETERS ONLY - Actual parameters may vary depending on operating conditions

1 	Follow guidelines to set correct RPM speed. Incorrect RPM can lead to poor life or tool breakage	4 	Ensure regular application of quality cooling lubricant, especially when drilling thick or hardened materials.
2 	Apply firm, steady feed pressure throughout the cut	5 	Hardened or heat-affected materials may require higher torque, reduced RPM and feed rates and extra coolant
3 	Avoid lateral movement or tilting which can cause damage to the tool	6 	VersaDrive Drill Bits up to 10mm diameter can be driven by an Impact wrench (in rotary mode only)

Quick Guide

1	For fastest performance use on impact wrenches & impact drivers
2	For optimum life and accuracy use with pistol drills and magnet drills
3	Suitable for use on standard construction grade steels such as Structural or Stainless Steel.
4	Use appropriate lubrication and correct RPM to achieve long tool life