


Print this page, the square must be exactly 2 cm x 2 cm

If it is, proceed to print the patterns.

The printer “actual size” option must be enabled and
all resize or adjust option disabled.

PRINT IN A4

0 Cm2 Cm



PATTERN ASSEMBLY INSTRUCTIONS

1

Trace the border of every page joining the corners of the registration marks and cut it off.

2

Assembly the pages as the diagram indicates placing the pages together matching the registration marks



Tape them together following the order of page numbers for rows and columns.

A3 A4 A5 A6

B1 B2 B3 B4 B5 B6

C1 C2 C3 C4 C5 C6

D1 D2 D3 D4 D5 D6

SIZE KEY		
XS		
S		
M		
L		
XL		
XXL		
XXXL		
Seam allowance: 1 cm / 0.4 inches		

SYMBOLS USED IN THIS PATTERN	
	Fabric Lengthwise grain
	Set this side of the pattern on the fold side of fabric


You can print this pattern either in color or B&W.
Select the size in the size key and follow either the color or the style of line to cut the pattern for your size.


To print separate sizes, [show or hide the correspondent layers on your PDF Reader](#)

SLEEVE


Cut 2 pieces








BACK
Cut 2 pieces




NECKLINE FA





ACING

Cut 1 piece



B3







BELT


Cut 1 piece

B4





C1




C2


SKIRT

Cut 2 pieces






▼
C4



C5





FROM

Cut 1 pie




IT
ce


D1




D2



D3






▼
D4



D5



D6

