注: 带底纹的配合为优先配合。

											孔										
基准轴	A	В	С	D	Е	F	G	Н	Js	K	M	N	P	R	S	T	U	V	Х	Y	Z
	间隙配合							过渡配合			过盈配合										
h5						<u>F6</u>	<u>G6</u>	<u>H6</u>	<u>IS6</u>	<u>K6</u>	<u>M6</u>	<u>N6</u>	<u>P6</u>	<u>R6</u>	<u>S6</u>	<u>T6</u>					
						h5	h5	h5	h5	h5	h5	h5	h5	h5	h5	h5					
h6						<u>F7</u>	<u>G7</u>	<u>H7</u>	<u>JS7</u>	<u>K7</u>	<u>M7</u>	<u>N7</u>	<u>P7</u>	<u>R7</u>	<u>S7</u>	<u>T7</u>	<u>U7</u>				
						h6	h6	h6	h6	h6	h6	h6	h6	h6	h6	h6	h6				
h7					<u>E8</u>	<u>F8</u>		<u>H8</u>	<u>JS8</u>	<u>K8</u>	<u>M8</u>	<u>N8</u>									
					h7	h7		h7	h7	h7	h7	h7									
h8				<u>D8</u>	<u>E8</u>	<u>F8</u>		<u>H8</u>													
				h8	h8	h8		h8													
h9				<u>D9</u>	<u>E9</u>	<u>F9</u>		<u>H9</u>													í I
				h9	h9	h9		h9													
h10				<u>D10</u>				<u>H10</u>													
				h10				h10													
h11	<u>A11</u>	<u>B11</u>	<u>C11</u>	<u>D11</u>				<u>H11</u>													
	h11	h11	h11	h11				h11													
h12		<u>B12</u>						<u>H12</u>													
		h12						h12													