


## DIN RS232 to DB 9 ZEBRA PRINTER COMMUNICATION CABLE WIRING

7 PIN DIN to (Indicator)		DB9 9 PIN MALE to (ZEBRA)	
		1	+5V
RXD	2	 2	TXD
TXD	3	 3	RXD
		4	CTS
SG	5	 5	SG
		6	RDY
		7	N/C
		8	RDY
		9	N/C



View of Din Socket in panel

## DB9 RS232 to DB9 ZEBRA PRINTER COMMUNICATION CABLE WIRING

DB9 9 PIN FEMALE to (Indicator)		DB9 9 PIN MALE to (ZEBRA)	
		1	+5V
RXD	3	2	TXD
TXD	2	 3	RXD
		4	CTS
SG	5	5	SG
		6	RDY
		7	N/C
		8	RDY
		9	N/C