NO.	PARTS NO.	DESCRIPTION	APLLIED TO
	7PM-GX600-3	PAN UNIT	GX1000/600/400/300/200
	1043003604	PAN	GX1000/600/400/300/200
1	7PM-GX6000-3	PAN UNIT	GX8000/6000/6100/4000/3000/2000/1200
	1043003603	PAN	GX8000/6000/6100/4000/3000/2000/1200
	1043003608A	DUST PLATE	GX1000/600/400/300/200
2	1042000470C	DUST PLATE	
	1042000470B	DUST PLATE	GX8000/6000/6100/4000/3000/2000
3	1032000465	BREEZE BREAK FRAME	GX8000/6000/6100/4000/3000/2000
	1031000118C	UPPER CASE	GX1000/600/400/300/200
4	1031000118B	UPPER CASE	GX600/400/200
	1031000117D	UPPER CASE	
	1031000117C	UPPER CASE	GX8000/6000/6100/4000/3000/2000
	1031000117B	UPPER CASE	GX8000/6000/6100/4000/2000
5	1032000467A 03+2000467A	PAN SUPPORT ARM GX600 PAN SUPPORT ARM	GX1000/600/400/300/200 GX600/400/200
	1032000466A	PAN SUPPORT ARM GX6000	GX8000/6000/6100/4000/3000/2000
	03+2000466A	PAN SUPPORT ARM	GX8000/6000/6100/4000/2000
	1043003606B	S/A SPRING GX600	GX1000/600/400/300/200
6	1043003606A	S/A SPRING	GX600/400/200
	1043003605B	S/A SPRING	GX8000/6000/6100/4000/3000/2000
	1064007987D	PAN SUPPORT RECEPTOR	
7	1064007987C	PAN SUPPORT RECEPTOR	FOOT PLATE GX/GF
	1064007987B	PAN SUPPORT RECEPTOR	GX8000/6000/6100/4000/2000/600/400/200
40	1044028620A	RECEPTOR	4,1000, 000, 0100, 1000, 2000, 000, 400, 200
	1083003699A	KEY SHEET GX	
8	1083003976	KEY SHEET GF	
9	1074007986	DISPLAY FILTER	
	1083003933-1	CAPACITY LABEL GX600	GX600
	1083003933-2	CAPACITY LABEL GX400	GX400
	1083003933-3	CAPACITY LABEL GX200	GX200
	1083003933-4	CAPACITY LABEL GX6100	GX6100
	1083003933-5	CAPACITY LABEL GX4000	GX4000
1	1083003933-6	CAPACITY LABEL GX2000	GX2000
	1083003933-7	CAPACITY LABEL GX6000	GX6000
	1083003933-8	CAPACITY LABEL GX8000	GX8000
	1083003933-9	CAPACITY LABEL GX300	GX300
	1083003933-10	CAPACITY LABEL GX3000	GX3000
	1083003933-11 1083003933-12	CAPACITY LABEL GX1000 CAPACITY LABEL GX800	GX1000 GX800
10	1083003937-1	CAPACITY LABEL GX800  CAPACITY LABEL GF200	GF200
10	1083003977-1	CAPACITY LABEL GF200  CAPACITY LABEL GF300	GF300
	1083003977-2	CAPACITY LABEL GF1200	GF1200
	1083003977-4	CAPACITY LABEL GF2000	GF2000
	1083003977-5	CAPACITY LABEL GF3000	GF3000
	1083003977-6	CAPACITY LABEL GF6000	GF6000
	1083003977-7	CAPACITY LABEL GF400	GF400
	1083003977-8	CAPACITY LABEL GF600	GF600
	1083003977-9	CAPACITY LABEL GF4000	GF4000
	1083003977-10	CAPACITY LABEL GF6100	GF6100
	1083003977-11	CAPACITY LABEL GF8000	GF8000
1	1083003977-12	CAPACITY LABEL GF1000	GF1000
ļ	1083003977-13	CAPACITY LABEL GF800	GF800
11	1033003595C 1033003594D	BEEM BEEM	GX600/400/300/200 GX8000/6000/6100/4000/3000/2000
	1033003594D	BEEM	GX8000/6000/6100/4000/3000/2000
	10330033940	BEEM	GX800/1000
12	1094008009	BOBBIN	47.000, 1000
	1044008310A-1	FLEXURE (T)	GX200/300/400/600/800/1000
10	04+4008311	FLEXURE (T)	
13	04+4008310	FLEXURE (T)	
	1044008310A-2	FLEXURE (T)	GX2000/3000/4000/6000/8000/6100
	1044008312	FLEXURE (S)	GX200/300/400/600/800/1000
44	1044008313	FLEXURE (S)	GX600/400/200
14	1044008758A	FLEXURE (S)	GX2000/3000/4000/6000/8000/6100
	1044008825	FLEXURE (S)	
15	7PM-GX600-5	MAGNET UNIT	
	705-3009559	ROBERVAL GX600	GX600/400/300/200
	1053003841	ROBERVAL GX600	GX600/400/200
16	705-3003841	ROBERVAL GX600	GX600/400/200
	705-3009557	ROBERVAL GX6000	GX8000/6000/6100/4000/3000/2000
	1053003840A	ROBERVAL GX6000	GX8000/6000/6100/4000/3000/2000
	705-3003840B	ROBERVAL GX800/1000	GX8000/6000/6100/4000/2000
	705-3009558 1084008510	ROBERVAL GX800/1000	GX800/1000
18	1074008510 1074007978A	WIRE SWITCHING CAM	
19	1104007978A	GEARED MOTOR	
13	110700/3/3	ALVIED MOTOL	

NO.	PARTS NO.	DESCRIPTION	APLLIED TO
20	1074026584C	LEVEL VIAL	
20	100A46916	LEVEL VIAL	
	1031000119D	LOWER CASE	
21	1031000119C	LOWER CASE	
22	1031000119A 1064005645	LOWER CASE LEVELING FOOT	
	1084008389A	STEP SHEET (JAPANESE)	
23	1084008389	STEP SHEET (JAPANESE)	,
0.4	1084008415	STEP SHEET (ENGLISH)	
24 25	1073003685A 1044007981	STEP CARD PLATE STEP CARD GUIDE	
26	1154009484	SEESAW SPRING	
	7PZ-3470A	MAIN BOARD GX	GX600/400/300/200
	7PZ-3470B	MAIN BOARD GX	GX6100/4000/3000/2000
	7PZ-3470C	MAIN BOARD GX	GX6000/8000
27	7PZ-3470J	MAIN BOARD GX	GX800/1000 GF600/400/200
	7PZ-3470D 7PZ-3470E	MAIN BOARD GF MAIN BOARD GF	GF6100/400/200 GF6100/4000/3000/2000
	7PZ-3470F	MAIN BOARD GF	GF6000/8000
	7PZ-3470K	MAIN BOARD GF	GF800/1000
28	7PZ-3470-RS232C	INTERFACE BOARD PC3471	
29	7PZ-3470-SENSE	POSITION SENSOR BOARD PC3472	
30	7PZ-3470-MOTER	MOTOR BOARD PC3473	GX
31	7PZ-3470-SW	SWICH BOARD PC3474	
32	1064008388 7PZ-3470-CONNEC	RUBBER KEY TOP CONNECTOR BOARD PC3475	
	1MFAMZ51-RS	ANALOG MODULE(PoHS:Preparing)	
34	7MF -AMZ51	ANALOG MODULE	
35	7PA-GX-JIG	GX/GF JIG	
36	1PC3516	FLEXIBLE PRINT CIRCUIT	
}	AX-073003691-S 1073003691	PROTECTIVE COVER PROTECTIVE COVER	600/400/200
	AX-073003692-S	PROTECTIVE COVER	2000/4000/6000/6100/8000
	1073003692	PROTECTIVE COVER	
	1KO1798A	Interface board cable (JST)	707.0470 / 15. 40. 707.0470 / 154
	1KO1798 1KO1799A	Interface board cable (JAE)  Motor board cable (JST)	7PZ-3470/J5 ⇔ 7PZ-3470/J5A
	1KO1799A	Motor board cable (JAE)	7PZ-3470/J6 ⇔ 7PZ-3470-MOTOR/J6A
	1KO1800A	Connection board cable (JST)	
	1KO1800 1KO3998-04-005	Connection board cable (JAE) Swich board cable (JST)	7PZ-3470/J11 ⇔ 7PZ3470-CONNEC/J11A
	1KO2446-04-005	Swich board cable (JAE)	7PZ-3470/J4 ⇔ 7PZ-3470-SW/J4A
	1KO964-04W005	Swich board cable	7PZ-3470/J4 ⇔ 7PZ-3470-SW/J4A
	105B43355	Under hook	
	107A46858 1073003599	Under hook cover	
37	1EDVFD32-1001	VFD	
0,	1EDCM1887G	VFD	
	1UCD780058B-182 1UCD780058B-161	CPU CPU	
	1UCD780058B-102	CPU	GX/GF
	1094008166	Breeze break	GX200 ~ 1000
38	1EBCR2032-WT12 1EJ0470-01-230	Ltium battery	
41	1FS218.800	Jack Huse	
39	1SKEVQ21307K	Switch	SWICH BOARD
	100C42770F	TOP GLASS(GX-10/11)	GX-10/11
}	1194008156 100C42768G	FRONT GLASS(GX-10/11) SIDE GLASS(GX-10/11)	GX-10/11 GX-10/11
	1033003602A	WEIGHT FRAME	GX-10/11
	1RLMP10R00	RESISTOR	GX6000/8000
	1RLMP84R00	RESISTOR	GX200
	1RLMP45R00 1054007985	RESISTOR	GX2000
	1042000782A	500g INTERNAL MASS BASE PLATE GX-10	GX-10
	1034007969A	SEA SAW	GX/GP
	1073003978A	Internal mass guide	
	1033003593	Internal mass guide Sensor UNIT GF6000	NO Sales sahadula
	1UC93LC66B/P	EEPROM	NO Sales schedule
	AX-TB248	AC100-240V Aplug	
1	AX-TB237	40.41	
	AX-TB109	AC Adaptor AC100V GX-10K SENSOR ASSY	
<b></b>		da Toll GENGOIL AGGI	
L			



