

Digital Blood Pressure Monitor

Model UA-767 Plus

Instruction Manual

Contents

Dear Customers	2
Preliminary Remarks	2
Precautions	2
Parts Identification	3
Symbols	4
Using the Monitor Installing / Changing The Batteries	
Connecting The Air Hose	
Attaching The Arm Cuff	
How To Take Proper Measurements	
Measurement	
After Measurement	
Measurements	
Normal Measurement	
Measurement With The Desired Systolic Pressure Notes For Proper Measurement	
What Is An Irregular Heartbeat	9
Pressure Bar Indicator	9
WHO Classification Indicator	9
About Blood Pressure	10
What Is Blood Pressure?	
What Is Hypertension And How Is It Controlled?	10
Why Measure Blood Pressure At Home?	10
WHO Blood Pressure Classification	
Blood Pressure Variations	10
Troubleshooting	11
Maintenance	12
Technical Data	12

Dear Customers

Congratulations on purchasing a state-of-the-art A&D blood pressure monitor, one of the most advanced monitors available today. Designed for ease of use and accuracy, this monitor will facilitate your daily blood pressure regimen.

We recommend that you read through this manual carefully before using the device for the first time.


Preliminary Remarks

- This device conforms to the European Directive 93/42 EEC for Medical Products. This is made evident by the CE mark of conformity accompanied by the reference number of the designated authority.
- ☐ The device is designed for use on adults only, not newborns or infants.
- Environment for use
 The device is for use indoors.

Precentions

- Precision components are used in the construction of this device. Extremes in temperature, humidity, direct sunlight, shock or dust should be avoided.
- ☐ Clean the device with a soft, dry cloth. Never use thinner, alcohol, benzine, or wet cloth.
- Avoid tightly folding the cuff or storing the hose tightly twisted for long periods, as such treatment may shorten the life of the components.
- The device and cuff are not water resistant. Prevent rain, sweat and water from soiling the device and cuff.
- Measurements may be distorted if the device is used close to televisions, microwave ovens, cellular telephones, X-ray or other devices with strong electrical fields.
- Used equipment, parts and batteries are not treated as ordinary household waste, and must be disposed of according to the applicable local regulations.

Parts Identification




Symbols

Symbols	Function / Meaning	Recommended Action		
<u>(</u>	Standby and Turn the device on.			
⊕(R6(AA))⊝	Battery installation guide			
	Direct current			
SN	Serial number			
20022	Date of manufacture	Management 1		
太	Type BF: Device, cuff and tubing are designed to provide special protection against electrical shocks.	A PROPERTY OF THE PROPERTY OF		
•	The indicator while measurement is in progress. It blinks while detecting the pulse.	Measurement is in progress. Remain as still as possible.		
(()	Irregular Heartbeat indicator. (I.H.B.) The indicator that detects irregular heartbeats or any excessive body movement during the measurement.			
M	Previous measurements stored in MEMORY.	· .		
Full Battery	The battery power indicator during measurement.			
C low Battery	The battery is low when it blinks.	Replace all batteries with new ones, when the indicator blinks.		
	Unstable blood pressure due to movement during the measurement.	Try measurement again. Remain very still during the measurement.		
Err	The systolic and diastolic values are within 10 mmHg of each other. The pressure value did not increase	Fasten the cuff correctly,		
Euf	during inflation. The cuff is not fastened correctly.	and try the measurement again.		
PUL, DISPLAY ERROR	The pulse is not detected correctly.			
SYS	Systolic blood pressure in mmHg			
DIA	Diastolic blood pressure in mmHg.			
PUL./min	Pulse per minute			
C €0366	EC directive medical device label	-		
C N92	The certification trade mark registered to the Australian Communication Authority by the Trademarks office.			

Using the Moniton

Installing / Changing The Batteries

- 1. Slide the battery cover up to open it.
- 2. Remove the used batteries and insert new batteries into the battery compartment as shown, taking care that the polarities (+) and (-) are correct.
- Slide the battery cover down to close it.
 Use only R6P, AA batteries.




CAUTION

- Insert the batteries as shown in the battery compartment. If not, the device will not work.
- When (LOW BATTERY mark) blinks in the display, replace all batteries with new ones. Do not mix old and new batteries. It may shorten the battery life, or cause the device to malfunction.
- (LOW BATTERY mark) does not appear when the batteries are drained.
- □ Battery life varies with the ambient temperature and may be shorter at low temperatures.
- ☐ Remove the batteries if the device is not to be used for a long time. The batteries may leak and cause a malfunction.
- Use the specified batteries only. The batteries provided with the device are for testing monitor performance and may have a limited life.

Connecting The Air Hose

Insert the air connector plug into the air socket firmly.



Using the Monitor

Attaching The Arm Cuff

- Wrap the cuff around the upper arm, about 2 - 3 cm above the elbow, as shown. Place the cuff directly against the skin, as clothing may cause a faint pulse, and result in a measurement error.
- Constriction of the upper arm, caused by rolling up a shirtsleeve, may prevent accurate readings.



For the most accurate blood pressure measurement:

- Sit comfortably at a table.
 Rest your arm on the table.
- ☐ Relax for about five to ten minutes before measurement.
- □ Place the center of the cuff at the same height as your heart.
- □ Remain still and keep quiet during measurement.
- Do not measure right after physical exercise or a bath. Rest for twenty or thirty minutes before taking the measurement.
- ☐ Try to measure your blood pressure at the same time every day.

Measurement


During measurement, it is normal for the cuff to feel very tight. (Do not be alarmed)

After Measurement

After measurement, press the START button to turn off the power. Remove the cuff and record your data.

Note: The device has an automatic power shut-off function, which turns the power off approximately one minute after measurement.

Allow at least ten minutes between measurements on the same person.



Measurements

Model UA-767 Plus is designed to detect the pulse and to inflate the cuff to a systolic pressure level automatically.

If your systolic pressure is expected to exceed 230 mmHg or you use the optional small cuff, read "Measurement with the desired systolic pressure" on next page.

Normal Measurement

- Place the cuff on the arm (preferably the left arm).
 Sit quietly during measurement.
- 2. Press the START button.

 The last data of systolic and diastolic pressure and pulse rate are displayed briefly. Then the display changes, as indicated in the figure at the right, as the measurement begins. The cuff starts to inflate. It is normal for the cuff to feel very tight. A pressure bar indicator is displayed, as in the figure at the right, during inflation.

Note: If you wish to stop inflation at any time, press the START button again.

3. When inflation is complete, deflation starts automatically and the (heart mark) blinks, indicating that the measurement is in progress. Once the pulse is detected, the mark flashes with each pulse beat.

Note: If an appropriate pressure is not obtained, the device starts to inflate again automatically.

- 4. When the measurement is complete, the systolic and diastolic pressure readings and pulse rate are displayed. The cuff exhausts the remaining air and deflates completely.
- 5. Press the START button again to turn off the power.

At heart level START | button The last data at initial display Starts inflation Pressurizing Measurement in progress Systolic pressure Diastolic pressure WHO classification Pulse rate Exhausts remaining air automatically


Note: Model UA-767 Plus is provided with an automatic power shut-off function. Allow at least ten minutes between measurements on the same person.

Measurements

Measurement With The Desired Systolic Pressure

If your systolic pressure is expected to exceed 230 mmHg or you use the optional small cuff, use this procedure.

- 1. Place the cuff on the arm (preferably the left arm).
- 2. Press and hold the START button until a number about 30 to 40 mmHg higher than your expected systolic pressure appears.
- 3. Release the START button to start measurement, when the desired number is reached. Then continue to measure your blood pressure as described on the previous page.



Notes For Proper Measurement

- Sit down in a comfortable position. Place the arm to be used for the measurement on a table or other support so that the center of the cuff will be at the same height as your heart.
- Relax for about five or ten minutes before taking a measurement. If you are excited or depressed by emotional stress, the measurement will reflect this stress as a higher (or lower) than normal blood pressure reading and the pulse reading will usually be faster than normal.
- An individual's blood pressure varies constantly, depending on what you are doing and what you have eaten. What you drink can have a very strong and rapid effect on your blood pressure.
- This device bases its measurements on the heartbeat. If you have a very weak or irregular heartbeat, the device may have difficulty determining your blood pressure.
- □ Should the device detect a condition that is abnormal, it will stop the measurement and display an error symbol. See page 4 for the description of symbols.
- This blood pressure monitor is intended for use by adults only. Consult with your physician before using this device on a child. A child should not use this device unattended.


What is An irregular Hearibeat

Model UA-767 Plus blood pressure monitor provides a blood pressure and pulse rate measurement even when an irregular heartbeat occurs. An irregular heartbeat is defined as a heartbeat that varies by 25% from the average of all heartbeats during the blood pressure measurement. It is important that you be relaxed, remain still and do not talk during measurements.

Note: We recommend contacting your physician if you see this (()) indicator frequently.

Pressure Barlnofertor

The indicator monitors the progress of pressure during measurement.




W40 Classification Indicator

Each six segments of the bar indicator correspond to the WHO blood pressure classification described on the next page.

WHO Classification Indicator

Severe hypertension
Moderate hypertension
Mild hypertension
High normal
Normal
Optimal

■ : The indicator displays a segment, based on the current data, corresponding to the WHO classification.



About Blood Pressure

What is Blood Pressure?

Blood pressure is the force exerted by blood against the walls of the arteries. Systolic pressure occurs when the heart contracts. Diastolic pressure occurs when the heart expands. Blood pressure is measured in millimeters of mercury (mmHg). One's natural blood pressure is represented by the fundamental pressure, which is measured first thing in the morning while one is still at rest and before eating.

What is Hypertension And How is it Controlled?

Hypertension, an abnormally high arterial blood pressure, if left unattended, can cause many health problems including stroke and heart attack. Hypertension can be controlled by altering lifestyle, avoiding stress, and with medication under a doctor's supervision.

To prevent hypertension or keep it under control:

•	4	•	•		
Do not sm	noke			Exercise	regularly

- □ Have regular physical checkups Reduce sait and fat intake
- Maintain proper weight

Why Measure Blood Pressure At Home?


Blood pressure measured at a clinic or doctor's office may cause apprehension and can produce an elevated reading, 25 to 30 mmHg higher than that measured at home. Home measurement reduces the effects of outside influences on blood pressure readings, supplements the doctor's readings and provides a more accurate, complete blood pressure history.


WHO Blood Pressure Classification

Standards to assess high Reference Material: Journal of Hypertension 1999, Vol 17 No.2 peen in the chart below.

In a world in the world in the world in the chart below.

In a world in the world in th without mmHg






Blood Pressure Variations

30 to 50 mmHg due to various conditions during the day. In hypertensive individuals' variations are even more pronounced. Normally, the blood pressure rises while at work or play and falls to its lowest levels during sleep. So, do not be overly concerned by the results of one measurement.

Take measurements at the same time every day using the procedure

described in this manual to get to know your normal blood pressure. Regular readings give a more comprehensive blood pressure history. Be sure to note date and time when recording your blood pressure. Consult your doctor to interpret your blood pressure data.



enticontechduoin

Problem	Possible Reason	Recommended Action		
Nothing appears in the	Batteries are drained.	Replace all batteries with new ones.		
display, even when the power is turned on.	Battery terminals are not in the correct position.	Reinstall the batteries with negative and positive terminals matching those indicated on the battery compartment.		
The cuff does not inflate.	Battery voltage is too low. (LOW BATTERY mark) blinks. [If the batteries are drained completely, the mark does not appear.]	Replace all batteries with new ones.		
The unit does not measure. Readings are too high or too low.	The cuff is not fastened properly.	Fasten the cuff correctly.		
	You moved your arm or body during the measurement.	Make sure you remain very still and quiet during the measurement.		
	The cuff position is not correct.	Sit comfortably and still. Raise your hand so that the cuff is at the same level as your heart.		
		If you have a very weak or irregular heat beat, the device may have difficulty in determining your blood pressure.		
Other	The value is different from that measured at a clinic or doctor's office.	See "Why measure blood pressure at home".		
Oulei		Remove the batteries. Place them back properly and try the measurement again.		

Note: If the actions described above do not solve the problem, contact the dealer. Do not attempt to open or repair this product, as any attempt to do so will make your warranty invalid.

Maintenance

Do not open the device. It uses delicate electrical components and an intricate air unit that could be damaged. If you cannot fix the problem using the troubleshooting instructions, request service from your dealer or from the A&D service group. The A&D service group will provide technical information, spare parts and units to authorized dealers.

The device was designed and manufactured for a long service life. However it is generally recommended to have the monitor inspected every 2 years, to ensure proper functioning and accuracy. Please contact either your authorized dealer or A&D for maintenance.

ilechinical il Daita

Type UA-767 Plus

Measurement method Oscillometric measurement Measurement range Pressure: 20 - 280 mmHg

Pulse: 40 - 200 beats / minute

Measurement accuracy Pressure: ±3 mmHg or 2%, whichever is greater

Pulse: ±5%

Power supply 4 x 1.5V batteries (R6P or AA)

Upper arm circumference 22 - 32 cm
Classification Type BF 🛧

Clinical test According to ANSI / AAMI SP-10 1987

EMC IEC 60601-1-2: 2001

Operating condition +10°C to +40°C / 30%RH to 85 %RH
Storage condition -10°C to +60°C / 30%RH to 85 %RH
Dimensions Approx. 147 [W] x 64 [H] x 110 [D] mm
Weight Approx. 300 g, excepting batteries

C€0366

Note: Specifications are subject to change without prior notice.