HV/HW-G M/L type SPARE PARTS PRICE LIST ANY PRICE, F.O.B JAPAN IN J YEN

NO.	PARTS NO.	DESCRIPTION	APPLIED TO
1	1071000097A	UPPER CASE	,
	1071000098A	LOWER CASE	
2	1071000098	LOWER CASE	HV/HW-G
3	1072000417	BATTERY COVER	1.07/1.04/1.01
4 5	1071000099	BATTERY CASE BATTERY GUIDE	HV/HW-GL HV/HW-GL
6	1073003238 1073003185	BATTERY GOIDE BATTERY HOLDER	HV/HW-GL
7	1154007225	SPRING (-)	HV/HW-GL
8	1154007226	SPRING (+)	HV/HW-GL
9	1004007568	RIBBON	HV/HW-GV
10	1073003186	REAR COVER	
13	105A42208	LOCK SCREW	
		E-RING M2.6	
11	1073003184	CONNECTOR COVER	
12	1074007221 1084007480-2B	KEY TOP FILTER A HV60KGV-EX	HV60KGV
	1084007480-2B	FILTER A HV80KGV-EX	HV200KGV
ŀ	1084007480-4B	FILTER A HVKGV-EG	HVKGV-EG
ŀ	1084007481-2B	FILTER B HV60KGL-EX	HV60KGL
ľ	1084007481-3B	FILTER B HV200KGL-EX	HV200KGL
	1084007481-4B	FILTER B HVKGL-EG	HVKGL-EG
14	1084007482-2B	FILTER A HV60KGV-JA	HV60KGV-JA
14	1084007482-3B	FILTER A HV200KGV-JA	HV200KGV-JA
	1084007483-2B	FILTER B HV60KGL-JA	HV60KGL-JA
1	1084007483-3B	FILTER B HV200KGL-JA FILTER A HW-GV JA	HV200KGL-JA
	1084007475B 1084007222B	FILTER A HW-GV JA FILTER A HW-GV EX/EG	HW-GV JA HW-GV EX/EG
}	1084007222B 1084007476B	FILTER B HW-GL JA	HW-GL JA
	1084007223B		HW-GL EX/EG
	1083003337-2	CAPACITY LABEL HV60KGV/L EX/JA	
ľ	1083003337-3	CAPACITY LABEL HV200KGV/L EX/JA	HV200KGV/L EX/JA
	1083003337-5	CAPACITY LABEL HW60KGV/L EX/JA	
	1083003337-6	CAPACITY LABEL HW100KGV/L EX/JA	
1	1083003337-7	CAPACITY LABEL HW200KGV/L EX/JA	
15	1083003337-9		HV60KGV/L EG HV200KGV/L EG
	1083003337-10 1083003337-12	CAPACITY LABEL HV200KGV/L EG CAPACITY LABEL HW60KGV/L EG	HW60KGV/L EG
	1083003337-12	CAPACITY LABEL HW100KGV/L EG	HW100KGV/L EG
	1083003337-14	CAPACITY LABEL HW200KGV/L EG	HW200KGV/L EG
	1083003337-20	CAPACITY LABEL HW1200KGV/L	HW1200KGV/L EG
	1084007469	KEY SHEET HV-GV/L JA	HV-GV/L JA
	1084007470	KEY SHEET HW-GV/L JA	HW-GV/L JA
	1084007462	KEY SHEET HV-GV EX/EG	HV-GV EX/EG
16	1084007463	KEY SHEET HV-GL EX/EG	HV-GL EX/EG
	1084007464	KEY SHEET HW-GV EX/EG	HW-GV EX/EG
	1084007465A 1084007465	KEY SHEET HW-GL EX/EG KEY SHEET HW-GL EX/EG	HW-GL EX/EG HW-GL EX/EG
17	1084007465	MODEL LABEL HV60KGV	HV60KGV
	1084007456-3	MODEL LABEL HV200KGV	HV200KGV
	1084007456-5	MODEL LABEL HV60KGL	HV60KGL
	1084007456-6	MODEL LABEL HV200KGL	HV200KGL
	1084007456-8	MODEL LABEL HW60KGV	HW60KGV
	1084007456-9	MODEL LABEL HW100KGV	HW100KGV
	1084007456-10	MODEL LABEL HW200KGV	HW200KGV
	1084007456-12 1084007456-13	MODEL LABEL HW60KGL MODEL LABEL HW100KGL	HW60KGL HW100KGL
	1084007456-13	MODEL LABEL HW100KGL	HW200KGL
	1084007456-18	MODEL LABEL HW1200KGL	2001.02
	1084007456-22	MODEL LABEL HW1200KGV	
18	1074006723	CENTER PAD	
19	1073003002	CORNER PAD	
20	1063003043	DIAPHRAGM	
21	1043003044	RING A	
22	1043003045	RING B	FON
23	1031000079A 1031000076A	PAN SUPPORT MIDDLE PAN SUPPORT LARGE	60K 100K/200K
24	1062000400A	GASKET (M/L)	10010/2001
25	1043003047	LOAD ANGLE	
26	1044006924	FIXED PLATE A	
27	1044006925	FIXED PLATE B	
28	1154006926A	LEAF SPRING	

HV/HW-G M/L type SPARE PARTS PRICE LIST ANY PRICE, F.O.B JAPAN IN J YEN

NO.	PARTS NO.	DESCRIPTION	APPLIED TO
29	1071000082B 1071000082A	L.C. COVER L.C. COVER	
	1044006923	L.C. COVER	
30	1044007029	L.C.PLATE LARGE	
31	1044007031B	STOPPER PLATE	
32	1073007273 1073003003	LEVELING FOOT M10 LEVELING LEG	
	107B49929	LEVELING LEG	
	1054008504	BUSH	
	AZ-OTHER3	M10 NUT SUS	
33	1031000078D 1031000078C	BASE CASTING MIDDLE BASE CASTING MIDDLE	60K
33	1031000075C	BASE CASTING (L)	100K/200K
	1043003049B	UNDER COVER `	
34	1043003049	UNDER COVER	
35	1031000194B 1031000194A	POLE BASE (M/L) POLE BASE (M/L)	
	1031000077A	POLE BASE LARGE	
	1074007073A	COVER(POLE)	
41	1074007441A 1043003108E	LEVEL FOOT(POLE) COLUMN (POLE)	
36	1043003108E	COLUMN (POLE)	
37	707-A21456	POLE BLAKET ÚNIT	
49	107A21456A	POLE BLAKET	001/
ŀ	1043003046C 1043003046B	PAN MIDDLE PAN MIDDLE	60K
38	1043003040B	PAN LARGE	100K/200K
	1043003087B	PAN LARGE	
20	7LC-127-60K	LOAD CELL 100K	
39	7LC-128-100K 7LC-128-220K	LOAD CELL 100K LOAD CELL 220K	
	7PZ-3414A	MAIN BOARD TypeV	
	7PZ-3414	MAIN BOARD TypeV	
40	7PZ-3413A 7PZ-3413	MAIN BOARD TypeL MAIN BOARD TypeL	
42	7PZ-3416	RS232 BOARD	
48	1JA4480-01-4151	DIN CONNECTOR	PZ3416
	1074017252	CABLE CLAMP	
43	1044007030	CABLE CLAMP	
50 52	7PZ-3415 7PZ-3418	POWER RELAY BOARD TypeV POWER BOARD TypeL	HV/HW-GV HV/HW-GL
53	1EJ0470-01-230	AC ADAPTOR SOCKET (PZ3418)	HV/HW-GL
	1084007461	ADAPTER LABEL	HV/HW-GL
44	1SKEVQPAD07K 1SKEVQ-QS307K	KEY SWITCH KEY SWITCH	PC3413E/PC3414F~ ~PC3413D/PC3414E
44	1044006922	PLATE MIDDLE	PC3413D/FC3414E
	1054033989		
	105A44614	SPACER	
	106B42081A 1084004017A	LCD PILLOW CAUTION LABEL	
	110C150	CABLE TIE	
	1054011619		
47	110VFM12300	VENTFILTER	
47	110MR16 1UCD789407A-108	Bubble Spirit Level CPU	2007/2/1
ŀ	1UCD789407A-108	CPU	2301/ 2/ 1
	1143003217A	VINIL COVER	
	1154007471A	EARTH SPRING	
	1EDCL1773G	VFD PZ3414	HV/HW-GV PZ3414
	1EDHT4096A-TRP1	LIQUID CRYSTAL DISPLAY (LCD)	HV/HW-GL PZ3413
45	1TF472A 1ETSR-6P-4	TRANSFORMER CABLE CLAMP	HV/HW-GV
75	1FSEAWK-315MA	FUSE AC100V/120V (PZ3415)	HV/HW-GV
51	1FSEAWK-200MA	FUSE AC200V (PZ3415)	HV/HW-GV
	7PA-HVWGL-1	DISPLAY UNIT GL	HV/HW-GL
	7PA-HVWGV-1	DISPLAY UNIT GV	HV/HW-GV
40	1KO964-09W020	CABLE MAIN-RS232C(7PZ-3416)	MAIN - RS232C(7PZ-3416)
46	1044007427 1UCMAX232ECPE	HOLD PLATE IC U1 PZ3416/PZ3458	
ŀ	1UCMAX232ECPE 1UCMAX232CPE	IC U1 PZ3416/PZ3458 IC U1 PZ3416/PZ3458	
	1KO1570A	POWER CABLE (A PLUG:JA/USA)	HV/HW-GV
	1KO1571A	POWER CABLE (EU PLUG)	HV/HW-GV
	1KO1572A	POWER CABLE (KOREA PLUG)	HV/HW-GV

