## EK-i / EW-i Series SPARE PARTS PRICE LIST ANY PRICES F.O.B. JASPAN IN J. YEN

No	Parts No.	Description	Applied to	
140	Parts No. 1044015279	Pan (110) SUS	Applied to  EK120i/200i/300i/410i/610i, EW150i	
4	104A46385	Pan (S)	EK-120i/200i/300i/410i/010i, EW150i	
1	AX-04A44255	Pan(L)		
	1044007526	Pan (L)	EK600i/1200i/2000i/3000i/4100i/6000i/6100i/12Ki, EW1500i/12Ki	
	1074022590	Pan Support (S)	EK120i/200i/300i/410i/610i, EW150i	
2	1074001229	Pan Support (S)	EK120i/200i/300i/410i/610i, EW150i	
_	1043007830	Pan Support (Ni)	EK600i/1200i/2000i/3000i/4100i/6000i/6100i/12Ki, EW1500i/12Ki	
	1043006015A	Pan Support (Ni)	EK-600i/1200i/2000i/3000i/6000i/12Ki, EW-1500i/12Ki	
***************************************	1010000010100	M5X10 PAN HEAD WS	EK600i/1200i/2000i/3000i/4100i/6000i/6100i/12Ki, EW1500i/12Ki	
3	1043005648B	Earth Plate (S)	EK-120i/200i/300i, EW150i	
4	1043005647B	Earth Plate (L)	EK600i/1200i/2000i/3000i/4100i/6000i/6100i12Ki, EW1500i/12Ki	***************************************
4	1154011703B 1083005660-1	Earth spring Model label (EK120i)		
	1083005660-2	Model label (EK200i)		
	1083005660-3	Model label (EK300i)		
	1083007628-1	Model label (EK410i)		
	1083005660-4	Model label (EK600i)		
	1083007628-2	Model label (EK610i)		
	1083005660-5	Model label (EK1200i)		
	1083005660-6	Model label (EK2000i)		
	1083005660-7	Model label (EK3000i)		
5	1083007628-3	Model label (EK4100i)		
	1083005660-8	Model label (EK6000i)		
	1083007628-4	Model label (EK6100i)		
	1083005660-9	Model label (EK12Ki)		
	1083005661-1	Model label (EW150i)		***************************************
	1083005661-2	Model label (EW1500i)		
	1083005661-3	Model label (EW12Ki)		
	1083014185-1	Model label (EW12Ki-K)		
	1083014185-2	Model label (EW1500i-K)		
	1083014185-3 1083005577A	Model label (EW600i-K)  Key sheet (EK-i)		
	1083005577	Key sheet (EK-i)		
6	1083005578A	Key sheet (EW-i)		
	1083005578	Key sheet (EW-i)		
	1074025120	Filter		
7	1074011704	Filter		
0	1071000220C	Upper Case		
8	1071000220B	Upper Case		
	1044011698	Load angle (410i)	EK120i/200i/300i/410i/610i, EW150i	
9	1044011699A	Load angle (S)	EK-120i/200i/300i, EW150i	
	1044011697	Load angle (L)	EK600i/1200i/2000i/3000i/4100i/6000i/6100i/12Ki, EW1500i/12Ki	
10	1044011701	Cell spacer (S)	EK120i/200i/300i/410i/610i, EW150i	
	1044011700	Cell spacer (L)	EK600i/1200i/2000i/3000i/4100i/6000i/6100i12Ki, EW1500i/12Ki	
4.4	1044012015A	Chassis (S) Preparing		
11	1044012015	Chassis (S)	EK120i/200i/300i/410i/610i, EW150i	
10	1044012014	Chassis (L)	EK600i/1200i/2000i/3000i/4100i/6000i/6100i/12Ki, EW1500i/12Ki	
12 13	1044005255 1043004953	Shield case (UPPER) Shield case (B)		
14	1073005346A	Conector holder		
15	1073005346A	Blank cover		
16	110MR14	Level Vial		
17	1073005344A	CAL. cover		••••••
	1064011084B-2	Level foot (BLACK)		
18	1064011084A-2	Level foot (BLACK)		
	1064011084B	Level foot(GRAY)	ONLY THE STOCK	
	1064011084A	Level foot (GRAY)		
19	1074000318	Cap (B)		
20	1071000221C	Lower case		
<del>-</del>	1071000221B	Lower case		
	7LC-148-300-FE	Load cell (300g)	EK120i/200i/300i/410i/610i, EW150i	
21	7LC-140-3000-FE	Load cell (3k)	EK600i/1200i/2000i/3000i, EW1500i	
	7LC-140-6000-FE	Load cell	EK4100i/6100i	
	7LC-140-12K-FE	Load cell (12k)	EK6000i/12Ki, EW12Ki	
22	7PZ-3762	PCB	EK600i/1200i/2000i/3000i/6000i/12Ki, EW1500i/12Ki	
23	7PZ-3762A 1EDBTJ038	PCB LCD EK/EW-I	EK120i/200i/300i/410i/610i/4100i/6100i, EW150i	
۷3	1EDB13038	LED EK/EW-I		
24	1SKSKHHAK	KEY Switch		
27	1SKEVQPF06K	CLA Switch		
	1UCMN101C58A-AG	CPU P120 EK/EW-I		
25	1UCMN101C58A-AF	CPU EK/EW-I		
	AX-3005824-5S	Protective cover	EK120/200/300/410/610	***************************************
	1073005824D	1	,	
	107A45440	Lock screw (EKW-09i)		
26		Lock screw (EKW-09i) DC JACK		
26 28	107A45440			

