HVW-WP SERIES SPARE PARTS PRICE LIST

EX VIEW NO.	PIC. NO.	PARTS NO.	DESCRIPTION	APPLIED TO
5	1	1072000505A 1094008644	PCB FRAME PCB FRAME	
		1042000512B	FRONT COVER	
6	2	1042000512	FRONT COVER	
7		110M6KNOB	M6 KNOB	
A	3		M6X15	
8	4	7PZ-3414	MAIN PCB (V)	
		1084008635	KEY SHEET	HW10/60/100/200KVWP-EX
	5	1004000033	(HW10/60/100/200KVWP-EX)	11W10/00/100/200RVWF-EX
11		1084008783	KEY SHEET (HV15/60/200KVWP-	HV15/60/200KVWP-EX
			EX)	
		1084008636 1083003913-1	KEY SHEET HW-KVWP (JA) CAP. LABEL(HV15KVWP-EX)	HW-KVWP (JA) HV15KVWP-EX
	6	1083003913-2	CAP. LABEL(HV13KVWP-EX)	HV60KVWP-EX
		1083003913-3	CAP. LABEL(HV200KVWP-EX)	HV200KVWP-EX
12		1083003913-4	CAP. LABEL(HW10KVWP-EX)	HW10KVWP-EX
		1083003913-5	CAP. LABEL(HW60KVWP-EX)	HW60KVWP-EX
		1083003913-6	CAP. LABEL(HW100KVWP-EX)	HW100KVWP-EX
		1083003913-7	CAP. LABEL(HV200KVWP-EX)	HV200KVWP-EX
		1084008638	FILTER (HW10/60/100/200KVWP-	HW10/60/100/200KVWP-EX
	7		EX)	
		1084008639-1	FILTER (HV15KVWP-EX)	HV15KVWP-EX
13		1084008639-2	FILTER (HV60KVWP-EX)	HV60KVWP-EX
		1084008639-3 1084008641-1	FILTER (HV200KVWP-EX)	HV200KVWP-EX
		1084008641-1	FILTER A (HV15KVWP-JA) FILTER A (HV60KVWP-JA)	
		1084008641-3	FILTER A (HV00KVWP-JA)	
14	8	1074007221	KEY TOP	
15	9	7PZ-3416	RS232C BOARD	
19	10	7PZ-3415	POWER RELAY BOARD	
20	11	1093004248A	MAIN PACKING UNIT	
20		1093004248	MAIN PACKING UNIT	
21	12 13	1042000506C	REAR COVER	
		1042000506	REAR COVER	
22		110WJ-16A	CABLE CLAMP 16A	
		110NEC-01-16A 1064018731	CABLE CLAMP 16A AC PACKING	
23	14	1064008621B	AC PACKING AC PACKING	
20		1064008621	AC PACKING	
0.4	15 16	110WJ-20A	CABLE CLAMP 20A	
24		110NEC-01-20A	CABLE CLAMP 20A	
25		1064008622A	RS232C/421 PACKING	
23		1064008622	RS232C/422 PACKING	
26	17	110WJ-12A	CABLE CLAMP 12A	
		110NEC-01-12A	CABLE CLAMP 12A	
27	18	1064018730	L/C PACKING	
21		1064008623A 1064008623	L/C PACKING L/C 4.5 PACKING	
		1064008880A	CAL. PACKING	
30		1064008880	CAL. PACKING	
31	20	1044008879	CAL. COVER	
32	21	1054008881	CAL. SCREW	
38	22	1054008782	WP BOLT	
9		1073003989	CAL. SW. GUIDE	
28		1064008664	O-LING 2.8	
29		1064008665	O-LING 3.8	
33		1064008666	O-LING 5.5	
34		1054008627	SEALING BOLT	
39		1084014290 1FSEAWK-200MA	PCB CHASSIS TAPE FUSE AC230V	AC230V
		1FSEAWK-200MA	FUSE AC230V	AC100V/120V
		1KO964-09W020	CABLE MAIN-RS232C (7PZ-3416)	
		1KO1570A	AC POWER CABLE A PLUG	JA PLUG(A)
		INOTOTOR	1.6m	on I Louin

HVW-WP SERIES SPARE PARTS PRICE LIST

PLAT (S)- EXP		PLAT (L)- EXP	PIC. NO			APPLIED TO		
	PLAT (M)- EXP			PARTS NO.	DESCRIPTION	Small size HV15KVWP HW10KWP	Middium size HV60KVWP HW60KVWP	Large size HV200KVWP HW200KVWP
24			1	1043003955	PAN, SMALL	V		
	19		1	1043003956	PAN, MIDDLE SUS304		V	
		18	1	1043003957	PAN, LARGE			V
2	14	14	2	1073003002	CORNER PAD HVW-G	V	V	V
1	17	16	3	1074006723	CENTER PAD HVW-G	V	V	V
9			4	1032000403B	PAN SUPPORTS HV15K/HW10KG	V		
				1032000403	PAN SUPPORTS HV15K/HW10KG	V		
	13		4	1031000079A	PAN SUPPORT MIDDLE		V	
		13	4	1031000076A	PAN SUPPORT LARGE			V
4	9	9	5	1063003043	DIA PHRAGM HVW-G	V	V	V
5	8	8	6	1043003044	RING A	V	V	V
6	10	10	7	1043003045	RING B	V	V	V
15			8	1071000090A	LC COVER HV	V		
	7	7	8	1071000082B	L.C. COVER		V	V
	,	,	- U	1071000082A	L.C. COVER		V	V
10			9	1062000404A	GASKET SMALL	V		
	6	6	9	1062000400A	GASKET		V	V
25			10	7LC-126-15K	LADCELL UNIT HA15KG/HW10KG	V		
	5		10	7LC-127-60K	LOAD CELL UNIT HV/HW60KG		V	
		5	10	7LC-128-100K	LOAD CELL UNIT HW100KG			V
		5	10	7LC-128-220K	LOAD CELL UNIT HV/HW200KG			V
11			11	1043003047A	LOAD ANGLE	V		
			'''	1043003047	LOAD ANGLE	V		
14			12	1154006926A	LEAF SPRING	V		
12			13	1044006924	FIXED PLATE A	V		
13			14	1044006925	FIXED PLATE B	V		
	12	12	15	1074017252	CABLE CLAMP		V	V
	12	12	13	1044007030	CABLE CLAMP		V	V
	3		16	1044006923	L.C. PLATE MIDDLE		V	
	3		10	1044007029	L.C. PLATE LARGE			
18			17	107B49929	ADJUSTABLE FOOT (S)	V		
	2	2	17	1073007273	LEVEL ADJUSTER (M/L) M10		V	V
		4	17	1073003003	LEVEL ADJUSTER HVW/G		V	V
21			18	1071000089A	BASE, SMALL	V		
	1		18	1031000078C	BASE, MIDDLE		V	
		1	18	1031000075C	BASE (L) FOR HVW-G			V
20			19	1043003049B	UNDER COVER	V		
			19	1043003049	UNDER COVER	V	'	
16			20	1044006927A	L.C. PLATE SMALL	V		
26			21	1044008092	GROUND PLATE	V		
				1031000194B	POLE BASE (M/L)			
	20	19	22	1031000194A	POLE BASE (M/L)		V	V
				1031000077A	POLE BASE (M/L)		V	V
23	22	21	23	1074007441A	LEVEL FOOT(L) 60/100/200KHVW-G		V	V
22	=			1093003959D	POLE ASSY'S FOR S-PLATFORM	V		
			24	1093003959	POLE ASSY'S FOR S-PLATFORM	V		
	23	22	24	1093003960	POLE ASSY'S FOR M/L-PLATFORM		V	V
7	11	11	25	110MR16	LEVEL VIAL FOR SK SERIES	V	V	V
	21	20		1074007073A	COVER	•		<u> </u>
*		-	26	1073004453A	UNDER COVER (PLAT-S)			





HVW-WP (Display Pod) Page4







