
SJ series(EX) SPARE PARTS PRICE LIST ANY PRICES F.O.B. JAPAN IN J. YEN


No	Ex view No.	Parts number	Description	Applied to
1 1		1044017766A	Description LC FRAME-2	Applied to
2		1044017767	LC FRAME-1	
3		1064017768C	PAD	
5		1064018418A	PS COVER	
		1071000436B	UNDER CASE	
6	6	1071000436A	UNDER CASE	
_	0	1071000430A	UPPER CASE	
7	7	1071000437A	UPPER CASE	
8		1071000437A	PAN SUPPORT	
9		1072001080A	PAN	
10		1072001081	BATTERY BOX	
30		1154017765	BATTERY SPRING (+)	
33		1154017842	BATTERY SPRING (+-)	
32		1154017771	SPRING SUPPORT	
11	11	1073008539	BATTERY COVER	
	• • • • • • • • • • • • • • • • • • • •	1073008540B	COVER GUIDE	
12	12	1073008540	COVER GUIDE	
13	13	1073008541A	LC BASE	
		1073009774	LC SUPPORT (INCOMPATIBILITY)	
14	14	1073008542B	LC SUPPORT	
15		1073008739	CAL COVER	
	-	1073008866B	PS SUPPORT	
16	16	1073008866A	PS SUPPORT	
		1074018232A	FOOT	
17	17	1074018232	FOOT	
53	4	1064018233A	FOOT RUBBER	
		1074018241A	NUT CAP M8	
54	23	1074018241	NUT CAP M8	
		1074019916	PLA NUT M8	
55	38	11703-11-FZ8	HEX NUT M8	
52		707-4018232	FOOT UNIT (ViewNo.17 / 4 / 23 / 38*2Pcs)	
19	19	1074018236A-1	KEY TOP-1	
20	20	1074018236A-2	KEY TOP-2	
21	21	1074018236A-3	KEY TOP-3	
		1074018417C	LOCK BOLT PREPARING	PREPARING
24	24	1074018417B	LOCK BOLT	
25	25	1074018480A-1	LC STOPPER-1 (SJ-1000/2000/5000)	SJ-1000/2000/5000
25	25	1074018480A-2	LC STOPPER-2 (SJ-12K)	SJ-12K
29	29	110MR14	LEVEL VIAL HL100	
43	43	1083009416	KEY SHEET (SJ-EX)	
		1083008774-15	MODEL LABEL (SJ-1000H)	SJ-1000H
44	44	1083008774-16	MODEL LABEL (SJ-2000H)	SJ-2000H
	44	1083008774-17	MODEL LABEL (SJ-5000H)	SJ-5000H
		1083008774-18	MODEL LABEL (SJ-12KH)	SJ-12KH
48		7PZ-4576	MAIN BOARD+POWER BOARD	SH/SJ
	51	7LC-164-1K	LOAD CELL (SJ-1000) 2Pcs	Aug-08
		7LC-ETTS103B-1K	LOAD CELL (SJ-1000)	SJ1000H
		1ETTS103B-1K	LOAD CELL (SJ-1000)	SJ1000H
		7LC-164-2K	LOAD CELL (SJ-2000) 2Pcs	Aug-08
51		7LC-ETTS103B-2K	LOAD CELL (SJ-2000)	SJ2000H
		1ETTS103B-2K	LOAD CELL (SJ-2000)	SJ2000H
		7LC-165-5K	LOAD CELL (SJ-5000) 2Pcs	Aug-08
		7LC-ETTS103B-5K	LOAD CELL (SJ-5000)	SJ5000H
		1ETTS103B-5K	LOAD CELL (SJ-5000)	SJ5000H
		7LC-165-10K	LOAD CELL (SJ-12K) 2Pcs	0.140141
		7LC-ETTS103B10K	LOAD CELL (SJ-12K)	SJ12KH
		1ETTS103B-10K	LOAD CELL (SJ-12K)	SJ12KH
		7LC-166-20K	LOAD CELL (SJ-20K) 2Pcs	SJ20K
		1074018234A	KEY TOP CAL	
		1084018453A	HOLE COVER 3	
	27	1084018454	HOLE COVER-2	
		1084018479A	HOLE COVER-3	
		1084018479	HOLE COVER-3	
	47	1154017769A 1084018235	HOLDER SPRING CAL KEY SHEET A	
	47	1004010233	POWER SUPPLY BOARD	INCLUDED IN 7PZ-4576
	50			UNUSED
		1043008538-2	SENSOR BOARD SUS PAN	UNUSED
<u> </u>	56		GUM WASHER	
E7	96	1064019859A		707_4576
57		1EDTA2037TR-P	LCD MASK CRIT	7PZ-4576
		1UC1909AZ5G	MASK CPU	707 4576
		1UC1909AZ4G	MASK CPU	7PZ-4576
<u> </u>		1UC1909AZ3G 7PA-SJ-JIG	MASK CPU MAINTENANCE JIG UNIT	
<u> </u>		71 A-00-010	INVALIDATION OF OUR OWNER	
Ī				

SJ series 1



SJ series 2

SJ series(EX) SPARE PARTS PRICE LIST ANY PRICES F.O.B. JAPAN IN J. YEN



3

SJ series