| No. | Prats Name | Description | Applied to |
|-----|-----------------|--------------------------------|-------------|
| 101 | 1031000330 | Upper case | |
| 103 | 1063006874A | Diaphragm | |
| 104 | 1044014386 | Diaphragm stopper | |
| 105 | 1043006871 | S/A spring | |
| 106 | 1031000335A | Pan support arm | |
| 107 | 1064014388 | Pan support receptor | |
| 108 | 1043006929 | Weighing pan | |
| | 1083007039A-1 | Model label for GX-8K | GX8K |
| | 1083007039-2 | Model label for GX-12K | GX12K |
| | 1083007039-3 | Model label for GX-20K | GX20K |
| | 1083007039-4 | Model label for GX-30K | GX30K |
| | 1083007039A-5 | Model label for GX-8K2 | GX8K2 |
| | 1083007039-6 | Model label for GX-30K | GX30K |
| 400 | 1083007039-7 | Model label for GX-10K | GX10K |
| 109 | 1083007176A-1 | Model label for GF-8K | GF8K |
| | 1083007176-2 | Model label for GF-12K | GF12K |
| | 1083007176-3 | Model label for GF-20K | GF20K |
| | 1083007176-4 | Model label for GF-30K | GF30K |
| | 1083007176A-5 | Model label for GF-8K2 | GF8K2 |
| | 1083007176-6 | Model label for GF-32K | GF32K |
| | 1083007176-7 | Model label for GF-10K | GF10K |
| 110 | 1083006930 | Key sheet (GX-K) | GX-K |
| | 1083007175 | Key sheet (GF-K) | GF-K |
| 111 | 1074009515 | Display filter | |
| 112 | 1064014385 | Key caps | |
| 113 | 7PZ-4107-SW | Switch board PZ-4111 GX-K | |
| 114 | 7PZ-4107-DISPLY | Display board PZ-4108 GX-K | |
| 202 | 705-2001090 | Roverval 8K (t=0.4) | 8K/10K |
| | 705-2000892A-1 | Roverval 30K (t=0.5) | 12K/20K/30K |
| 203 | 1044014373 | Furcrum flexure (1) 8K (0.16) | 8K/10K |
| | 1044013628 | Furcrum flexure (1) 30K (0.29) | 12K/20K/30K |
| 204 | 1044014374 | Tension flexure (1) (0.2) | |
| 206 | 1044008758A | Furcrum flexure (2) (0.1) | |
| 207 | 1044008310A-2 | Tension flexure (2) (0.18) | |

| 213 | 1054014382A | UNDER HOOK | |
|-----|-----------------|--------------------------------|-----------------------|
| | 1054014382 | UNDER HOOK | |
| 214 | 7PZ-4107-RELAY | PZ-4113 Relay Board GX-K | |
| | 7PZ-4107-RS232C | PZ-4110 RS-232C Board | |
| 216 | 1032000893B | Pan support joint | |
| 217 | 1PC4609 | Flexible print circuit | |
| | 1PC4216 | Flexible print circuit | Old parts can be used |
| 223 | 7PZ-4107-SENSE | Position sensor board PZ-4109 | |
| 301 | 1031000329A | Lower case | |
| 309 | 7PZ-4107A | Main board GX8K/8K2/10K | GX8K/8K2/10K |
| | 7PZ-4107B | Main board GX12/20/30/32K | GX12/20/30/32K |
| | 7PZ-4107C | Main board GF8K/8K2/10K | GF8K/8K2/10K |
| | 7PZ-4107D | Main board GF12/20/30/32K | GF12/20/30/32K |
| | 7PZ-4107E | Main board GX10K | GX10K |
| | 7PZ-4107F | Main board GF10K | GF10K |
| 311 | 1104007979 | Geared motor | GX-K |
| 316 | 7PZ-4107-MOTOR | Motor board PZ-4112 | GX-K |
| 320 | 1064009518 | RUBBER PLUG CAP GXK | |
| 330 | 1004010937 | Bubble sprit level | |
| 331 | 1064014389 | Leveling foot | |
| | 1084014937 | STEP SHEET GX-K(EX) | GX-K |
| 334 | 1084014936 | STEP SHEET GX-K(JP) | GX-K |
| 304 | 1084015054 | STEP SHEET GF-K(EX) | GF-K |
| | 1084015036 | STEP SHEET GF-K(JP) | GF-K |
| 336 | 1073004214 | STEP CARD PLATE | |
| 337 | 1043004279 | STEP CARD GUIDE | |
| 401 | 1EDCM1985G | Vacuum Fluorescent Display | |
| | 1UCD780058B-183 | CPU | |
| | 1UCD780058B-162 | | |
| | 1UCD780058B-149 | CPU | Old parts can be used |
| 402 | 1SKEVQ21307K | Tact switch | |
| 403 | 7MF-AMZ51 | Analog module MF+AMZ51 | |
| | 1063006974 | WATERPROOF PACKIN FOR C ASE | |
| | AX-073007197-S | CLEAR DISPLAY COVER GXK | |
| | 1073007197A | CLEAR DISPLAY COVER GXK | |
| | 7PA-GXK-JIG | MAINTENANCE JIG GXK | |







