
HT-120 SPARE PARTS Price List

No.	Parts No.	Discription
1	1071001173A	UNDER CASE
2	7PZ-6147	MAIN BOARD
50	1SKEVQPAG05R	POWER ON/OFF SWITCH
28	1EDJS24356	LCD
29	1EDBL022073A-1W	LCD BACK LIGHT
30	1073015962	LCD HOLDER(BL)
5	7PA-HT120	LOADCELL UNIT (WITH FRAME)
9	1083015965-4	KEY SHEET (EX)
	1083015965-3	KEY SHEET (JA)
3	110MR14	LEVEL VIAL
4	1084030889	SHEET (A)
6	1074022945	KEY TOP (B)
7	1074022944	KEY TOP (A)
8	1071001175	UPPER CASE
51	1044030888A	SUS PAN
10	1043015957	EARTH PLATE
26	1154030155	EARTH SPRING
11	1073015955	PAN SUPPORT
12	1073015956	CAL COVER
13	1LRBFR120507ADK	CORE
14	1PZ5413B	PC BOARD + DC JACK
15	1074023194	FOOT HOLDER (A)
18	1074023195	FOOT HOLDER (B)
16	1073011375	FOOT
17	1064023196	FOOT RUBBER
20	1074022946	CAL KEY TOP
23	1073011171	BATTERY COVER
21	1154027418	BATTERY TERMINAL(+/-)
24	1154027533	BATTERY TERMINAL(-)
25	1U44597	BATTERY TERMINAL(+)
19	1084030158B	CAL SHEET
52	1071001176A	UPPER CARRYING CASE
53	1071001174A	UNDER CARRYING CASE


HT-120 page1

HT-120 SPARE PARTS Price List



HT-120 page2

HT-120 SPARE PARTS Price List



HT-120 page3