OPERATING INSTRUCTION MANUAL

FOR

MODEL ET-7626/7626F

(TYPE NAME:MR-1)

TABLE OF CONTENTS

INTRODUCTION	Page . 1
1. NAME OF PARTS AND MAIN SPECIFICATION	. 2
2. FUNCTION 2-1 Control Lock Key 2-2 Display 2-3 Key Board Function 2-4 Setting and Replacing Roll Paper, Ribbon Cassette etc. 2-5 Drawer Opening and Locking 2-6 Setting before Operation. (1: Date and Time (2: Deduction Rate or Addition Rate (3: Commercial Message for Print 2-7 Training Mode	. 4 . 5 . 6 . 12 . 13 . 14 . 15 . 15
3. REGISTRATION 3-1 Example of Registration 3-1-1 Price preset single item -2 Department of high amount lock out -3 Price entry of PLU -4 Multiple sale and change -5 Change computation after transaction -6 Multiplication, split pricing and repeat -7 Covers key -8 PLU key -9 PLU entry key -10 Sales registration of non-programmed PLU -11 Price reduction -12 Discount rate -13 Premium rate -14 Sale on charge with [#/NS] key and	.18 .19 .19 .19 .20 .20 .21 .21 .22
error correction with [EC] key -15 Registering cash tendered with [x1000 TEND] key -16 Registering cash tendered with [x10000 TEND] key -17 Transaction with [CHKS TEND] key -18 [CARD 1][CARD 2][CARD 3][CARD 4] key -19 Registration with [SHFT 1][SHFT 2][SHFT 3] key -20 Return registration -21 Bottle returning -22 VOID -23 Received on account and paid out -24 Registering with [NTX][TX1][TX2] key -25 Registering with [TXEX] key -26 Various cases of receipt issuing -27 Validation	.23 .24 .24 .24 .25 .25 .25 .26 .26
3- 2 Previous Balance	.31 .32 .33 .37 .39 .40

4.	REPORTS43
4 -	-1 Operation for issueing a report43
4 -	-2 Example Reports46
	TROUBLESHOOTING / SYSTEM CLEARANCE48
5-	-1 Main Error Message48
5-	-2 How to Reset the System50
6.	RECOMMENDATION FOR PROPER PERFORMANCE51

•

INTRODUCTION

First of all, We thank you very much for your best choise of our new cash register.

This operating instruction manual explains the feature, operating procedure and general precaution to help you perform this cash register.

Secondly, please keep the following instruction to maintain long and proper performance of the cash register.

1. Each key shall be pressed softly.



2. Do not touch the machine with wet hands or wet rag.



3. After using, cover the machine with attached dust cover.




4. Avoid placing the machine in a direct sunlight for a long time



1. NAME OF PARTS AND MAIN SPECIFICATION

1.1 NAME OF PARTS



(ATTACHMENT)









Waterproof cover

Programming overlay sheet

Instruction manual, Programming manul

Drawer key









Dust cover

Roll paper

Key case

Control key

1-2 MAIN SPECIFICATION

- * Power source : AC117V \pm 10%, AC220V \pm 10%, AC240V \pm 10%
- * Power consumption: Operating power 45W, 50/60Hz Stand-by power 15W, 50/60Hz
- * Memory battery : 500 hours
- * Printer: Dot matrix printer 3.2 Line/second
- * Ambient temperaturer: 0° 40°C (32 104F)
- * Circuit composition: Calculation LSI Memory C-mos Ram
- * Dimension: 410 mm (W) x 481 mm (L) x 330 mm (H) (405 mm/Rear Display)
- * Receipt and journal paper: $44.5 \, \text{mm}$ (W) x $80 \, \text{mm}$ (O.D) x $12 \, \text{mm}$ (I.D)
- * Weight: 15.0kg

SICHERHEITS-HINWEIS

Die Steckdose zum Anschluß dieser Registrierkasse muss nahe dem Gerät angebracht und leicht zugänglich sein.

Vor dem Einschalten der Stromversorgung vergewissern Sie sich anhand des Leistungsschilds an der Rückseite der Abdeckung, daß dieses Gerät mit der vorhandenen Spannung kompatibel ist.

SAFETY NOTICE

The mains outlet for this cash register must be located near the unit and easily accessible.

Please check the descriptions on the rating label on the rear side of the cover before turning the power on.

AVIS SUR LA SÉCURITÉ

La prise du secteur principal pour cette caisse enregistreuse doit se trouver près du bloc et qui doit facilement accessible.

Avant de mettre de l'énergie en circuit, veuillez vérifier les descriptions de l'étiquette de caractéristiques" qui se trouvant sur le coté arrière du couvercle.


ADVERTENCIA DE SEGURIDAD

El tomacorriente de la caja registradora debe estar ubicado en un lugar de fácil desconexión cerca de la máquina.

Verificar la descripción de la etiqueta de características del dorso de la tapa, antes de conectar la energía.

2. FUNCTION

2-1 CONTROL LOCK KEY



POSITION

FUNCTION

L : The cash register is locked and can not used.

: Used to perform regular registration

X1(T) : Used to check the contents of various kinds

of daily sales.

Used to make a training mode.

V : Used to correct registration.

Z1 : Used to reset daily sales totals.

X2 : Used to check periodical term sales totals.

22 : Used to reset periodical term sales totals.

P1 : Used to program Date, Time, Name and Unit Price

of Department, PLU etc.

P2 : Used to program Main Flags.

CONTROL KEY

FUNCTION

OP : Key for operator (L and R position)

MA : Key for manager (L,R,X1,Z1 and P1 position)

OW : Key for owner (All position)

OP KEY MA KEY OW KEY








2-2 DISPLAY

1) Layout



* UPPER LINE : 5 X 7 Dot Matrix, 16 Digits Fluorescent Tube.

Displayed Name of Commodity or transaction.

* LOWER LINE : 7 Ssegment 11 Digits Fluorescent Tube.

Displayed Unit Price during Operation, and
Total Amount when transaction was completed.

* DISPLAYED CHARACTER:

NAME OF COMMODITY: Max. 16 Characters NAME OF TRANSACTION: Max. 6 Characters

2) DISPLAY OF COMMERCAIL MESSAGE AND TIME


Commercail message in max. 48 characters can be displayed. Message of 16 characters is displayed on the board in one time and illuminated from right to left.

Either commercial message or time can be displayed by depressing the [RLS] [SUB TOTAL] key.

Choice of display of either "COMMERCIAL MESSAGE" or "TIME" is depending on the programming of main flag.

2-3 KEYBOARD FUNCTION

A) KEYLAYOUT OF 60 DEPT. [ET-7626]



NUMERIC INPUT KEY Used for input of amount. quantity and code number

DEPARTMENT KEY

Used for classification of commodities and have the following preset functions.

- 1) Preset of Dept. Name. (Max. 16 characters)
 2) Preset of Unit Price. (Max. 8 digits)
- 3) Preset of High Amount Lock Out.
- 4) Preset of Single Item. Cash transaction is completed by the operation of department key, "Single Item" can be preset in spite of preset of unit prices or high amount lock out.
- 5) Preset of TAX 1 , TAX 2 , TAX 3 and TAX 4.

MENU 1	MENU 11	MENU 21	MENU 31	MENU 41	MENU 51	MENU 61	MENU 71	MENU 81	MENU 91	MENU 101	DPT 1	DPT6	RA	#	HOLD
2	12	22	32	42	52	62	72	82	92	102	DPT2	DPT7	PO	-	PRNT
3	13	23	33	43	53	63	73	83	93	103	DPT3	DPT8	RLS	+%G	SLIP
4	14	24	34	44	54	64	74	84	94	104	DPT4	DPT9	VOID	-%G	CARD 4
5	15	25	35	45	55	65	75	85	95	105	DPT5	DPT10	EC	CHKS PRNT	CARD 3
6	16	26	36	46	56	66	76	86	96	106	CLR	Q/F	CLK ID	CKPD	CARD 2
7	17	27	37	47	57	67	77	87	97	107	7	8	9	PBAL	CARD 1
8	18	28	38	48	58	68	78	88	98	108	4	5	6	NBAL	CHRG TEND
9	19	29	39	49	59	69	79	89	99	109	1	2	3	SUB TOTL	CHKS TEND
10	20	30	40	50	60	70	80	90	100	110	0	00		TOTL	CASH TEND

FUNCTION:

* [SHFT 1] [SHFT 2] [SFHT 3] : DEPARTMENT SHIFT KEY Used to select the department numbers as follows; : 1 - 60 departments [SHFT 1] : 101 - 160 departments [SHFT 2] [SHFT 3] : 201 - 260 departments * [CVRS] : COVERS NUMBER ENTRY KEY Used to enter covers number. * [PLU ENT] : PLU ENTRY KEY Used for the temporary change of a unit price which was previously programmed in [PLU]. * [Q/F] : QUANTITY/ SPLIT PRICING KEY Used to multiply quantity by a unit price. Used for multiplication in split pricing. EXAMPLE OF MULTIPLICATION BY: 1) [DEPARTMENT] key (QUANTITY |Q/F | [DEPT.]) * Programmed price * Non programmed price (QUANTITY [Q/F] PRICE [DEPT.]) 2) [PLU] key (QUANTITY [Q/F] PLU CODE NO. [PLU]) * Programmed price * Non programmed price (QUANTITY [Q/F] PRICE [PLU ENT] PLU CODE NO. [PLU]) ** IN CASE OF SPLIT PRICING ** Register quantity of split sale first, Quantity per Pack second, and price per pack third. 1) [DEPARTMENT] key * Programmed price (REGISTER QUANTITY OF SPLIT SALE (RQSS) [Q/F] QUANTITY PER PACK (QPP) [Q/F] [DEPT.]) * Non programmed price (RQSS [Q/F] QPP [Q/F] PRICE PER PACK [DEPT.]) 2) [PLU] key * Programmed price (RQSS [Q/F] QPP [Q/F] PLU CODE NO. [PLU]) * Non programmed price (RQSS [Q/F] QPP [Q/F] PRICE PER PACK [PLU ENT] PLU CODE NO. [PLU]) ** Multiplication is carried out by operating quantity (integer 4 digits, fraction 2 digits) x Unit price in 8 digits.

Its result is Max. 9 digits.

* [PLU] : PRICE LOOK UP KEY

Used to register item by entering PLU number.

* [VOID] : VOID KEY

Used to correct registered amount.

* [EC] : ERROR CORRECTION KEY

Used to correct amount which is registered just before finalization of the transaction.

* [RET] : MERCHANDISE RETURN KEY

Used to register returned merchandises.

* [#/ST] : NON-ADD / NON-SALE KEY

Used to register code number. Used to open a drawer without registration.

* [CLR] : CLEAR KEY

Used to correct a mistakenly entered amount. Used to release an error.

* [-N] : MINUS NET KEY

Used to deal with store coupon or price reduction. This key shall be used after registration of department or PLU key.

* [-1] [-2] : MINUS 1, MINUS 2 KEY

Used to register discount amount.
Used to register bottle returning etc.

* [-%G] : MINUS PERCENT KEY

Used for percent discount for sub-total, department or PLU. This key has the following function:

- 1) Discount percent rate
 It is presetable from 0.01% to 99.99% range.
- 2) Tax mode preset This is selectable to preset either before or after discounting from the amount.

* I+%GI : PLUS PERCENT KEY

Used to increase amount by specified percentage to the sub-total, department or PLU. This key has the following functions:

- 1) Preset of adding percent ranging from 0.01% to 99.99%. However, entered percent rate has a priority over the preset percent rate.
- 2) Tax mode preset
 Tax mode is presetable for the amount either before or after
 adding percent.
- * [CASH TEND] : CASH / TENDERED KEY

 Used to finalize cash sales transaction.

 used to calculate amount of change and cash received.

 used to read "X" report and to reset "Z" report.
- * [CHRG TEND] : CHARGE / TENDERED KEY

Used to finalize credit sales transaction.

* [CHKS TEND] : CHECKS / TENDERED KEY

Used to finalize sales transaction by payment in checks. Used to calculate amount received or payed by checks.

* [CARD 1] [CARD 2] [CARD 3] [CARD 4] : CARD 1 - 4 KEY

Used to finalize sales transaction by credit cards. 4 kinds of credit cards are acceptable.

* [x1000 TEND] : x1000 TENDERED KEY

Used to quick tendering EX.

- 1) In case of US\$10.00 sales, Depress this key directly.
- 2) In case of US\$300.00 sales, Depress this key after registration of (3) (0).
- * [x10000 TEND] : X10000 TENDERED KEY

Used to quick tendering. EX.

- 1) In case of US\$100.00 sales, Depress this key directly.
- 2) In case of US\$500.00 sales, Depress this key after registration of (5).
- * [SUB TOTAL] : SUB TOTAL KEY

Used to check a sub-total during transaction.
Used for percent calculation of [+%G] and [-%G] after sub-total.
Used to display time or commercial message.

* [TOTAL] : TOTAL KEY

Used to finalize transaction including tax amount.

* [RA] : RECEIVED ON ACCOUT KEY

Used to register received amount on account.

* [PO] : PAID OUT KEY

Used to register payment paid out from drawer.

* [HOLD] : HOLD KEY

Used to keep sales data temporariry in the memory for the registration of next waiting customer.

* [DEPO] : DEPOSIT KEY

Used to register deposit from customer.

* [STUB] : STUB RECEIPT KEY

Used to issue a stub receipt.

* [SLIP] : ITEM SLIP PRINT KEY

Used to issue a slip paper.

* [PRNT] : PRINT KEY

Used for printing one line validation

* [PBAL] : PREVIOUS BALANCE KEY

Used to read previous balance sales amount.

* [NBAL] : NEW BALANCE KEY

Used to read new balance sales amount after resetting of previous balance.

* [CKPD] : CHECK PAID KEY

Used for guest payment in Bar/Restaurant mode.

* [CHKS PRNT] : CHECKS PRINT KEY

Used to print out the details of previous balance of the guest (whose number has been previously programmed). Previous balance per item is printted out after entry of the guest number and this key.

* [RLS] : SINGLE ITEM AND HIGH AMOUNT LOCK OUT RELEASE KEY

Used to release single item preset price of department and PLU. And also used to release high amount lock out.

* [NTX][TX1][TX2] : NON TAXABLE SHIFT, TAX SHIFT 1, TAX SHIFT 2 KEY

When making registration, make the department, PLU, -1, -2, -3 and -4 to be non taxable (taxable 1, taxable 2) status temporarily.

* [TXEX] : TAX EXEMPT KEY

When this key is depressed, previously registered amount becomes non taxable except for taxable amount under the previous balance conditions.

* [CLK ID] : CLERK-ID KEY

By the input I.D. Number, Up to 50 clerks can be selected. Selected clerk name is printted in 8 characters and the number is printted in 6 digits.

* [(0)] - [(9)] [(00)] [(.)] : NUMERIC INPUT KEY

Used to enter any figure to operate the cash register i.e. input sales amount, indicate how many times a particular item repeats, add or subtract percentages in conjunction with % and -% keys, and to handle figures that require a decimal point.


* [(1)]-[(60)] or [(1)]-[(10)] : DEPARTMENT KEY

Used to classify which department the transaction is for.

2-4. SETTING AND REPLACEMENT OF ROLL PAPER, RIBBON CASSETTE.

2-4-1 ROLL PAPER

- 1) Remove the printer cover.
- 2) Cut the remaining roll paper and take it out. Press the [PF] key (Receipt Feed Key) / [JF] key (Journal Feed Key) and take out the paper remained in the printer.
- 3) Place a new roll paper on the specified position of the receipt paper side. Insert the paper straight into the paper inlet.
- 4) While inserting the paper end, keep pressing the [PF] Key until the paper end advances so that you can see it in front of paper outlet.
- 5) For the journal paper, repeat this process, using the [JF] Key (Journal Feed Key).
- 6) For the journal paper, keep pressing the [JF] key until the paper advances to the paper winding holder (winder). Insert the paper end into a groove of the winder and wind the paper two or three turns.
- 7) Press the [JF] / [PF] Key to check that the paper is taken up properly.
- 8) Close the printer cover.




Cut formation at the top edge of roll paper

Roll paper setting direction

2-4-2 RIBBON CASSETTE


- 1) Remove the printer cover
- 2) For the removal of the used ribbon cassette, hold the cassette pinch and lift it up vertically.
- 3) Insert an inked ribbon between the stamp and the paper guide, and place the cassette on the printer.
- 4) Give one or two turns to the ribbon pinch in the direction of arrow so that the ribbon moves smoothly and that it is not bent.
- 5) close the printer cover.



2-5 DRAWER OPENING AND LOCKING

1) OPENING

When a power failure or other emergency occurs, pull the drawer release lever located at the bottom of the cash register to open the drawer.




Rear side

Front side

2) LOCKING

When cashier leaves for a while, insert the drawer key into the drawr lock and turn to the right so that drawer is locked to avoid the theft.



2-6 SETTING BEFORE OPERATION

[NOTE]

- 1. PLEASE USE ATTACHED PROGRAMMING OVERLAY SHEET WHEN FOLLOWING IS PROGRAMMED.
- 2. PLEASE REFER PROGRAMMING MANUAL FOR PROGRAMMING OF CLERK I.D., PLU, HOUSE CHARGE MODE, ETC.
- 1) DATE AND TIME (CONTROL LOCK : P1)

STEP KEY OPERATION

DISPLAY

- 1) [CLEAR] (1) [STRT]
- 2) [SLCT]

3) [INPUT]

DATE ?

DATE

DATE

DATE 980510

TIME

TIME

1350

CSCN 1

- 4) EX. Setting Date: MAY 10, 1998
 - (9)(8)(0)(5)(1)(0)
 - * Enter 2 digits each for year, month and day in that order.
- 5) [INPUT]
- 6) Ex. Setting Time: PM 1:50

(1) (3) (5) (0)

- * 24 hour system is used. Therefore, PM1:50 must be entered as 13:50.
- * enter 2 digits each for hour and minute in that order.
- 7) [INPUT]

** CONFIRMATION OF SETTING TIME **

* Set the control lock at "R" position.

* Press the [RLS] [SUB TOTAL] Key, and Time is displayed.

	TIME	_
P	01-50-00	

2) DEDUCTION RATE OR ADDING RATE [CONTROL LOCK: P1]

A) DEDUCTION RATE (-%G)

DISPLAY

STEP 1) 2) 3) 4)	KEY OPERATION [CLEAR] (4) [STRT] [SLCT] [INPUT] Setting Reduction Rate EX. 15%	% , N ?
	(1) (5) (0) (0)	-%G R 0
5)	[INPUT]	-%G R 1500
		-2G F
B) ADDING	RATE (+%G)	00 0
2)	KEY OPERATION [CLEAR] (4) [STRT] [SLCT] [SLCT] [INPUT] Setting Adding Rate EX. 10%	7, N? +%G
•	(1) (0) (0) (0)	+%G R
5)	[INPUT]	+%G R 1000
		+ % G F
		00 0

- 3) COMMERCIAL MESSAGE FOR PRINT ON THE RECEIPT PAPER
 - * Max. 5 lines in printing.
 - * 24 single or 12 double characters or combination in 1 line.
 - * Each double size character = 2 single spaces.
 - * 2 steps of 12 characters each are required for programming.
 - A) EXAMPLE COMMERCIAL MESSAGE ON THE RECEIPT PAPER WITH "TOWA" DOUBLE SIZE

1st LINE
2nd LINE
3rd LINE
3rd LINE
4th LINE
5th LINE
1801/19UE TOWA
0Pening Sale
ALL 20% - 40% OFF
Small Gift Present
May 1 - May 31


B) PROGRAMMING OF COMMERCIAL MESSAGE ON THE RECEIPT PAPER (CONTROL LOCK: P1)

STEP	KEY OPERATION	DISPLAY
1)	[CLEAR] (1) (0) [STRT]	
2)	[SLCT]	LOGO ?
3)	[INPUT]	
4)	(5)	
5)	[INPUT]	LOGO
6)	[CPTL LTTR] [B][O][U][T][I] [Q][U][E][SPACE]	
_ 、	•	LOGO
7)	[INPUT]	0
8)	[DBLE SIZE] [T][O][W][A]	
	[DBLE SIZE] [SPACE][SPACE]	LOGO
٥.١	[waynem]	5
9)	[INPUT]	
10)	[CPTL LTTR] [O] [SMLL LTTR]	HEADER
	[P][E][N][I][N][G]	[L1]
•	(PLEASE OPERATE SAME AS ABOVE)	BOUTIQUE
:	(1) MIND OF MINTER STREET	
:		MESSAGE 1
		R 1
		A WW O W T W
		R 1
		HEADER
		L 2
		1
		Opening
		L 2

C) For the confirmation of the above programming, press;

[CLEAR] (1) (0) [STRT] [SLCT] [PRNT]

PRINTING EXAMPLE:



2-7. TRAINING MODE (NON-RECORDING)

This training mode is used to familiar with the cash register for inexperienced operator.

During operation in the TRAINING MODE, the register does not record at all. The letter of "TRAINING" is printted on the top of the receipt.

[OPERATION PROCEDURE]

- 1) HOW TO CHANGE TO "TRAINING MODE"
 - 1-1. Set the control lock to "X1(T)" position.
 - 1-2. Depress (9)(9)(9) [CHRG TEND] key.

 - 1-3. "TRAINING START" is displayed. 1-4. Set the control lock to "R" position.

RECEIPT

2) EXAMPLE

STEP KEY OPERATION

1)	(3)	[CVRS]
2)	(3)	[Q/F]
3)	(1)(5)(00)	[DEP 1]
4)	(3)	[Q/F]
5)	(3)(0)(00)	[DEP 2]
6)		[CASH TEND]

TRAI	HI	
COVERS_		3
30		015-00
White Shirt	A I	45.00
30		030-00
White Shirt	8 I	90.00
Tax		6-08
ITEM CT	6	
CASH	14	1-08


- 3) HOW TO CHANGE TO NORMAL "REGISTER MODE".
 - 3-1. Set the control lock to "X1(T)" position.
 - 3-2. Depress (9)(9)(9) [CHRG TEND] key.
 - 3-3. "TRAINING END" is displayed and the cash register is reset to the normal "REGISTER MODE".

3. REGISTRATION POSITION OF CONTROL LOCK: " R "

When the cash register is operated in wrong way, buzzer sounds for two seconds and error message is displayed. When error occured, depress "CLR" key to stop the sound and operate again correctly.

3-1. EXAMPLE OF REGISTRATION AND RECEIPT

3-1-1. SINGLE ITEM PRICE PRESET



(NOTE)

- * Entered sales price has priority to register over single item preset price.
- * "SINGLE ITEM PRICE PRESET" mode is released in the following case.
 - 1) When [RLS] key was depressed before registration of the single item preset price.
 - 2) When multiple sales items were registered before registration of the single item preset price.
 - ** Store stamp, commercial message, time, name of clerk, machine number, consecutive number, name of clerk key and date on the receipt sample will be omitted afterwards.**

3-1-2. DEPARTMENT OF HIGH AMOUNT LOCK OUT.

EX.

- 1) (2)(0)(00)[DEP 10]
- * In this case, buzzer sounds because single item sale and high amount lock out of \$10.00 is programmed.
- 2) [CLR]
- 3) [RLS] (2)(0)(00) [DEP 10]
- 4) [CASH TEND]

Gadaets 20.00 ITEM CT CASH 20.00

* If [RLS] key is depressed before registration, "HIGH AMOUNT LOCK OUT" mode is released and registration up to 8 digits number is possible.

3-1-3. PRICE ENTRY OF PLU

EX.

- 1) (1)(2)(0)(00) [PLU ENT]
- 2) (2) [PLU]
- 3) [CASH TEND]

* If price of PLU is not programmed, price can be entered with [PLU ENT] key.

Tie Pin B II TAX ITEN CT	120.00 7.20
CASH	127-20

White Shirt B I

Mans Pants B I

TOTAL 167-20

TAX

ITEM CT

Cash to

CHANCE

30.00

130.00

200.00

32.80

7.20

3-1-4. MULTIPLE SALE AND CHANGE

EX.


- 1) (3)(0)(00) [DEP 2]
- 2) (1)(3)(0)(00)[DEP 6]
- 3)
- [TOTL] 4) (2)(00)(00)[CASH TEND]
- * If cash tendered is short, error occurs. * By programming of the flag, the registration of the cash tendered is possible at any time.

3-1-5. CHANGE COMPUTATION AFTER TRANSACTION

EX.

- 1) (1)(2)(0)[DEP 3]
- 2) (2)(3)(0)[DEP 3]
- 3) [CASH TEND]
- 4) (1)(0)(00)[CASH TEND]

* In this case, transaction was finalized without cash tendered. However, By registering cash tendered, the change can be displayed. But the change is not issued on the receipt.



3-1-6. MULTIPLICATION, SPLIT PRICING AND REPEAT COMPUTATION

EX. 1) (5)[Q/F](1)(2)(00) [DEP 7] 2) (7)[Q/F](1)(0)[Q/F][DEP 1]3) (6)(00) [DEP 3] 50 012.nn 4) [DEP 3] Socks 1 60.00 5) [DEP 3] 7/ 10 020.OO 6) [CASH TEND] White Shirt A I 14.00 Handkerchief I 6-00 * Key operation of multiplication: Handkerchief I 6.00 (Quantity) x (Unit Price) Handkerchief I 6.00 * Unit price: Max. 8 digits can be registered. TAX 4.14 * Total number of registration: Max. 9 digits. ITEN CT 15 * Registration of quantity: CASH 96-14

Integer .. Max. 4 digits.
Decimal .. 2 digits.

3-1-7. COVERS KEY

EX.

1) (3) [CVRS]

2) (3)[Q/F](1)(5)(00) [DEP 1]

3) (3)[Q/F](3)(0)(00) [DEP 2]

4) [CASH TEND]

- * At the beginning of registration, enter the guest number with [CVRS] key.
- * If the guest number is not entered, it is automatically registered as the guest number is only one person.
- * This key is used for covers report and remote printer.
 (Remote printer is optional parts)

COVERS	3
3Q	015-00
White Shirt A I	45-00
3Q	030-00
White Shirt B I	90-00
TAX	6-08
ITEN CT 6	
CASH 14:	1-08

3-1-8. PLU KEY

EX.			
1)	(1)	[PLU]	
2)	(4)(9)(4)(00)(4)(0)(3)	[PLU]	
3)		[CASH	TEND]

Tie Pin A I 50.00 Belt C I 150.00 TAX 12.00 ITEN CT 2 CASH 212.00

- * Used to register the comodities as the assigned number.
- * PLU can be registered by the assigned number up to 16 digits.

(Please refer to the Programming Manual for the programming)

* It is also possible to register by using the optional Bar Code Reader.

3-1-9. PLU ENTRY KEY

* Following is example how to change preset price of \$35.00 in PLU No.10 to the temporary price of \$33.00.

EX.				
1)	(1)	[PLU]	Tie Pin	
2)	(3)(3)(00)	[PLU ENT]	Belt B II	33 - 00
3)	(1)(0)	[PLU]	[TAX	4.98
4)		[CASH TEND]	ITE1 CT	2
			CASH	87-98

3-1-10. SALES REGISTRATION OF NON-PROGRAMMED PLU

* Previously non-programmed bar code is also able to register by using the Bar Code Reader.

EX. 1) Scan Non-Programmed Bar Code	PRICE ?
2) Enter the Unit Price (1)(00) [PLU ENT]	DEPT ?
3) In case of multiple number, enter the quantity (5) [Q/F]	DEPT ?
4) Enter the Department [DEP 3]	DEPT 003 5.00
5) Enter [CASH TEND]	CASH 5.00

- * Receipt paper is normaly printted out.
- * Sales item is temporarily programmed by the above procedure. Therefore, the same procedure is not required from the next operation.
- * The temporarily programmed items shall be formally programmed after finalization of the transaction. For the details, please refer the subject of "Programming of PLU" in the attached programming manual.
- * The temporarily programmed items can be printted out by the following procedure.
 - a. set the control lock to "P1" position.
 - b. Put the programming overlay sheet on the keyboard.
 - c. Press the key as follows.

(3)[STRT][SLCT][PRNT]

* Code number of temporarily programmed items will be "FF". If it is programmed formally, change the code number to "0" or assigned number.

3-1-11. PRICE REDUCTION

EX. (A): REDUCTION WITH THE [-1] KEY

1)	(3)(5)(0)(00)	[DEP 8]
2)	(4)(3)(0)(00)	[DEP 4]
3)		[SUB TOTL]
4)	(8)(0)(00)	[-]
5)		[CASH TEND]

Mans Jacket I 350-00
Mans Suit I 430-00
SU8-TL 780-00
-1 80-00
TAX 35-10
ITEM CT 2
CASH 735-10

- * Price reduction after subtotal can be registered.
- * Price reduction for each item can be registered.
- * If [RLS] key is entered in advance, price reduction can be registered up to "High Amount Lock Out".

EX. (B): REDUCTION WITH THE [-N] KEY

1)	(2)(0)(00)	[DEP 9]
2)	(1)(00)	[-N][DEP 9]
3)		[DEP 5]
4)		[CAH TEND]

* In this case, \$19.00 is registered in DEPT. 9 and \$1.00 is registered in the [-N] key.

Weck Tie A	
Meck Tie A	I -N
	1.00
Mans Pants	A I 100-80
Tax	5.36
ITEM CT	2
CASH	124-36

3-1-12. DISCOUNT RATE

EX. (A): DISCOUNT AFTER SUB-TOTAL

1)	(1)(3)(0)(00) [DEPT 6]
2)	(4). [PLU]
3)	[SUB TOTL]
4)	[-% G]
	(Discount percent rate is programmed)
5)	[CASH TEND]

0 0 0 0
5
_
5
֡

EX. (B): DISCOUNT FOR EACH SINGLE ITEM

KEY OPERATION

1)	(2)	[PLU]
2)	(3)(5)(0)(00)	[DEP 8]
3)	(1)(0)	[-%G]
4)	(3)	[PLU]
5)		[CASH TEND]

1	Tie Pin B II	150-00
	Mans Jacket I	350.00
	10 -%H I	35.00
	Tie Tack A II	50-00
	TAX	26-19
	ITEM CT 3	
	CASH 54	1-18

- * Entered percentage rate has a priority over the programmed discount rate.
- * In this case, \$315.00 is registered in the department 8 because 10% of \$350.00 is discounted.
- * Perform the same procedure for PLU registration by pressing the [-%G] key after [PLU] key.

3-1-13. PREMIUM RATE

EX. 1) (3)(0)(00) [DEP 9]
2) [DEP 1]
3) (4) [PLU]
4) [SUB TOTL]
5) [+%G]
(10% is programmed)
6) [CASH TEND]

Neck Tie A I 30.00 White Shirt A I 20.00 Tie Tack B II 150.00 SUB-TL 200-00 10 +ZG 20-00 TAX 11-25 ITEM CT 3 CASH 231 - 25

- * Both the premium of sub-total and that of each single item can be registered.
- * Entered premium rate has a priority over the programmed premium rate.

3-1-14. SALE ON CHARGE WITH [#/NS] KEY AND ERROR CORRECTION WITH [EC] KEY

EX. 1) (1)(2)(3)(4) [#/NS]
2) (4) [PLU]
3) [EC]
4) (5) [PLU]
5) [CHRG TEND]

* Error correction for the discount rate (-%) and premium rate (+%) is also possible.

1234#
Tie Tack B II 150-00
- VOID Tie Tack B II 150-00
Cuff Botton A II 50-00
TAX 3-00
ITEN CT 1
CHARG 53-00

3-1-15. TENDERING WITH [x1000 TEND] KEY

EX. 1) (1)(2)(00) [DEP 1]
2) (6)(00) [DEP 3]
3) [TOTL]
4) (2) [x1000 TEND]
(\$20.00 is tendered)
5) [CASH TEND]

* Used for quick tendering.

White Shirt A I 12.00
Handkerchief I 6.00
TAX 0.81
ITEN CT 2
TOTAL 18-81
CASH TD 20.00
CHANGE 1-19

3-1-16. TENDERING WITH [x10000 TEND] KEY

EX. 1) (1)(5)(00) [DEP 1] 2) (8)(0)(00) [DEP 5] 3) [x10000 TEND]

(\$100.00 is tendered)

4) [CASH TEND]

* Used for quick tendering.

* If \$300.00 is tendered, press (3) [x10000 TEND] KEY.

White Shirt A I 15-00
Mans Pants A I 80-00
TAX 4-28
ITEM CT 2
TOTAL 99-28
CASH TD 100-00
CHANGE 0-72

3-1-17. TRANSACTION WITH [CHKS TEND] KEY

* Used for payment by checks, coupon etc.)

```
EX. 1) (1)(3)(0)(00) [DEP 6]

2) (1) [PLU]

3) (2) [PLU]

4) (3)(0)(00) [DEP 10]

5) [TOTL]

6) (5)(00)(00) [CHKS TEND]
```

* (Check \$500.00 is tendered for the sales)

```
Mans Pants B I
                 130.00
Tie Più A II
                  50.00
Tie Pin B II
                 150.00
Neck Tie B I
                  30.00
TAX
                  19.20
ITEN CT
TOTAL
           379.20
CHECK TD
                 500.00
CHANGE
                 120.80
```

3-1-18. [CARD 1][CARD 2][CARD 3][CARD 4] KEY

* Used for Credit Card

EX.	1)	(1)(3)(0)(00)	[DEP 6]
	2)	(3)	[PLU]
	3)	(3)(0)(00)	[DEP 10]
	4)		[TOTL]
	5)		[CARD 1]

- * Paid by Credit Card programmed in [CARD 1] key.
- * Same operation is performed for the [CARD 2][CARD 3] and [CARD 4]


Mans Pants B I	130.00
Tie Tack A II	50.00
Neck Tie B I	30.00
TAX	10.20
ITEN CT 3	
CARD1 22	0-20

3-1-19. REGISTRATION WITH [SHFT 1][SHFT 2][SHFT 3] KEY

EX.	1)	[SHFT	1]	(8)(0)(00)	[DEP	5]
	2)	[SHFT	2]	(2)(2)(00)	[DEP	7]
	3)	[SHFT	3](1)	(3)(0)(00)	[DEP	6]
	4)				[CASH	TEND]


* Department range of the shift key is as follows:

[SHFT	1]	:	1	-	60	Departments
[SHFT	2]	:	101	-	160	Departments
[SHFT	3]	:	201	-	260	Departments



3-1-20. RETURN REGISTRATION


- EX. 1) [RET] [SHFT 1] [DEP 3] [CASH TEND]
 - * Please reconfirm the department and clerk I.D. before registration.



3-1-21. BOTTLE RETURNING

* 3 bottles, \$0.50 each are returned from the item programmed in the [-2] key.

* Key operation: Quantity x Price and then press "MINUS" key.



3-1-22. VOID

A) VOID BEFORE FINALIZATION OF THE TRANSACTION

EX.	1)	[DEP 2]
	2) (2)(0)(0	0) [DEP 9]
	3) (1) [PLU]
	4) [VOID	[DEP 2]
		egistered for [DEP 2]
	is cancelled)
	5)	[CASH TEND]

* The word "- VOID -" is printted on the receipt.

White Shirt B I Neck Tie A I Tie Pin A II	50.00 20.00 50.00
- VOID - White Shirt B I TAX	50.00 3 . 90
ITEMICT 2 CASH 73	5-90

B) VOID AFTER FINALIZATION OF THE TRANSACTION

Set the control lock to the "V" position and operate the same as the previous registration.

CONTROL LOCK : VOID

* Previously registered sales amounts are cancelled completely.

* The word "-FULL VOID-" is printted on the receipt.

- FULL VI) ID -
White Shirt B 1	50.00
Heck Tie A I	20.00
Tie Pin A I	50-00
Tax	6-15
ITEM CT -3	
CASH 12	6-15

C) ALL CANCEL DURING OPERATION

EX.	1)	(1)(5)(00)	[DEP	1]
	2)	(3)(8)(0)	[DEP	3]
	3)	(6)(9)(0)	[DEP	1]
	4)		[CAN]	

* This is used to cancel all registered items during operation.

* For this function, special programming on the keyboard is required.

White Shirt A I Handkerchief I White Shirt A I *CANCEL*	15.00 3.80 6.90
--	-----------------------

3-1-23. RECEIVED ON ACCOUNT AND PAID OUT

A) RECEIVED ON ACCOUNT BY CASH

EX. 1) (1)(00)(00) [RA]

2) (2)(00)(00) [RA]

3) [CASH TEND]

RA 100.00 RA 200.00 R/A CA300-00

B) RECEIVED ON ACCOUNT BY CHECK

EX. 1) (2)(00)(00) [RA]

2) [CHKS TEND]

RA 200.00 R/A CK200-00

C) RECEIVED ON ACCOUNT BY CREDIT CARD

EX. 1) (5)(00)(00) [RA]

2) [CARD 1]

RA 500.00 R/A CARD 500.00

D) PAID OUT BY CASH

EX. 1) (5)(0)(00) [PO]

2) [CASH TEND]

P/O CA 50-00

E) PAID OUT BY CHECK

EX. 1) (5)(0)(00) [PO]

2)

[CHKS TEND]

P/O CK **50-00**

* Paid out by using [CARD 1] - [CARD 4] key is also possible.

3-1-24. REGISTRATION WITH [NTX][TX1] AND [TX2] KEY

EX. 1) [NTX](8)(00) [DEP 7]

2) [TX1](6)(0) [DEP 3]

3) [TX2] (5)(00) [PLU ENT] (8) [PLU]

4) [TOTL]

5) [x10000 TEND]

6) [CASH TEND]

Socks 8.00
Handkerchief I 0.60
Suspender B I 5.00
TAX 0.33
ITEM CT 3
TOTAL 13.93
CASH TD 100.00
CHANGE 86.07

3-1-25. REGISTRATION WITH [TXEX] White Shirt A I 20-00 EX. 1) [DEP 1] White Shirt A I 20,001 2) [DEP 1] Handkerchief I 7-00 3) [DEP 3] TAX EX 47.00 4) [TXEX] ITEM CT 5) [CASH TEND] CASH 47.00 * In this case, registered amount will be non-taxable 3-1-26. VARIOUS CASES OF ISSUING RECEIPT A) ISSUING OF DOUBLE RECEIPT (lst receipt) * RCEIPT ON-OFF SWITCH : ON White Shirt B I 70.00 EX. 1) (7)(0)(00)[DEP 2] Handkerchief I 6.00 2) (6)(00)[DEP 3] 50-00 Tie Pia A I 3) (1)[PLU] TAX 6-42 4) [CASH TEND] ITEM CT (Issued the first receipt) CASH 132.42 5) [SLIP] (Issued the second receipt) (2nd receipt) White Shirt 8 1 70.00 Handkerchief I *NOTE* 6-00 Tie Pin A I 50.00 By setting the flag, the double receipt TAX 6-42 can be issued automatically without ITEM CT depressing the [SLIP] key. CASH 132.42 B) ISSUEING A RECEIPT OR STUB ONLY, WHEN REQUIRED * RECEIPT ON-OFF SWITCH : OFF *NOTE* Operation procedure is the same as above item A). But, The first receipt is not issued because the receipt on-off siwtch is set at "OFF" position. EX. 1) (7)(0)(00)[DEP 2] 2) (6)(00)[DEP 3] 3) (1)[PLU] 4) [CASH TEND] (The first receipt is not issued) a) When SLIP is required, orb) When STUB is required, 5) [SLIP] 5) [STUB] White Shirt 8 I 70.00 Handkerchief I 6.00 CASH 132-42 Tie Pin A I 50-00 TAX 6.42 ITEM CT

132-42

CASH

C) ISSUEING BOTH A RECEIPT AND A STUB

RECEIPT ON-OFF SWITCH : ON

EX. 1) (7)(0)(00) [DEP 2]

2) (6)(00) [DEP 3]

3) (1) [PLU] 4) [CASH TEND]

(a RECEIPT is issued)

5) [STUB] (a STUB is issued)

White Shirt 8 I 70.00
Handkerchief I 6.00
Tie Pin A II 50.00
TAX 6.42
ITEM CT 3
CASH 132-42

CASH | 132-42

3-1-27. VALIDATION

EX. 1) (7)(0)(00) [DEP 2]


2) (6)(00) [DEP 3]

3) (1) [PLU] 4) [CASH TEND]

5) Insert a validation paper straight into the validation entrance and insert the paper straight downward while guiding to the right end position.

White Shirt 8 I 70-00 Handkerchief I 6-00 Tie Pin A II 50-00 TAX 6-42 ITEM CT 3 CASH 132-42

CASH



6) [PRINT]

01# 9038 A 0-00-00

132-42

* If the receipt on-off switch is set at "OFF" position, Validation paper is only issued.

NOTE

- 1) The validation paper should be inserted after finalization of the transaction.
- 2) Use our designated validation paper.

3-2. PREVIOUS BALANCE (IN CASE OF CHARGE SALES)

(In this operation, all registered sales items are belong to the charge sales.)

* Number of Programming:

Guest Number: Max. 6 digits
Guest Name: Max. 12 characters

- * Memory capacity without expansion memory board:
 - a) For total amount only : 504 guests
 - b) For both items of charge sales and total amount:
 Max. 50 charge sales each for total 45 guests

(Optional expansion memory board is available for larger capacity)

Above a) or b) is selectable by programming of the Main Flag.

- * If the amount tendered is less than the previous balance, it results an error. However, the previous balance can be carried forward by programming of the main flag.
- * EXAMPLE OF OPERATION *
 In this case, Main Flag 19, Position 1 = "1"
 - A. GUEST NO. : 201 GUEST NAME : LINDA
 - 1) (2)(0)(1) [PBAL] 2) (2)[Q/F] [DEP 3] 3) [DEP 10] 4) [NBAL]

LINDA	
2018	0.00
20	07.00
Handkerchief I	14.00
Neck Tie B I	50.00
Tax	2.88
ITEN CT 3	
TOTAL 6	5-88
NB 66	5-88

- B. ADDITIONAL CHARGE SALES ON OTHER DAY
 - 1) (2)(0)(1) [PBAL] 2) [DEP 4] 3) [DEP 3] 4) [NBAL]

LINDA
201P8 66.88
Mans Suit I 350.00
Handkerchief I 7.00
TAX 16.07
ITEN CT 2
TOTAL 373.07
NE 439.95

- C. PERIODICAL CHARGE SALES REPORT
- 1) (2)(0)(1) [CHKS PRNT]

	201LINDA	
i	39 67.00	
	Handkerchief I 21.00	
	10 050.00	
	Neck Tie 8 I 50.00	
	19 6350-00	
	Mans Suit I 350.00	
	TOTAL 439.95	

*Request payment for the guest

- * In case the previous balance is paid at the end of the month.
 - 1) (2)(0)(1) [PBAL]
 - 2) [CASH TEND]

LINDA 20178 439.95 CASH 439.95

- * In case the previous balance is carried forward.
 - 1) (2)(0)(1) [PBAL] [NBAL]

LINDA 201% 439.55 TOTAL 0.00 NB 439.95

3-3. BAR-RESTAURANT MODE AND [CLK ID], [CKPD] KEY

[NOTE: PLEASE REFER PROGRAMMING MANUAL FOR BAR-RESTAURANT MODE]

* Number of Programming.

Number of clerk I.D. : Max 6 digits each

Name of clerk I.D. : Max 8 characteres each

EX.

* MAIN FLAG 19, POSITION 1 = "0"

* CLERK I.D. NO. : 1001 CLERK I.D. NAME: HELEN * GUEST NO. : 201 GUEST NAME : LINDA

1) (1)(0)(0)(1)[CLK ID] 2) (2)(0)(1)[PBAL] 3) [DEP 1] 4) [DEP 2]

5) [NBAL]

HELEN LINDA 20198 0.00DINHERAL 50.00 DINNER 8 T 45-00 SRVCH 9.50 Tax 5.23 LTEM CT 2 TOTAL 109-73 NB: 109-73

** ADDITIONAL ORDER

1) (2)(0)(1)[PBAL] 2) [DEP 7] 3) [DEP 9] 4) [NBAL]

HELEN LINDA **201**PB 109.73 COFFEE I 2.00 ORANGE JUICE I 2.50 SRUCH 0.45 TAX 0.25 ITEM CT 2 TOTAL 5-20 MB. 114-93

** ADDING UP AND PAID OUT

1) (2)(0)(1)[CKPD] 2) [CARD 1]

HELEN LINDA 201CKPD 114.93 CARD1 114.93

3-4. TRANSACTION [HOLD] KEY

EX.

- 1)
- (1)(0) [PLU]
- 2)
- (7) [PLU]

* At this point, The guest leaves for a while.

3) [HOLD]

- Belt B I
 150.00

 Suspender A I
 10.00

 HOLDST
 160.00
- * When the [HOLD] key is depressed, the mark of "HOLD" lights on. * When the [HOLD] key is depressed, The receipt paper is once
- * When the [HOLD] key is depressed, The receipt paper is once jump-cut and registration for the next waiting customer can be operatted.

(START OF REGISTRATION FOR NEXT CUSTOMER)

- 4) (2)(0)(00) [DEP 10]
- (1)(5)(00) [DEP 1]
- 6) [CASH TEND]

* When the former customer returns, depress the [HOLD] key again.

Neck Tie B I 20.00 White Shirt A I 15.00 TAX 1.58 ITEN CT 2 CASH 36.58

- 7) [HOLD]
- 8) (2)(0)(00) [DEP 9]
- 9) [CASH TEND]

HOLDST 160.00 Heck Tie A I 20.00 TAX 10.50 ITEN CT 3 CASH 190.50

* If the [SLIP] key is depressed just after registration of [CASH TEND] key, All sales items (both before and after HOLD) can be issued on one receipt paper.

8elt B II. 150.00 Suspender' A II 10.00 Neck Tie A I 20.00 TAX 10.50 ITEM CT 3 CASH 190.50

(NOTE)

During operation of the previous balance, registration with [HOLD] key results an error.

3-5. SLIP PRINTER (GUEST CHECK PRINTER)

- A) Flag selectable function
 - * Connected with slip printer: Main Flag 2, Position 5 = "1" (If slip printer operation is required, the flag must be set at "1")
 - * Slip compulsory : Main Flag 2, Position 6 = "1"
 - * Compulsory check endorsement: Main Flag 7, Position 1 = "1"

Endorsement style No.1 = Main Flag 7, Position 5 = "0"Endorsement style No.2 = Main Flag 7, Position 5 = "1"

Back feed line number to the print start on Personal Check for Endorsement Style No. 2 =

Main Flag 26 = 01 ... 99 (Standard setting No. = 2)

* Time Print YES : Main Flag 14, Position 3 = "0" NO : Main Flag 14, Position 3 = "1"

* Date Line Print YES : Main Flag 20, Position 4 = "0" NO : Main Flag 20, Position 4 = "1"

* PBAL Line Print YES : Main Flag 20, Position 5 = "0" NO : Main Flag 20, Position 5 = "1"

* Item Line Print YES : Main Flag 20, Position 6 = "0" NO : Main Flag 20, Position 6 = "1"

- * Initial Line Number for feeding before the printing can be programmed : Main Flag 22 = 01 ... 99 (This number must be less than total number of line)
- * Total Number of Line on Slip Paper including above Initial Line Find Number:

Main Flag 23 = 01 ... 99 (This number must be larger than initial line find number)

* Buffered Guest/Non-Buffered Guest with Automatic Line Find.

Buffered Guest Mode : Main Flag 19, Position 3 = "1"

(Guest Data shall be retained in the memory)

Non-Buffered Guest Mode: Main Flag 19, Position 3 = "0" (Only NBAL and Tax/Taxable amount shall be memorized)

Automatic Line Find:

YES : Main Flag 20, Position 3 = "1"
NO : Main Flag 20, Position 3 = "0"

** VALIDATION **

Validation of ITEM, TOTAL, R/A and P/O can be executed by depressing the [PRINT] key so that print on Slip Paper.

Line Feed Number before Validation Print can be programmed : Main Flag 27 = 01 ... 99

B) OPERATION

1. Without Guest Operation

1) (1)(00)(1) [CLK ID] 2) [DEP 1] 3) [DEP 2] 4) [CASH TEND]

* depress [SLIP] key after [CASH TEND] key or insert Guest Check before depressing [CASH TEND] key.

* If total validation is required, depress [PRNT] key.

HELEN DINNER A I 50.00 DINNER B I 45.00 SRVCH 9.50 TAX 5.23 ITEM CT 2 CASH 109-73 D1# A 0-00-00

EX. SLIP PRINT

2. With Guest Operation

2-1. Non-Buffered Guest with Automatic Line Find Mode.

* This Guest Operation is executed in the following Main Flag Mode.

Bar-Restaurant Mode : Main Flag 19, position 1 = "0"
Non-Buffered Guest Mode: Main Flag 19, position 3 = "0"
Automatic Line Find : Main Flag 20, position 3 = "1"
Date Line Not Print : Main Flag 20, position 4 = "1"
Tax Automatic Calculation
at [NBAL] key : Main Flag 15, position 4 = "1"

* 1ST ORDER *

- 1) (1)(00)(1) [CLK ID] 2) (2)(0)(1) [PBAL] 3) [DEP 2] 4) [DEP 7] 5) [NBAL]
- * Depress [SLIP] key after [NBAL] key or insert Guest Check before [NBAL] key.
- * If Slip Compulsory Flag (Main Flag 2-6) is "1", Guest check must be inserted before [NBAL] key.
- * 2ND ORDER *
 - 1) (2)(0)(1) [PBAL] 2) [DEP 1]
 - * If the Item Validation of above Department 1 is required, insert Check and depress [PRNT] key.
 - 3) [DEP 9] 4) [NBAL]
 - * Slip operation is the same as that of 1st order.
 - * Clerk-ID operation is not required from 2nd order.

LINDA	N a no	0.00
20		0.00
DINNER B I	45.00	
COFFEE I	2-00	
SRUCH		4-70
TAX		2.59
ITEM CT 2		
TOTAL	54.	-29
НB	54.	

DINNER A I 50.00 01# 0014 A 0-00-00

1	HELEN			
	INDA	20		0.00
	INNER B I)FFEE I		45.00 2.00	
	Srvch Tax			4-70 2-59
[]	EN CT Tot	2 AL	54.	.79
	NB	20:		7 2
	NNER A I ANGE JUICE	Ī	50-00 2-50	
	srvch Tax			5-25 2-89
IT	EM CT Tot	γ Ή	60.	44
	ИB		114.	93

* CHECK-OUT *

- 1) (2)(0)(1) [CKPD] (Check-Paid)
- 2) [CARD 1]
- * Slip operation is the same as that of 1st order.
- * If Total Validation is required, insert Check and depress [PRNT] key.

EX. SLIP PRINT

·	
LINDA	ELEN
FINDH	201PB 0.00
DINNER B I	45-00
COFFEE 1 SRVCH	2-00 1 4 <i>-</i> 70
TAX	2.59
ITEM CT	¹ TAL 54.29
NB	54-29
DINNER A I	201 PB 54.29 50.00
ORANGE JUIC	
SRVCI	
TAX ITEM CT	2 -89 2
TO:	TAL 60-64
NB	114-93 201CKPD 114-93
*TAX	5.48
NET >	109.45 RD1 114-93
01# F	
<u> </u>	

2-2. Buffered Guest Mode

*This Guest Operation is executed in the following Main Flag Mode.

```
Bar-Restaurant Mode : Main Flag 19, position 1 = "0"
Buffered Guest Mode : Main Flag 19, position 3 = "1"
Automatic Line Find : Main Flag 20, position 3 = "1"
Date Line Not Print : Main Flag 20, position 4 = "1"
Tax Automatic Calculation
at [NBAL] key : Main Flag 15, position 4 = "1"
```

* 1ST ORDER *

- 1) (1)(00)(1) [CLK ID] 2) (2)(0)(1) [PBAL] (Table Number) 3) [DEP 2] 4) [DEP 7] 5) [NBAL]
- * 2ND ORDER *
 - 1) (2)(0)(1) [PBAL] 2) [DEP 1] 3) [DEP 9] 4) [NBAL]

Insert a New Guest Check and then

- 1) (2)(0)(1) [CHKS PRNT]
- * When [CHKS PRNT] key is depressed, all retained items and total amount per the Guest are printted on the New Guest check.
- * If the guest requires additional order at this point, it can be registered after the above guest check Print Operation.
- * When the guest requires Check-Out at this point (after finalization of additional order), the Check-Out operation is as follows;
 - 1) (2)(0)(1) [CKPD] (Check-Paid) 2) [CARD 1]
- * Depress [SLIP] key after [CARD 1] key or insert the Guest Check before registration of [CARD 1] key.

	HELE 201LIN	H IA	_
	10	045-00	
DIHHER	В I 1Q	45-00 62-00	
COFFEE	1	2-00	
DINNER	1 <u>0</u> A ⊺	950- 00 50-00	
	10	02.50	
	JUICE I SRUCH	2-50	9-95
	TAX		5-48
01#		. 114- 00-00	93

EX. SLIP PRINT

HELEH 201LINDA			
	10 ER B I 10	945-00 45-00 92-00	
COFF	EE I 10 ER A I	2-00 950-0 0 50-00	:
ORAN	10 GE JUICE I SRVCH	92.50 2.50	9-95
01#	TAX TOTAL A 0- 20 *TAX*	00-00 1 CKPD 1	5.48 - 93 14.93 5.48
01#	NET X CARD1 A 0-		09-45 - 93

3-6. RESTAURANT TICKET MODE

```
* Restaurant Ticket Mode : Main Flag 3, Position 2 = "1"

* Large Size Ticket Mode : Main Flag 21, Position 5 = "0"

* Small Size Ticket Mode : Main Flag 21, Position 5 = "1"

(TICKET ISSUEING FLAG OF DEPARTMENT AND PLU)
```

a) No-Ticket : Flag 3, Position 1 ... 0
Flag 3, Position 2 ... 0
b) Double Ticket (Food Item) : Flag 3, Position 1 ... 1
Flag 3, Position 2 ... 0
c) Single Ticket (Drink Item): Flag 3, Position 1 ... 0
Flag 3, Position 2 ... 1

^{*} This flag is available for both large and samll size ticket.

(OPERATION)

1) (1)(0)(0)(1) [CLK ID]
2) (2)(0)(1) [PBAL]
3) [DEP 1]
 (Food item double ticket)
4) [DEP 7]
 (Drink item single ticket)
5) [NBAL]

Example of Samll size ticket

RESTAURANT TOWA OPENING SALE ALL 20x - 40x OFF SMALL GIFT PRESENT MAY 1 - MAY 31 HELEN LINDA 2018 0.00 DINNER A I 50.00 COFFEE I 2.00 SRUCH 5-20 TAX 2.86 ITEM CT 2 TOTAL 60-06 NB: 60-06 Cashiera 01# A 0-00-00 10 50-000 DINNER A 7:00 PM (2) 01# 0061 0-00-00 0061 A - 1 2-000 1Q COFFEE 7:00 PM (2) 01# 0061 0-00-00 0061 A - 2 50.000 10 DINNER A 7:00 PM [2] 01# 0061 0-00-00 ******************************

Example of Large size ticket

RESTAURANT TOWA OPENING SALE ALL 20% - 40% OFF SMALL GIFT PRESENT MAY 1 - MAY 31
HELEM LINDA 201P8 0.00 DINNER A I 50.00 COFFEE I 2.00 SRVCH 5.20 TAX 2.86 ITEN CT 2 TOTAL 60.06 ME 60.06 CASHIERA 01# A 0-00-00
RESTAURANT TOWA OPENING SALE ALL 20% - 40% OFF SMALL GIFT PRESENT MAY 1 - MAY 31
10 50.000 DINNER A 6:58 PM { 2 } 01# 0059 0-00-00 DOS9 A - 1
10 50-000 DINNER A 6:58 PN (2) 01# 0059 0-00-00 0059 A - 1
RESTAURANT TOWA OPENING SALE ALL 20% - 40% OFF SMALL GIFT PRESENT MAY 1 - MAY 31
10 2.000 COFFEE 6:58 PM (2) 01# 0059 0-00-00 0059 A - 2

3-7. RESTAURANT DOUBLE RECEIPT WITH CONDIMENT KEY

- * Main Flag : 16 , Position 8 = "1" (Print Double Size Consecutive # on the receipt)
- * The condiment name is not printted when [COND #] key is depressed.
- * The condiment name is printted before the department name, if the department key is depressed.
- * The entered condiment items can be cancelled by [CLR] key, if the key is depressed before the department key.

EX. PRESET :

Condiment #1 ... "CONSOMME" Condiment #2 ... "POTAGE" Condiment #3 ... "RARE" Condiment #4 ... "MEDIUM" Condiment #6 ... "TOH"

Department 1 ... "DINNER A" Department 7 ... "COFFEE"

OPERATION:

1) (1)(00)(1) [CLK ID] 2) (2)(0)(1) [PBAL] 3) (1) [COND #] 4) (3) [COND #] 5) [DEP 1] 6) (2) [COND #] 7) (4) [COND #] 8) [DEP 1] 9) (6) [COND #] 10) [DEP 7] [DEP 7] 11) (Repeat) 12) [NBAL]

1st Receipt

2nd Receipt

		_
HE LINDA	LEN	
201	PB 0.00	1
201	CONSOMME	,
	RARE	
DINNER A I	50-00	3
721	POTAGE	
	MEDIUM	
DINNER A I	50.0	n
DIMEK H 1		J
020000 ·	TOH	_
COFFEE I	2.0	IJ
	HOT	
COFFEE I	2-0	0
SRVCH	10.4	0
TAX	5.7	7
TTEN CT	4	_
TOTAL	120-12	>
	120-1	
ИB		
01#	Cashier A 0-00-0	
		_

LIND	HELEN 9 0108 0.00
DINNER A	POTAGE
DINNER A	MEDIUM I 50-00 Hat
COFFEE I	2-00 HOT
COFFEE I SRUCH TAX I TEN CT	2.00 10.40 5.72
TOTAL NB	-
01#	A 0-00-00

^{*} The direct entered CONDIMENT key can be operated instead of the [COND #] key.

3-8. CHECK ENDORSEMENT

- Main Flag 7, * Compulsory Check Endorsement Mode: Position 1 = "1"
- * 2 kinds of Printing Style is available.

A) Style 1 : Main Flag 7, Position 5 = "0"

Programmable endorsement

message

ENDORSMENT 1 ENDORSMENT 2 ENDORSMENT 3

CHECK 57.75 01# 0002 A 0-00-00 Total check Amount

B) Style 2 : Main Flag 7, Position 5 = "1"

FF57-75**

FF: Programmable monetary kind

symbol

** : Traillor

symbol

FF57-75xx

Programmable endorsement message

ENDORSMENT 1 ENDORSHEHT 2 ENDORSMENT 3

0-00-00

Total check Amount

- * The monetary kind symbol is 124th transaction word (FF**) which can be changeable at "PGM 2"
- * Back Feed Line Number to the start position of print on the Personal Check for endorsement style 2:

Main Flag $26 = 01 \dots 99$ (Standard Setting Number = 2)

3-9. CASH DECLARATION

- * Cash declaration can be operated before the issueing of Z1 Reset Full Report (by [CASH TEND] key) and Individual Cashier Report (by [SUB TOTL] key).
- * Compulsory Cash Declaration: Main Flag 4, Position 1 = "1"

EX. OPERATION

1st : Drawer is opened by depressing [EC] key

2nd : Count coins and bills in the drawer

3rd : Enter count number as follows:

	count	#	monetary	unit	
1)	39	[X]	1	[RA]	
2)	33	[X]	10	[RA]	
3)	21	[X]	100	[RA]	
4)	15	[X]	500	[RA]	
5)	31	[X]	1000	[RA]	
6)	11	[X]	5000	[RA]	
7)	11	[X]	10000	[RA]	
8)				[CASH	TEND 1

* * * Z *** CASH DECL	
390	0.01
330	0.39 0.10
21Q	3-30 [†] 1-00
150	21.00 5.00
310	75 . 00 10.00
110	310-00 50-00
	550-00
110	100.00 1,100.00
TOTAL 2,059.69	2,059.69 -1.22 -1.22

FULL RE	PORŢ
DINNER A	340
DINNER B	1,700-00 16Q
COFFEE	720-00 220
ORANGE JUICE	44.00 12 Q
SHIFT 1	30-00 840
DEPT TTL	2,494.00 840
TXBL-1	2,494,00 2,494,00
TAX-1	43N 137.28
TOTAL GROSS	2,871.18 2,871.18
	28N
NET TL	2,751.06 21N
Cash	2,060-91 2N
CHECK	115.50 5N
CARD×	574.65 42N

SRVCH	239.90 5N
NOSALE CAID CKID CARD1	0.00 2.060.91 115.50 574.65
PB	44N 1,783.75 64N
NB CKPD CKUNPD RPRT CNT 0001	2,305.22 2,185.10 120.12
NRGT	2,871.18
DAVID	วดน
NET TL TAX NET * CAID CKID CDID	28N 2,751.06 137.28 2,619.50 2,060.91 115.50 574.65
NEAL CKPD BEGUN FINISH	2,305.22 2,185.10 21N 20N
01# 0001 A	0-00-00 04VID

3-10. VARIOUS CORRECTIONS AND RETURNS

* [CLR] KEY : Used to correct mistakenly entered value before registration of a department key.

Used to release an error.

* [EC] KEY : Used to correct amount which is registered

just before finalization of the transaction.

* [VOID] KEY : Used to cancell registered items.

* [RET] KEY : Used to register returned merchandizes.

* [-2] KEY : Used for registration of bottle returns etc.

* CONTROL LOCK [VOID] POSITION:

Used when an error registration is found after finalization of the transaction. Set the control lock to the [V] position and proceed the same operation again.

4. REPORT

4-1. OPERATION FOR ISSUING A REPORT

No	. Conte	ents		l Lock X2 Z2	Cash: Key	ier Operation
1.	Sale of Dept.	Individual	X	X	A	(1)[DEP1](2)[DEP1] [CASH TEND]
2.	Sale of Dept.	SHIFT 1	X	X	A .	[SHFT 1][DEP1]
3.	Sale of. Dept.	SHFIT 2	X	Х	A	[SHFT 2][DEP1]
4.	Sale of Dept.	SHIFT 3	X	X	Α	[SHFT 3][DEP3]
5.	Sale of Dept. Gr	Individual coups	X	X	A	[Q/F] () () [DEP1] {Group No.}
6.	Sale of Groups.	All Depts.	X	X	A	[Q/F][DEP1]
7.	Sale of	ALL DEPTS.	X	X	Α	[RLS][DEP1]
ı		ny other volum pove [DEP 1] F		epartmer	nt kej	v is useable instead of
8.	Sale of PLU	Individual	X	X	A	(1)[PLU](2)[PLU] [CASH TEND]
9.	Sale of Group 1	Individual	X	X	Α	(1)[Q/F]()() [PLU] {Group No.}
10.		Individual	X	X	A	(2)[Q/F]()()() [PLU] {Group No.}
11.	Sale of 1 PLU	All Groups	X	X	A	(1)[Q/F][PLU]
12.	Sale of 2 PLU	All Groups	X	X	Α	(2)[Q/F][PLU]
13.	Sale of	All PLUs	x x	x x	Α	[RLS][PLU]
14.	Inventor Individe	ry of ual Dept.	X		В	(1)[DEP1](2)[DEP1] [CASH TEND]
15.	Inventor SHIFT 1		X		В	[SHFT 1][DEP1]
16.	Inventor SHIFT 2		X		В	[SHFT 2][DEP1]
17.	Inventor SHIFT 3		X		В	[SHFT 3][DEP1]

No.				1 L X2	ock Z2	Cashi Key	
			•••	.		neg	Operation
18.	Inventory of Individual Dept. Grou	X P	٠			В	[Q/F] ()() [DEP1] {Group No.}
19.	Inventory of All Dept. Groups.	X				В	[Q/F][DEP1]
20.	Inventory of ALL Depts.	X	X			В	[RLS][DEP1]
21.	Inventory of Indiviual PLU	X				В	(1)[PLU](2)[PLU] [CASH TEND]
22.	Inventory of Individual GROUP 1 PL	X U				В	(1)[Q/F] () () [PLU] {Group No.}
23.	Inventory of Individual GROUP 2 PL	X U				В	(2)[Q/F/]()()()()[PLU] {Group No.}
24.	Inventory of All GROUP 1 PLUs	Х				В	(1)[Q/F][PLU]
25.	Inventory of All GROUP 2 PLUs	Х				В	(2)[Q/F][PLU]
26.	Inventory of All PLU	X	Х			В	[RLS][PLU]
27.	Report of Individual Cashier	X	X	X		A-P	[SUB TOTL]
28,	Report of all Cashiers	X	X	X	X	A-P	[RLS][SUB TOTL
29.	Report of Individual Clerk	X	X	X		A-P	()()()()()() {Clerk No.} [CLERK TD]
30.	Report of All Clerks	X	X	X	X	Λ-Ρ	[RLS][CLERK 1D]
31.	Individual Guest/ Previous Balance	X	X			A-P	()()()()()()[PBAL] {Guest No.}
32.	All Guests/ Previous Balance	Х	X			A-P	[RLS][PBAL]
33.	Full Report (Dept. & Transaction)	X	X	X	X	A-P	[CASH TEND]
34.	Hourly Net Sales	X	X	X	X	Λ-P	[CARD 1]
35.	Transaction Reports	X		X		A-P	[CHRG]
36.	Covers Report	X	X	X	х	Λ-Р	[CVRS]

No.	Contents	Control Lock X1 Z1 X2 Z2	Cashier Key Operation
37.	NRGT Report	X X X X	A-P [VOID]
38.	Cash in Drawer	X X	A-P [CHKS TEND]
39.	Total Sales of All Dept. Groups.	Х Х	A [Q/F][TOTL][DEP1]
40.	Total Sales of All Group 1 PLUs	X X	Λ (1)[Q/F][TOTL][PLU]
41.	Total Sales of All Group 2 PLUs	X X	A (2)[Q/F][TOTL][PLU]
42.	Total Inventory all Groups Depts.	X	B [Q/F][TOTL][DEP1]
43.	Total Inventory of All Group 1 PLUs	X	B (1)[Q/F][TOTL][PLU]
44.	Total Inventory of All Group 2 PLUs	X	B (2)[Q/F][TOTL][PLU]
45.	Individual Server Guest	X	A-P ()()()()()() {Guest No.} [NBAL]
46.	All Server Guest	X	A-P [RLS] [NBAL]

4-2. EXAMPLE OF FULL REPORT

* POSITION OF CONTROL LOCK : X1

1) [CASH TEND]

	<u>-</u>)	
***X 1 FULL REF		
White Shirt A	12 9 212-00	Q'ty of Dept.
White Shirt B	120 120 540-00	Amount of Dept.
Handkerchief	129 60-10	
Mans Suit	1Q	
Mans Pants A	430-00 30	
Mans Pants B	260-00 70	
Sock s	676-00 10	
Mans Jacket	8-00 30	
Neck Tie A	1,005.00 80 189.00	
DEPT020	40	
DEPT060	0-00 40	
SHIFT 1	155-00 670	Sales Q'ty of Shift l
DEPT107	3,535,10 10	Sales Amount of Shift l
SHIFT 2	22.00 10 22.00	
DEPT206	10 130-00	
SHIFT 3	130-00 1Q 130-00	
DEPT TTL	69Q	Total Q'ty of Dept.
TXBL-1 TXBL-2	3,687.10 3,325.10 55.00	
TAX-1	32N 149.66	Total Amount of Tax 1
TAX-2	2H 3-30	
+%G	1N 5-00	
TOTAL GROSS	3,845.06 4,166.80	
VOID-R	10N 275-00	
RETURN	1N 7-00 1N	
		لر [46]

ĺ	-14	1.00	
	-2N	1M 35.00	
	-%G	1N 19-50	
	-1	1N 80-00	
	-2	3N 1-50	
	HET TL	38N 3,744-06 34N	
	Cash	3,346-96	
	CHECK	2N 188-10	·
	CHARG	1N 41-80	
	CARDX	1N 167-20 2N	
	MSC-V	3-42	Void of Tax and %
	tax ex -ttl	1N 47.00 101.24	Total Amount of Tax Expulsion
	-Tax	3N 3.74	
	NOSALE	2N 0-00	
	R∕A CA	-1N -300.00 -1N	Total Amount of R/A Cash
	R/A CK	-200-00 -1N	Total Amount of R/A Check
ĺ	R/A CARD	-500-00 -1N	Total Amount of R/A Card
	P/0 CA	-50-00 -1N	Total Amount of P/O Cash
	CKID CUID ENO CK	-50-00 2,764-16 370-90	Cash in Drawer Check in Drawer
	CARD1 RPRT CNT 0002	-332-80	Total Amount of Card 1 Sales X1 Full Report Counter
	NRGT	4,166.80	Not Reset Grand Total
	DAVID	36N	Clerk Name
	NET TL TAX NET * CAID CKID CDID VOID RETURN MICHAEL	3,374-13 137-03 3,237-10 2,394-23 370-90 -332-80 275-80 7-00	
	NET TL TAX NET * CAID	369-93 15-93 354-00 369-93	

5. TROUBLESHOOTING AND SYSTEM CLEARANCE

* When error occurs, check the following causes before contacting our dealer.

5-1. MAIN ERROR MESSAGE

DISPLAY	MATN CAUSE	CHECK POINT
* KEY BOARD ERROR	Wrong Key Operation	Press [CLR] key and operate again correctly
* ENTRY OVER	Registered Numbers are more than limit	Press [CLR] key and enter the correct number
* ENTRY ERROR	During registration of Sales Price, The [.] key is depressed.	Press [CLR] key and enter the correct price
* MEMORY OVER	Programming is over than the capacity of the memory	Press [CLR] key and program a correct number or use additional memory board
* ENTER AMOUNT	Price for the Dept. or tendered amount is not entered	Press [CLR] key and enter the amount
* NOT PROGRAMED	Wrong number is entered	Press [CLR] key and enter the correct number
* NEW ROLL REQD		Replace with new roll paper and)When control lock is "R" position, press [CLR] key and operate again. OR)When control lock is inspection or reset position, press [SLIP] key and operate again
* CASHIER KEY REQD	Cashier key (A-P) is not entered.	Press [CLR] key and enter the cashier key
* NO SPLIT TENDER		Press [CLR] key and enter the enough amount
* STOP REGISTERING	Print buffer is approaching to the full capacity and requesting to stop the registration	Press [CLR] key and then enter the [CASH TEND] key
* ENTER PBAL/CKPD	[PBAL] key or [CKPD] key is not entered	Press [CLR] key and enter the [PBAL] key or [CKPD] key

DISPLAY	MAIN CAUSE	CHECK POINT
* ENTER COVERS	Operation was started without registration of Cover Number	Press [CLR] key and enter the [CVRS] key
* PRESS CLEAR KEY	When error occured, other key was pressed instead of [CLR] key	Press [CLR] key
* TURN OFF 5 SEC	When power failure occured during printing operation	Turn off the power switch for 5 seconds and after then turn the switch "ON"
* VALIDATE CHECK	Slip paper is not set for slip print	Press [CLR] key and insert a slip paper
* CANNOT VALIDATE	Issueing of slip print is operatted twice (Issueing of slip print is only once)	Press [CLR] key
* CHECK R/J PRINT	There are some clogs in the printer	Turn off the power switch. Remove the printer cover and check whether there are any clogs (paper, coin etc) in the printer and then turn on the switch. Press [CLR] key and operate again.
* CHECK SLIP	There are something wrong in the slip printer	Turn off the power switch. Check inside the printer and then turn on the switch. Press [CLR] key and operate again.
* INSERT CHECK	Slip paper is not inserted at all or correctly	Press [CLR] key and insert slip paper correctly. Press [SLIP] key or [PRNT] key
* CHECK 80	Connection with 80 digits printer is not correct	Turn off the power switch. Check the conditions of the printer and correct it. Turn on the power switch and press [CLR] key and operate again

- 5-2. HOW TO RESET THE SYSTEM (TO RELEASE A LOCKING OF THE MACHINE)
 - * When the cash register does not work correctly, check the following points first.
 - 1) Is the electric current cut off?
 - 2) Is the power cord firmly connected ?
 - 3) Is the control lock set to the "L" position? OR Was the control lock switched to another position before finalization?
 - 4) Is a cashier key entered?
 - 5) Is the cash register operated correctly?
 - If you can not find the trouble by these checks, try
 - 6) System Reset

(HOW TO RESET THE SYSTEM)

- 6-1: Set the control lock to the "P2" position
- 6-2: Turn "OFF" the power switch of the machine
- 6-3: After 5 seconds, turn "ON" the switch again

By this procedure, the machine will start to work normally.

If the machine does not work in spite of above steps, set the control lock to "L" position, turn "OFF" the power switch and contact our dealer.

6. RECOMMENDATION FOR PROPER PERFORMANCE

* For long and proper performance of this cash register, Please keep the following instructions:

A) MAINTENANCE

- 1. Do not operate the cash register with wets hands or wipe it with a wet rag etc.
- 2. Removal of dirt and stains etc.
 Turn the power off and Remove dirt and stains by using alcohol.
- 3. Never use thinner, ketone etc. to avoid damages of the plastic parts.
- 4. When the shop is closed after work, set the control lock to "L" position, remove the control key, turn off the power switch and cover the machine with attached dust protection cover.

B) REPAIR

Do not allow any person other than authorized service man to repair the machine.

C) PARTS SUPPLY (INK RIBBON CASSETTE, ROLL PAPER, SHOP STAMP ETC.)

These parts supply shall be replaced with manufacturere's authorized replacement.

Contact our dealer when placing order.

(Remark)

The contents of this manual are subject to change without prior notice.

Ps.

If there are any questions, please contact our dealer at any time during office hour. Thank You.