AD4212B Maintenance parts list

No.	Parts number	Description	Applied to
102	1PC3516	Flexible print circui	
104	1054009657	Trimming mass	
106	1044008310A-2	Tension flexture T	
	1044008310	Tension flexture T	
107 115	1044008313A	Fulcrum flexture S	
	1044008313	Fulcrum flexture S	
	705-3004382A	Roberval	122 (12)
117	7PZ-4906A	Position sensor board	102/101
	7PZ-4906B	Position sensor board	201/301
118	7PZ-4907	Relay board	
119	1044020862	Roberval stopper	100 (101
201	1044020020A	Pan 34	102/101
	1044020020	Pan 34	102/101
	1044009642A	Pan	001 (001
	1044009642	Pan 50X50	201/301
202	1054020514	Pan support	102/101
	1034009511	Pan support	201/301
203	1044020016	Dust plate	102/101
004	1044009643	Dust plate	201/301
204	1054020018	Breeze bleak ring	102/101
205	1042001261	Weighing unit upper case	
206	1034009510	Pan support arm	
207	1054009655B	Pan boss	
207	1054009655A	Pan boss	
000	1054009655	Pan boss	
208	1154020518	Shock absorber spring	
209	1054009989	Spacer	
211	7PZ-4905	Analog relay boad	B: 1 0
010	1KO3342-200	Division cable (Display)	Display - Sensor
212	1KO3298-007	Division cable (Sensor)	Display - Sensor
	1KO2755-200	Cable	Display - Sensor
213	1031000146A	Weighting unit lower case	
014	1031000146	Weighting unit lower case	
214	110MR14	Bubble spirit level Adjustable foot	
215 301	1064010620 1083009908	Key sheet(AD4212B)	
302	1074020515	Display filter	
303		Front case(Display)	
304	1072001040 7PZ-4903	Display board	
304	1083009909A-1	Model label AD4212B-102	
	1083009909A=1	Model label AD4212B=102	
305		Model label AD4212B=102	
303	1083009909-2	Model label AD4212B-301	
	1083009909-3 1083009909-4	Model label AD4212B-301 Model label AD4212B-101	
306	1043009909-4	Front panel	
306		Display case	
307	1053008143 1044016931		
300	7PZ-4902A	Main board support Main board AD4212B-102/101	
309			
310	7PZ-4902B	Main board AD4212B-201/301 Rear panel	
311	1043010339	Intetface board	
311	7PZ-4904 1044016930	Slide lock	
312	1044016930 1064009518A	AC Plug guide	
313	1064009518A	AC Plug guide AC Plug guide	
314	1044014611	L fittingu plate	
315	110KG-B2-M6X10	Knob bolt	
316	1084020861	Reference sheet	
317	1084020861 1064009966A	Rubber foot	
	1064009966	Rubber foot	
318	1KO3195	Display board cable	Display – Main
010	1042000856A	Display stand	Display Wialli
	1042000000A		
319	1042000856	Dienlay etand	
319	1042000856	Display stand	
319	7PZ-4908	Reference boad	
319		,	

AD4212B series 1





