

AILKIN

DESIGNED FOR
EVERY ADVENTURE

TAKE IT ANYWHERE



WAVEX

PORTABLE BLUETOOTH SPEAKER

USER
MANUAL

V1.0 · EN

UP TO
8W

UP TO
12W

WAVEX · BLUETOOTH SPEAKER · UP TO 8W & 12W

01 / 06

01 · WELCOME

SOUND THAT MOVES YOU.

Thank you for choosing the WAVEX portable Bluetooth speaker. Built rugged and tuned for robust bass, WAVEX comes in two outputs — **up to 8W** and **up to 12W** — both engineered to follow your day from city streets to mountain trails.

This guide covers both variants. Setup, controls and pairing are identical; only battery, dimensions and output power differ — see page 6.

02 · IN THE BOX

[SPEAKER]

WAVEX SPEAKER

× 1

[TYPE-C CABLE]

**USB TYPE-C
CHARGING CABLE**

× 1

[BOOKLET]

USER MANUAL

× 1

[CARD]






WARRANTY CARD

× 1

HEADS UP

A wall adapter is not included. Use any standard 5V USB -A source (5V / 1A or higher).

THE CONTROLS.



⏻ · HOLD 2S

Power on / off. The center button doubles as the RGB control — short-press while powered on to cycle light modes or switch the LED off.

M · SHORT

Cycle **input mode** — Bluetooth > TF Card > USB Drive.

▶ · 2× TAP

Redial last number when paired with a phone (hands-free).

GET CONNECTED.

BLUETOOTH 5.4

Range ≈ 10 m

TWS Pairing

01

CHARGE FIRST

Plug the included Type-C cable into the side port. A solid red indicator means charging; it turns off when full. **8W variant** ≈ 1 h 45 min · **12W variant** ≈ 2 h 40 min.

02

POWER ON

Hold the  center button for 2 seconds. WAVEX boots into Bluetooth mode and announces with a chime.

03

PAIR YOUR DEVICE

On your phone or laptop, open Bluetooth settings and select **"WAVEX"**.
 . Connection confirmed by a second chime.

04

PLAY

Stream from any app. Use  /  for volume,  for play / pause,  to switch input.

05

TWS · TRUE WIRELESS STEREO

Power on two WAVEX units. Double-tap  on one — they pair as a stereo L/R pair. Pair your phone to the primary only.

NO FM RADIO

WAVEX does

NOT

include FM tuner functionality. Inputs supported: Bluetooth 5.4, TF (microSD) card and USB flash drive.

GO FURTHER.

WANT THE LONGEST PLAYBACK?



Keep volume around **60%** for the best battery life — up to 5.5 hours of music on a single full charge (both variants). Higher volume and active RGB lighting will reduce runtime.

@ 60% VOLUME		5.5 h
@ 80% VOLUME		≈ 4.0 h
@ 100% + RGB		≈ 2.8 h
CHARGE · 8W		1 h 45 m
CHARGE · 12W		2 h 40 m

CARE



**WIPE
DRY CLOTH**



**NO
SUBMERGING**



**AVOID
EXTREME HEAT**



**5V USB
ONLY**

TROUBLESHOOTING

NO POWER

Charge for 15 min, then hold  for 2 s. If unresponsive, plug into a 5V / 1A source.

WON'T PAIR

"Forget" WAVEX in your phone's Bluetooth list, power-cycle the speaker, then pair again.

DISTORTION

Lower the source volume below 80% and reduce equalizer bass boost.

THE DETAILS.

FEATURE	UP TO 8W	UP TO 12W
OUTPUT POWER	Up to 8 W	Up to 12 W
BATTERY	1200 mAh	2000 mAh
CHARGE TIME	≈ 1 h 45 m	≈ 2 h 40 m
PLAYBACK @ 60%	Up to 5.5 h	Up to 5.5 h
DIMENSIONS	85×85×123 mm	85×85×173 mm
WEIGHT	≈ 360 g	≈ 526 g

SHARED SPECS

DRIVER	52 mm · 4 Ω
FREQUENCY RESPONSE	20 Hz - 20 kHz
MAX SPL	105 dB @ 1 kHz
SIGNAL-TO-NOISE	< 92 dB · THD 1%
BLUETOOTH	V5.4 · 10 m range
INPUTS	BT · TF Card · USB Drive
CHARGING PORT	USB Type-C
LIGHTING COMPLIANCE	RGB Show Light

Specifications subject to change. Playback measured at 60% volume with RGB off; results vary with content and lighting.



YOUR WORLD. YOUR SOUND. YOUR WAVEX.

AILKIN · DESIGNED FOR EVERY ADVENTURE