
# 3η Ομάδα Ασκήσεων

Βαβουλιώτης Γεώργιος ΑΜ: 03112083 6° Εξάμηνο

Γιαννόπουλος Αναστάσης Α.Μ.: 03112176 6° Εξάμηνο



# Ο κώδικας σε assembly 8085 για την πρώτη άσκηση φαίνεται παρακάτω:

CHECK INPUT: LDA 2000H ; READ INPUT FROM SWITCHES

MVI D,00H CPI 00H ; SAVE THE INPUT ;OUTPUT REGISTER CPI 00H ; ALL LEDS ARE OFF

JZ DISPLAY

;TAKE THE SAVED INPUT MOV A, E MVI B,00H ;1ST ACE'S POSITION

MVI C,00H ; COUNTER

FIND ACE: RAR ; CHECK CURRENT LSB

> INR B ; POSITION++

INR B ; POSITION++

JC LED\_ON ; IF IS 1 THE LEDS MUST BE TURNED ON

JNC FIND\_ACE ; ELSE CHECK FOR ACE

DISPLAY: MOV A, D ;A = OUTPUT REGISTER

CMA

STA 3000H ;THE OUTPUT WAS INVERSED

JMP CHECK INPUT ; REPEAT PROCESS

LED ON: MVI A,08H ; NUM OF RIGHT SHIFTS NEED TO DO

> SUB B MOV B, A

INR B ; B=08H-POS OF 1STACE+2=NUM OF RIGHT SHIFTS+1

PREPARE OUTPUT: INR C ; COUNTER++

MOV A, B ; A= NUM OF RIGHT SHIFTS + 1

CMP C ; IF SHIFTS DONE THEN JZ DISPLAY MOV A,D ;THEN GO TO OUTPUT

;ELSE PREPARE THA OUTPUT REGISTER

;CY = 1STC

; WE PUT ACE IN D TO TURN ON LEDS RAR

MOV D, A ;UPDATE D

JMP PREPARE OUTPUT ; CONTINUE PREPARING

END: END

# Ο κώδικας σε assembly 8085 για την δεύτερη άσκηση φαίνεται παρακάτω:

START: CALL KIND ; CALLING KIND PROCCESS

> ; IF INPUT < 1 THEN CY = 1 ; CHECK AGAIN CPI 01H

JC START

CPI 09H ; IF INPUT >= 9 THEN CY = 0

JNC START ; CHECK AGAIN

MVI B,01H ; FIRST TURN ON THE LS LED

MVI C,01H ; C BECOMES 1 (SMALLEST NUMBER)

PREPARE: CMP C ; IF C=A

> ; FOUND PRESSED NUMBER, SO THE ; APROPRIATE JZ EXIT

LED TO TURN ON

CALL ROTATE ;ELSE TURN ON THE NEXT MS LED INR C ;INCREASE C,
JMP PREPARE ;AND REPEAT THE PROCCESS

EXIT: MOV A, B ;OUTPUT IS READY

; INVERSE THE OUTPUT CMA

;TURN ON THE RIGHT LEDS STA 3000H JMP START ; CHECK FOR NEW INPUT

ROTATE: PUSH PSW ; SAVE A AND FLAGS IN STACK

MOV A, B

;TURN ON THE NEXT LED RLC

MOV B, A

; REGAIN A AND FLAGS POP PSW

RET

END: END

Ο κώδικας σε assembly 8085 για την τρίτη άσκηση φαίνεται παρακάτω: IN 10H ; WITHOUT MEMORY'S PROTECTION START: ;CHECK LINE 0 ;STORE ADDRES MVI A, FEH STA 2800H ;STORE ADDRESS INSTR STEP: LDA 1800H ;LOAD ADDRESS ; KEEP THE LAST 3 LSB BIT ANI 07H ANI U/h LXI D,0806H ;CODE FROM KIND: 86.THIS IS THE PRINT VALUE CPI 06H ; CHECK IF THIS IS THE PRESSED BUTTON JZ DISPLAY ; IF IT IS DISPLAY IT IN THE 7-SEGMENT FTCH PC: LDA 1800H ;LOAD ADDRESS ANI 07H ; KEEP THE LAST 3 LSB BIT LXI D,0805H CPI 05H ; PRESSED BUTTON == 101 ? JZ DISPLAY ; FOR BUTTON HDWR STEP WE DO NOTHING BECAUSE IT'S UNUSED MVI A, FDH ; CHECK LINE 1 STA 2800H BUTTON RUN: LDA 1800H ;LOAD ADDRESS ; KEEP THE LAST 3 LSB BIT ANI 07H LXI D,0804H CPI 06H ; PRESSED BUTTON == 110 ? JZ DISPLAY FTCH REG: LDA 1800H ;LOAD ADDRESS ANI 07H ; KEEP THE LAST 3 LSB BIT LXI D,0800H CPI 05H ; PRESSED BUTTON == 101 ? JZ DISPLAY FTCH ADR: LDA 1800H ;LOAD ADDRESS ANI 07H ;KEEP THE LAST 3 LSB BIT LXI D,0802H CPI 03H ; PRESSED BUTTON == 011 ? JZ DISPLAY ; CHECK LINE 3 MVI A, FBH STA 2800H BUTTON0: LDA 1800H ;LOAD ADDRESS ANI 07H ; KEEP THE LAST 3 LSB BIT LXI D,0000H CPI 06H JZ DISPLAY

;LOAD ADDRESS

; KEEP THE LAST 3 LSB BIT

ANI 07H LXI D,0803H CPI 05H JZ DISPLAY

LDA 1800H

STORE/INCR:

# DECR:

LDA 1800H ;LOAD ADDRESS

ANI 07H ; KEEP THE LAST 3 LSB BIT

LXI D,0801H CPI 03H JZ DISPLAY

MVI A, F7H ; CHECK LINE 4

STA 2800H

# BUTTON1:

LDA 1800H ;LOAD ADDRESS

ANI 07H ; KEEP THE LAST 3 LSB BIT

LXI D,0001H CPI 06H JZ DISPLAY

#### BUTTON2:

LDA 1800H ;LOAD ADDRESS

;KEEP THE LAST 3 LSB BIT ANI 07H

LXI D,0002H CPI 05H JZ DISPLAY

#### BUTTON3:

;LOAD ADDRESS LDA 1800H

ANI 07H ; KEEP THE LAST 3 LSB BIT

LXI D,0003H CPI 03H JZ DISPLAY

; CHECK LINE 5 MVI A, EFH

STA 2800H

#### BUTTON4:

;LOAD ADDRESS LDA 1800H

ANI 07H ; KEEP THE LAST 3 LSB BIT

LXI D,0004H CPI 06H JZ DISPLAY

#### BUTTON5:

LDA 1800H ;LOAD ADDRESS

ANI 07H ; KEEP THE LAST 3 LSB BIT

LXI D,0005H CPI 05H JZ DISPLAY

# BUTTON6:

LDA 1800H ;LOAD ADDRESS

ANI 07H ;KEEP THE LAST 3 LSB BIT

LXI D,0006H CPI 03H JZ DISPLAY

; CHECK LINE 6 MVI A, DFH

STA 2800H

#### BUTTON7:

LDA 1800H ;LOAD ADDRESS

ANI 07H ;KEEP THE LAST 3 LSB BIT

LXI D,0007H CPI 06H JZ DISPLAY

# BUTTON8:

LDA 1800H ;LOAD ADDRESS
ANT 07H :KEEP THE LAS'

ANI 07H ; KEEP THE LAST 3 LSB BIT

LXI D,0008H CPI 05H JZ DISPLAY

#### BUTTON9:

;LOAD ADDRESS LDA 1800H

ANI 07H ; KEEP THE LAST 3 LSB BIT

LXI D,0009H CPI 03H JZ DISPLAY

; CHECK LINE 7 MVI A, BFH

STA 2800H

#### **BUTTONA:**

;LOAD ADDRESS LDA 1800H

ANI 07H ; KEEP THE LAST 3 LSB BIT

LXI D,000AH CPI 06H JZ DISPLAY

#### BUTTONB:

;LOAD ADDRESS LDA 1800H

ANI 07H ; KEEP THE LAST 3 LSB BIT

LXI D,000BH CPI 05H JZ DISPLAY

#### BUTTONC:

LDA 1800H ;LOAD ADDRESS

ANI 07H ; KEEP THE LAST 3 LSB BIT

LXI D,000CH CPI 03H JZ DISPLAY

MVI A,7FH ; CHECK LINE 8

STA 2800H

#### BUTTOND:

LDA 1800H ;LOAD ADDRESS

; KEEP THE LAST 3 LSB BIT ANI 07H

LXI D,000DH CPI 06H JZ DISPLAY

# **BUTTONE:**

LDA 1800H ;LOAD ADDRESS

ANI 07H ; KEEP THE LAST 3 LSB BIT

LXI D,000EH CPI 05H JZ DISPLAY

#### BUTTONF:

;LOAD ADDRESS LDA 1800H

ANI 07H ; KEEP THE LAST 3 LSB BIT

LXI D,000FH CPI 03H JZ DISPLAY

JMP START ; PROGRAM NEVER STOPS

# DISPLAY:

LXI H,0A00H ; MEMORY TO SAVE THE BUTTON CODE
MVI B,10H ; TURN OFF THE 4 LS DIGITS OF 7\_SEGNMENT MOV M,B INX H MOV M, B INX H MOV M, B INX H MOV M, B INX H ; (H-L) = (D-E) = PRINT VALUEMOV M, E INX H MOV M,D LXI D,0A00H ;STARTING MEMORY POSITION FOR THE EXIT CALL STDM ;CALL THE PRINTING PROCCESSES CALL DCD JMP START ;REPEAT

END: END

# Ο κώδικας σε assembly 8085 για την τέταρτη άσκηση φαίνεται παρακάτω:

IN 10H START: MVI A, FEH ; CHECK LINE 0 STA 2800H ;STORE ADDRESS INSTR: LDA 1800H ;LOAD ADDRESS ANI 07H ;SAVE IN B THE BIN NUMBER 0000 0111 TO CHECK IF PRESSED ;BUTTON IS FOUND LXI D,8082H CPI 06H JZ DISPLAY FTCH PC: LDA 1800H ;LOAD ADDRESS ANI 07H ; SAVE IN B THE BIN NUMBER 0000 0111 TO CHECK IF PRESSED ;BUTTON IS FOUND LXI D,8092H CPI 05H JZ DISPLAY MVI A, FDH STA 2800H BUTTON RUN: LDA 1800H ;LOAD ADDRESS ANI 07H ; SAVE IN B THE BIN NUMBER 0000 0111 TO CHECK IF PRESSED ;BUTTON IS FOUND LXI D,8099H CPI 06H JZ DISPLAY FTCH REG: LDA 1800H ;LOAD ADDRESS ANI 07H ; SAVE IN B THE BIN NUMBER 0000 0111 TO CHECK IF PRESSED ;BUTTON IS FOUND LXI D,80C0H CPI 05H JZ DISPLAY FTCH ADR: LDA 1800H ;LOAD ADDRESS ANI 07H ; SAVE IN B THE BIN NUMBER 0000 0111 TO CHECK IF PRESSED ;BUTTON IS FOUND LXI D,80A4H CPI 03H JZ DISPLAY MVI A, FBH STA 2800H BUTTON0: LDA 1800H ;LOAD ADDRESS ANI 07H ;SAVE IN B THE BIN NUMBER 0000 0111 TO CHECK IF PRESSED ;BUTTON IS FOUND

LXI D, COCOH CPI 06H JZ DISPLAY

```
STORE/INCR:
     LDA 1800H
                ;LOAD ADDRESS
                  ; SAVE IN B THE BIN NUMBER 0000 0111 TO CHECK IF PRESSED
     ANI 07H
                  ;BUTTON IS FOUND
     LXI D,80B0H
      CPI 05H
      JZ DISPLAY
DECR:
      LDA 1800H
                ;LOAD ADDRESS
     ANI 07H
                  ; SAVE IN B THE BIN NUMBER 0000 0111 TO CHECK IF PRESSED
                  ;BUTTON IS FOUND
      LXI D,80F9H
      CPI 03H
      JZ DISPLAY
     MVI A, F7H
     STA 2800H
BUTTON1:
     LDA 1800H
                 ;LOAD ADDRESS
     ANI 07H
                  ;SAVE IN B THE BIN NUMBER 0000 0111 TO CHECK IF PRESSED
                  ;BUTTON IS FOUND
      LXI D, COF9H
      CPI 06H
      JZ DISPLAY
BUTTON2:
     LDA 1800H
                ;LOAD ADDRESS
      ANI 07H
                  ; SAVE IN B THE BIN NUMBER 0000 0111 TO CHECK IF PRESSED
                  ;BUTTON IS FOUND
     LXI D, COA4H
      CPI 05H
      JZ DISPLAY
BUTTON3:
     LDA 1800H
                 ;LOAD ADDRESS
      ANI 07H
                  ; SAVE IN B THE BIN NUMBER 0000 0111 TO CHECK IF PRESSED
                  ;BUTTON IS FOUND
     LXI D, COBOH
      CPI 03H
      JZ DISPLAY
     MVI A, EFH
      STA 2800H
BUTTON4:
      LDA 1800H
                 ;LOAD ADDRESS
      ANI 07H
                ; SAVE IN B THE BIN NUMBER 0000 0111 TO CHECK IF PRESSED
                  ;BUTTON IS FOUND
     LXI D, C099H
      CPI 06H
     JZ DISPLAY
BUTTON5:
     LDA 1800H
                 ;LOAD ADDRESS
                  ; SAVE IN B THE BIN NUMBER 0000 0111 TO CHECK IF PRESSED
     ANI 07H
                  ;BUTTON IS FOUND
     LXI D, C092H
```

CPI 05H JZ DISPLAY

```
BUTTON6:
     LDA 1800H
                ;LOAD ADDRESS
                  ; SAVE IN B THE BIN NUMBER 0000 0111 TO CHECK IF
     ANI 07H
                  ; PRESSED BUTTON IS FOUND
     LXI D, C082H
      CPI 03H
      JZ DISPLAY
     MVI A, DFH
     STA 2800H
BUTTON7:
     LDA 1800H
                 ; LOAD ADDRESS
     ANI 07H
                  ; SAVE IN B THE BIN NUMBER 0000 0111 TO CHECK IF PRESSED
                  ;BUTTON IS FOUND
      LXI D, COF8H
      CPI 06H
      JZ DISPLAY
BUTTON8:
     LDA 1800H
                ;LOAD ADDRESS
     ANI 07H
                  ;SAVE IN B THE BIN NUMBER 0000 0111 TO CHECK IF PRESSED
                  ;BUTTON IS FOUND
      LXI D, C080H
      CPI 05H
      JZ DISPLAY
BUTTON9:
     LDA 1800H
                ;LOAD ADDRESS
      ANI 07H
                  ; SAVE IN B THE BIN NUMBER 0000 0111 TO CHECK IF PRESSED
                  ;BUTTON IS FOUND
     LXI D, C090H
      CPI 03H
      JZ DISPLAY
     MVI A, BFH
      STA 2800H
BUTTONA:
     LDA 1800H
                 ;LOAD ADDRESS
      ANI 07H
                ; SAVE IN B THE BIN NUMBER 0000 0111 TO CHECK IF PRESSED
                  ;BUTTON IS FOUND
     LXI D, C088H
      CPI 06H
      JZ DISPLAY
BUTTONB:
                 ;LOAD ADDRESS
      LDA 1800H
                ;SAVE IN B THE BIN NUMBER 0000 0111 TO CHECK IF PRESSED
                  ;BUTTON IS FOUND
     LXI D, C083H
      CPI 05H
     JZ DISPLAY
BUTTONC:
     LDA 1800H
                ;LOAD ADDRESS
     ANI 07H
                  ; SAVE IN B THE BIN NUMBER 0000 0111 TO CHECK IF PRESSED
                  ;BUTTON IS FOUND
     LXI D, COA7H
      CPI 03H
      JZ DISPLAY
```

MVI A,7FH STA 2800H

# BUTTOND:

LDA 1800H ;LOAD ADDRESS

ANI 07H ;SAVE IN B THE BIN NUMBER 0000 0111 TO CHECK IF PRESSED

;BUTTON IS FOUND

LXI D, COA1H CPI 06H JZ DISPLAY

# **BUTTONE:**

LDA 1800H ;LOAD ADDRESS

ANI 07H ;SAVE IN B THE BIN NUMBER 0000 0111 TO CHECK IF PRESSED

;BUTTON IS FOUND

LXI D,C086H CPI 05H JZ DISPLAY

# BUTTONF:

LDA 1800H ; LOAD ADDRESS

ANI 07H ;SAVE IN B THE BIN NUMBER 0000 0111 TO CHECK IF PRESSED

;BUTTON IS FOUND

LXI D,C08EH CPI 03H JZ DISPLAY

JMP START

# DISPLAY:

MVI A,20H ;10 MSB

STA 2800H

MOV A,D

STA 3800H ;OUTPUT MVI A,10H ;20 MSB

STA 2800H

MOV A, E

STA 3800H ;OUTPUT MVI A,FFH ;SWITCH OFF

STA 3800H

JMP START

END: END

1

# Ασκηση 5

# Κώδικας 8085 για το μΥ-Σ 1:

```
LXI D,0100H; METRITIS GIA TA 256 DEDOMENA
BEGIN:
      MVI A, COH ; A = 11000000
                 ; SOD1 = 1
WAIT1:
                  ; ANAMONH MEXRI SOD2 = 1
      RIM
      ANI 80H
      JZ WAIT1
SEND:
      MVI A, 40H
                ; A = 01000000
                ; SOD1 = 0
                 ; (A) <- (H) (L)
     MOV A, M
                ; APOSTOLH DEDOMENWN 8 BIT
      OUT DATA1
WAITO:
     RIM
                  ; ANAMONH MEXRI SOD2 = 0
      ANI 80H
      JNZ WAITO
                  ; OTAN OLOKLHRWTHEI H APOSTOLH (D) <- (D) -1
      DCX D
                 ; AN O D MHDENISTEI, STAMATAEI H APOSTOLH
      JZ FINISH
                 ; ALLIWS EKKINEI H APOSTOLH NEOY DEDOMENOY
      INX H
      JMP START
FINISH:
     END
Κώδικας 8085 για το μΥ-Σ 2:
     LXI D,0100H; METRITIS GIA TA 256 DEDOMENA
BEGIN:
                 ; ANAMONH MEXRI SOD1 = 1
     RIM
     ANI 80H
      JZ START
READY:
     MVI A, COH
                ; A=11000000
     SIM
                ; SOD2 = 1
WAITO:
                 ; ANAMONH MEXRI SOD1 = 0
     RIM
     ANI 80H
      JNZ WAITO
      IN DATA 2 ; READ INPUT
     MOV M, A
                 ; (H)(L)<-(A)
      DCX D
                  ; (D) < -(D) - 1
```

JZ FINISH ; AN O D MHDENISTEI, STAMATAEI H APOSTOLH

; ALLIWS AKKOLOYTHEI LHPSH NEOY DEDOMENOY

#### FINISH:

END

INX H

JMP START

# Μέγιστη Ταχύτητα Μεταφοράς Δεδομένων:

Για τον υπολογισμό της μέγιστης ταχύτητας μεταφοράς δεδομένων απαιτείται πρώτα η μέτρηση των κύκλων CPU που απαιτούνται για την αποστολή ενός byte. Επειδή ζητείται μέγιστη ταχύτητα, υποθέτουμε ότι δεν υπάρχει καμία καθυστέρηση κατά την αποστολή δεδομένων από το ένα μΥ-Σ στο άλλο.

Έτσι υπολογίζουμε ότι για την αποστολή ενός byte απαιτούνται 49 κύκλοι CPU. Επειδή ο συγκεκριμένος μΕ 8085 λειτουργεί στα 5MHz, κάθε κύκλος διαρκεί 0,2 μsec. Επομένως για την αποστολή ενός byte απαιτούνται συνολικά 49\*0,2 = 9,8 μsec. Άρα σε 1sec πραγματοποιείται η αποστολή  $10^6/9,8 = 102040,8163265$  bytes.

Τελικά η μέγιστη ταχύτητα μεταφοράς δεδομένων είναι 102,041 Mbps.

# Ασκηση 6

Στην άσκηση αυτή θα σχεδιάσουμε ένα μΥ-Σ 8085 με την εξής χάρτη μνήμης:

0000-1FFF Hex : EPROM 2000-3FFF Hex : RAM 4000-5FFF Hex : EPROM

6000 Hex : θύρα εξόδου (Memory map I/O)
 60 Hex : θύρα εισόδου (Standard I/O)

80 Hex : θύρα εισόδου-εξόδου (Standard I/O)

Όπως είναι γνωστό, ο 8085 έχει 16-bit διευθύνσεις και 8-bit περιεχόμενα διευθύνσεων. Προκύπτει ο πίνακας:

Διευθύνσεις	A <sub>15</sub>	A <sub>14</sub>	A <sub>13</sub>	A <sub>12</sub>	A <sub>11</sub>	A <sub>10</sub>	A9	$A_8$	$\mathbf{A_7}$	$\mathbf{A_6}$	$A_5$	$\mathbf{A_4}$	$\mathbf{A}_3$	$\mathbf{A}_2$	$\mathbf{A_1}$	$\mathbf{A_0}$	bits
EPROM0																	
	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	Bin
Αρχή		0				0				0				^			
		0				0				0				0			Hex
Tálag	0	0	0	1	1	1	1	1	1	1	1	1	1	1	1	1	Bin
Τέλος		1				F				F				F			Hex
SRAM0																	110/1
	0	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0	Bin
Αρχή																	
		2				0				0				0			Hex
	0	0	1	0	1	1	1	1	1	1	1	1	1	1	1	1	Bin
Τέλος																	
		2				F				F				F			Hex
SRAM1																	
	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0	0	Bin
Αρχή		•															
		3				0				0			_	0	_		Hex
T4)	0	0	1	1	1	1	1	1	1	1	1	1	1	1	1	1	Bin
Τέλος		3				F				F				F			Hex
EPROM1		3				Г				Г				Г			HEX
LIKUWII	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	Bin
Αρχή	U	1	U	U	"	U	U	U	U	U	U	U	ľ	U	U	U	Dill
l var		4				0				0				0			Hex
	0	1	0	1	1	1	1	1	1	1	1	1	1	1	1	1	Bin
Τέλος		5				F				F				F			Hex
		3				Г				Г				Г			пех

Σχόλιο: Απ' τον παραπάνω πίνακα φαίνεται ότι για τον προσδιορισμό όλων των διευθύνσεων είτε EPROM είτε RAM, χρειάζονται ακριβώς 13 bits (από  $A_0$  -  $A_{12}$ ). Συνέπεια αυτού είναι οτι κάθε περιοχή μνήμης του χάρτη μνήμης έχει μέγεθος  $2^{13}B = 8KB$ . Η μνήμη RAM επιλέχθηκε ως μια δυάδα από SRAM 4K x 8 bits σύμφωνα με τα διαθέσιμα υλικά. Η μνήμη EPROM επιλέχθηκε με μέγεθος 16KB, αφού συγκροτείται από δύο περιοχές στον χάρτη μνήμης, την περιοχή από 0000 - 1FFFH και την περιοχή από 4000 - 5FFFH μεγέθους 8KB η κάθε μία. Περισσότερες λεπτομέρειες υπάρχουν παρακάτω. Σημειώνεται πως η RAM είναι μία συνεχής περιοχή μνήμης. Επίσης, από τον χάρτη μνήμης προκύπτει οτι υο  $A_{15}$  χρησιμεύει ως είσοδος επίτρεψης, ενώ τα bits από  $A_{12}$  -  $A_{14}$  χρειάζονται για τον μοναδικό προσδιορισμό κάθε ολοκληρωμένου κυκλώματος μνήμης. Συμπερασματικά, εξάγεται ο ακόλουθος

# Πίνακας Αποκωδικοποίησης:

A/A	A14=A	A13=B	A12=C	EPROM	SRAM0	SRAM1
0	0	0	0	1	0	0
1	0	0	1	1	0	0
2	0	1	0	0	1	0
3	0	1	1	0	0	1
4	1	0	0	1	0	0
5	1	0	1	1	0	0
6	1	1	0	0	0	0
7	1	1	1	0	0	0

Ο παραπάνω πίνακας έχει πεδίο ορισμού A, B, C και εξόδους τα enable των μνημών. Ο αποκωδικοποιητής 3 σε 8 είναι αντίστροφης λογικής, όπως και τα enable των μνημών. Γι' αυτό οι άσοι είναι μηδενικά και τα μηδενικά άσοι στη πραγματικότητα. Οι τύποι των λογικών συναρτήσεων στη μορφή αθροίσματος ελαχιστόρων είναι:


- EPROM =  $\Sigma(0,1,4,5)$
- SRAM0 =  $\Sigma(2)$
- SRAM1 =  $\Sigma(3)$

Για να αποφευχθούν όλα αυτά τα προβλήματα γίνεται μετατόπιση της δεύτερης περιοχής στα όρια μιας μνήμης των 16KB. Συγκεκριμένα γίνεται χρήση μιας 16KB μνήμης που έχει διευθύνσεις από 0000 - 3FFFH. Η πρώτη περιοχή του χάρτη μνήμης και της EPROM προφανώς αντιστοιχεί επακριβώς στην περιοχή από 0000 - 1FFFH της μνήμης. Η τρίτη περιοχή του χάρτη μνήμης από 4000 - 5FFFH αντιστοιχίζεται στην περιοχή από 2000 - 3FFFH της μνήμης. Ένα θέμα που ανακύπτει τώρα είναι πως θα διακρίνονται οι διευθύνσεις της πρώτης περιοχής του χάρτη μνήμης από την τρίτη. Παρατηρώντας τον αρχικό χάρτη μνήμης διαπιστώνεται πως οι δύο περιοχές της EPROM ως προς τα bits  $A_{11}$  -  $A_{14}$ , διαφέρουν μόνο ως προς το  $A_{14}$ . Όταν αυτό ισούται με 0 τότε λαμβάνεται η πρώτη περιοχή, ενώ όταν αυτό ισούται με 1, λαμβάνεται η δεύτερη περιοχή. Το ίδιο προκύπτει κι από τον χάρτη μνήμης της μνήμης των 16KB με την διαφορά οτι τον ρόλο του  $A_{14}$  έχει το  $A_{13}$ , γεγονός αναμενόμενο. Αναμενόμενο, γιατί μια μνήμη 16KB απαιτεί 14 bits από  $A_0$  -  $A_{13}$  για τον προσδιορισμό όλων των δυνατών διευθύνσεων. Στην σχεδίαση λοιπόν του συστήματος στο  $A_{13}$  που αφορά στην μνήμη εισέρχεται το  $A_{14}$  από τον 8085. Στον επόμενο χάρτη τα ονόματα EPROM1, EPROM2 αναφέρονται στις δύο περιοχές της EPROM του αρχικού χάρτη αντίστοιχα.

# <u> Χάρτης Μνήμης 16 KB :</u>

Διευθύνσεις	$A_{15}$	$A_{14}$	$A_{13}$	$A_{12}$	$A_{11}$	$A_{10}$	$A_{g}$	$A_8$	$A_7$	$A_6$	$A_5$	$A_4$	$A_3$	$A_2$	$A_{1}$	$A_{\theta}$	bits
EPROM0																	
	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	Bin
Αρχή																	
		0				0				0				0			Hex
	0	0	0	1	1	1	1	1	1	1	1	1	1	1	1	1	Bin
Τέλος																	
		1				F				F				$\mathbf{F}$			Hex
EPROM1																	
	0	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0	Bin
Αρχή																	
		2				0				0				0			Hex
	0	0	1	1	1	1	1	1	1	1	1	1	1	1	1	1	Bin
Τέλος		3				$\mathbf{F}$				$\mathbf{F}$				$\mathbf{F}$			Hex

Έτσι έχουμε τη σχεδίαση:




# Είσοδος – έξοδος μΥ-Σ:

Τέλος, για την είσοδο και την έξοδο του συστήματος απορρέει ο χάρτης μνήμης,

Διευθύνσεις 6000H	A <sub>15</sub>	A <sub>14</sub>	A <sub>13</sub>	A <sub>12</sub>	A <sub>11</sub>	A <sub>10</sub>	<b>A</b> <sub>9</sub>	$A_8$	$\mathbf{A}_7$	$A_6$	$A_5$	$A_4$	$A_3$	$\mathbf{A}_2$	$\mathbf{A_1}$	$A_0$
	0	1	1	0	0	0	0	0	0	0	0	0	0	0	0	0
60H																
	0	0	0	0	0	0	0	0	0	1	1	0	0	0	0	0
80H																
	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0

Τα bits χωρίζονται σε τρεις ομάδες, κάθε μια εκ των οποίων χρωματίζεται διαφορετικά. Η πράσινη ομάδα χρησιμεύει ως είσοδος επίτρεψης (όπως φαίνεται λεπτομερέστερα στο σχήμα). Η μπλε ομάδα χρειάζεται, ώστε μετά την αποκωδικοποίηση να επιλέγεται η σωστή θύρα σύμφωνα με τις τιμές των  $A_{13}$ ,  $A_{14}$ . Τέλος, η κόκκινη ομάδα καθορίζει τις τιμές στη είσοδο του αποκωδικοποιητή. Διευκρινίζεται πως το σχήμα που αφορά στην E/E, ως κύκλωμα βρίσκεται μαζί με το υπόλοιπο κύκλωμα που παρουσιάζεται παραπάνω. Η ξεχωριστή παρουσίαση έγινε για να δοθεί η προσοχή που αρμόζει σε κάθε μέρος του μΥ συστήματος και για να είναι πιο ευδιάκριτη η σχεδίαση.



# Ασκηση 7

# (a) Η υλοποίηση της μακροεντολής SWAP Q,R φαίνεται παρακάτω :

```
SWAP MACRO Q,R

MOV A,R

MOV R,Q

MOV Q,A

ENDM
```

# (β) Η υλοποίηση της μακροεντολής FILL ADDR, L, Κ φαίνεται παρακάτω :

```
FILL MACRO ADDR, L, K

LXI H, ADDR ; FIRST ELEMENT
MVI C, L ; STORE LENGTH OF MEMORY PART

LOOP:

MVI M, K ; FILL THE MEMORY PART
INX H ; NEXT CELL OF MEMORY
DCR C ; (C) = (C) -1
JNZ LOOP ; IF THE MEMORY PART IS NOT FULL

END:

ENDM
```

# (γ) Η υλοποίηση της μακροεντολής RHLL φαίνεται παρακάτω:

```
RHLL MACRO n
        PUSH B ; VAZW TON BC STIN STOIVA
PUSH H ; VAZW TON HL STIN STOIVA
MVI B,n ; (B) = n(>0)
MVI C,00H ; COOUNTER->NUM OF SHIFTS
      KEEP SHIFTING:
        MOV A, H
        RAL ;SHIFT LEFT H

JC CARRY_H_1 ;IF CY=1 THEN THE LAST BIT OF L IS 1

JNC CARRY_H_0 ;ELSE THE LAST BIT OF L IS 0
      CONTINUE:
        INR C
                                 ; COUNTER++
        MOV A, C
        JZ FINISH ; THEN FINITG
        JNZ KEEP SHIFTING ; ELSE KEEP SHIFTING
     CARRY H 1:
        MVI E,01H
                        ;E -> FLAG TO REMEMBER THE CY OF H
        MOV A, L
        RAL ;SHIFT LEFT L

JC CARRY_L_1 ;IF CY=1 THEN THE LAST BIT OF H IS 1

JNC CARRY_L_0 ;ELSE THE LAST BIT OF H 0
```

```
CARRY H 0:
 MVI E,00H
                     ;E -> FLAG TO REMEMBER THE CY OF H
  MOV A, L
  RAL ;SHIFT LEFT L

JC CARRY_L_1 ;IF CY=1 THEN THE LAST BIT OF H IS 1

JNC CARRY_L_0 ;ELSE THE LAST BIT OF H IS 0
CARRY L 1:
  MOV A, H
                      ; THE LAST BIT OF H = 1
  ORI 01H
  MOV H, A
  JMP CHECK
                    ; CHECK THE FLAG E
CARRY L 0:
  MOV A, H
                      ; DO THE LAST BIT OF H = 0
  ANI FEH
  MOV H, A
  JMP CHECK ; CHECK THE FLAG E
CHECK:
  MOV A, E
  CPI 00H ; IF FLAG = 0 THEN 

JZ NEXTO ; THE LAST BIT OF L = 0 

JNZ NEXT1 ; ELSE DO THE LAST BIT OF L = 1
NEXTO:
  MOV A, L
              ; THE LAST BIT OF L = 0
  ANI FEH
  MOV L, A
  JMP CONTINUE
NEXT1:
  MOV A, L
                 ; THE LAST BIT OF L=1
  ORI 01H
  MOV L, A
  JMP CONTINUE
FINISH:
               ;VGAZW TON HL APO TIN STOIVA ;VGAZW TON BC AP TIN STOIVA
  POP H
  POP B
  ENDM
```

*Ιδέα της υλοποίησης*: Ο παραπάνω κώδικας αξιοποιεί τα παρακάτω:

- Το κρατούμενο που προκύπτει απ' την ολίσθηση του Η είναι το τελευταίο bit του L.
- Το κρατούμενο που προκύπτει απ' την ολίσθηση του L είναι το τελευταίο bit του H.

**Σχόλιο**: Θα μπορούσαμε για εξοικονόμηση χώρου να ορίσουμε την μακροεντολή  $SET\_THE\_LAST\_BIT\_OF\ R$ , n η οποία παίρνει έναν καταχωρητή R και θέτει το τελευταίο του bit ίσο με n=00H ή 01H. H εν λόγω μακροεντολή θα είχε ως εξής:

```
SET_THE_LAST_BIT_OF MACRO R,n

MVI A,n

CPI 00H

JZ SET_0

JNZ SET_1

SET_0:

MOV A,R

ANI FEH

MOV R,E

JMP FINISH

SET_1:

MOV A,R

ORI 01H

MOV R,E

JMP FINISH

FINISH:

ENDM
```