

PIPS DecodePassThough/DPT™

plug-in for Axicon Verifiers

a/k/a AxScanCap

(“Axicon Scan Capture”)

Installation Instructions and User Manual

Manual Version 1.11C

For SOFTWARE VERSION 1.11

**PRODUCT IDENTIFICATION &
PROCESSING SYSTEMS, INC.**

10 MIDLAND AVE., STE. M-02
PORT CHESTER, NY 10573
TELEPHONE (212) 996-6000
MAIN FAX (212) 410-7477

Overview:

The PIPS DecodePassThrough/DPT™ (a/k/a AxScanCap) plug-in is designed to allow users of the Axicon PC- series of linear bar code verifiers to pass the decode data from a verification scan to a 3rd-party application program as an integral part of verification of a linear bar code symbol using the Axicon verifier.

Installation:

1. Follow the manufacturer's instructions for installing the Axicon PC verification software. It is important that you install to the default directory and path that the software recommends. If you do not use the default path, please note the location for the plug-in installation.
2. Once Axicon verifier software has been installed, connect the reader to a USB port on the PC and follow the installation procedures through the calibration process.
3. Once you have calibrated and have the verifier functioning properly close the Axicon verifier application.
4. Insert the PIPS DecodePassThrough/DPT™ CD-ROM and open the file view of the CD-ROM.
5. Copy and paste the **axscancap.avp** file to C:\Program Files (x86)\Axicon\Verifier
6. Start the Axicon verifier application.
7. Go to Options -> Set-up -> Plugin tab, and check the **axscancap.avp** plugin to activate.
8. You are ready to configure DecodePassThrough/DPT™

Configuration:

1. When using DecodePassThrough/DPT™, it is best to configure the Axicon PC verifier to use only a single scan verification operation. This is done by configuring in the main screen of the software, which is called the "Command Window" to read "**Display _ of 1 Scan**". This allows the user to scan different bar codes successively without error windows popping up.
2. To activate DecodePassThrough/DPT™, from the "Command Window" choose "Options", "Setup". Select the "Plugins" tab, than check off the plug-in named "**AxScanCap**". If it is already checked, un-check it and re-check it.
3. After checking off "**AxScanCap**", click on the "Configure" button.
4. In the configuration window that opens, you can add a prefix and/or a suffix to the data that is passed through from the verifier. For example if you want to scan a bar code and pass it through to an application (such as Excel) and want to automatically TAB to the next cell in the spreadsheet, you can add a suffix of TAB to the configuration and you will automatically TAB forward to the next cell. Many applications require the ENTER key to be pressed before the cursor/focus is moved to the next field. Here you would add the suffix of "Carriage Return".

5. The configuration option “Data Mask” is used to edit the data that is transmitted from the verifier. This is done by masking the data you want transmitted with “?” and the data you don’t want by marking with “X”. Or if the data you want left off is at the end of the symbol leaving those data elements blank. For example if you are scanning a EAN-13 bar code with 5 digit add-on (such as the one on the back of a book) and you want to transmit all 18 digits in the code but remove the space character that the Axicon verifier inserts (but is not present in the bar code encodation), you can do this by creating the mask “????????????X?????”. This will accept the first 13 digits, remove the space character in the 14th position, and then concatenate the next 5 digits of the add-on and transmit all 18 digits (but not the space) to the application. Because the Axicon verifier is a verification instrument and was not intended to be a data collection device, sometimes it presents decoded data in such a way that it may need some editing in order to pass it through to your application the way you want. This is what the masking feature is for.
6. After configuring the **AxScanCap** plug-in, click on the “Advanced” tab next to the “Plugins” tab in the “Options”, “Setup” menu. Make sure the boxes for “Show error dialog” in the options for “When barcode can not be decoded” and “When no barcode is detected” are NOT checked, and that the “Clear existing scan” boxes are checked.
7. DecodePassThrough/DPT™ is now ready to be used.

SETTING UP APPLICATION

DecodePassThrough/DPT™ needs an active application window in order to pass the data through.

1. With the Axicon verifier software open and configured close all windows except for the “Command Window”.
2. Select the option “View” and then select “Pass/Fail”; you can also press the F10 key.
3. When the “Pass/Fail” screen appears you can resize the window to about a 2” by 3” square and drag it to a corner of your computer screen so that it will not interfere with your view of your data capture application but will be visible to the user.
4. Drag the “Command Window” over and position it on top of the “Pass Fail” window. This screen can also be sized down.
5. Select the option View in the “Command Window” and then select “Save Positions”, now whenever you open the Axicon verifier these windows will automatically open in these locations and at the sizes you created, by default.
6. Open the application you want to pass the verified data through to.
7. Click again on the Axicon verifier to bring the application to the foreground and then click again on your application.
8. You are now ready to scan and pass data through and at the same time the pass/fail window of the Axicon verifier will tell you if the code is passing the requirements for bar code print quality.
9. Data will be passed to where ever the keyboard cursor is in your application.

For Assistance please contact:

PIPS, INC.
10 MIDLAND AVE., STE M-02
PORT CHESTER, NY 10573
TELEPHONE (212) 996-6000
MAIN FAX (212) 410-7477