

Verification Report

Unit Serial: 1A1903PP010754
Verified: Wed 14-Jan-2026 01:43:29(239ms) PM
Firmware Version: 6.1.16_sr4
Last Calibrated: Wed 14-Jan-2026 12:50 PM

Report Summary

Data	<F1>010123456789012810GRADE-4-A-AI-INC
Symbology	GS1 DataMatrix
Device Name	DM475-63530E-PIPS-Verif-Lab
Company	Product Identification and Processing Systems, Inc. (PIPS)
Operator	GW4

Verification Grades

Standard	Grade	Aperture	Wavelength	Lighting	Formal Grade
ISO 15415:2011	4.0 (A)	16	660	45Q	4.0/16/660/45Q
Custom	Pass				

Image



General Characteristics

Matrix Size	22x22 (Data: 20x20)
Horizontal BWG	-12%
Vertical BWG	-10%
Encoded characters	35
Total Codewords	50
Data Codewords	30
Error Correction Budget	20
Errors Corrected	0
Error Capacity Used	0
Error Correction Type	ECC 200
Image	White on black
Nominal X Dim	19.7 mil
Pixels per Module	15.29
Contrast Uniformity	75 at module(1,11)
MRD	70% (77% - 7%)

GS1 DataMatrix Quality Parameters

1. Unused Error Correction (UEC)		100.0%	4.0	A	PASS
2. Symbol Contrast (SC)	Rl/Rd (87/4)	83%	4.0	A	PASS
3a. Modulation (MOD)			4.0	A	PASS
3b. Reflectance Margin (RM)			4.0	A	PASS
4. Axial Nonuniformity (ANU)		0.3%	4.0	A	PASS
5. Grid Nonuniformity (GNU)		3.2%	4.0	A	PASS
6. Fixed Pattern Damage (FPD)			4.0	A	PASS
7. Left 'L' Side (LLS)			4.0	A	PASS
8. Bottom 'L' Side (BLS)			4.0	A	PASS
9. Left Quiet Zone (LQZ)			4.0	A	PASS
10. Bottom Quiet Zone (BQZ)			4.0	A	PASS
11. Top Quiet Zone (TQZ)			4.0	A	PASS
12. Right Quiet Zone (RQZ)			4.0	A	PASS
13.Top Transition Ratio (TTR)		0%	4.0	A	PASS
14. Right Transition Ratio (RTR)		0%	4.0	A	PASS
15. Top Clock Track (TCT)			4.0	A	PASS
16. Right Clock Track (RCT)			4.0	A	PASS
17. Average Grade (AG)		4.0	4.0	A	PASS
18. DECODE			4.0	A	PASS

Encodation Analysis

Codeword	Mode	Result
232	FNC1	<F1>
131	ASCII	01
131	ASCII	01
153	ASCII	23
175	ASCII	45
197	ASCII	67
219	ASCII	89
131	ASCII	01
158	ASCII	28
140	ASCII	10
240	ASCII	SWITCH TO EDIFACT MODE
029, 032, 068	EDIFACT	GRAD
022, 221, 045	EDIFACT	E-4-
006, 208, 073	EDIFACT	A-AI
180, 147, 131	EDIFACT	-INC
129	ASCII	ASCII PAD
209	ASCII	ASCII PAD
104	ASCII	ASCII PAD
254	ASCII	ASCII PAD
150	ASCII	ASCII PAD
045	ASCII	ASCII PAD
165, 003, 110, 126, 216, 172, 119, 104, 127, 003, 016, 117, 011, 165, 185, 024, 253, 013, 234, 125	ECC	

ASCII Values																																	
048 049 048 049 050 051 052 053 054 055 056 057 048 049 050 056 049 048 071 082 065 068 069 045 052 045 065 045 065 073 045 073 078 067																																	
Codewords																																	
232	131	131	153	175	197	219	131	158	140	240	029	032	068	022	221	045	006	208	073	180	147	131	124	129	209	104	254	150	045	165	003		
110	126	216	172	119	104	127	003	016	117	011	165	185	024	253	013	234	125																
*=Fixed by Error Correction																																	
Modulation																																	
98	98	98	98	98	97	98	97	98	97	98	97	98	97	98	97	98	97	97	97	98	98	98	98										
97	78	95	74	96	80	96	74	96	80	96	74	94	73	95	73	95	72	95	72	96	71	96	98										
97	88	82	96	97	89	82	95	81	89	95	95	75	94	95	94	79	95	97	97	97	96	71	97										
97	85	95	97	96	86	95	96	95	85	80	95	95	80	89	92	88	95	97	96	96	96	96	97										
97	84	95	87	93	92	94	80	95	95	94	96	96	93	86	95	89	94	95	78	89	89	79	96										
97	88	88	91	94	93	94	92	94	82	86	94	95	79	92	84	89	94	95	93	86	89	93	96										
97	85	94	95	96	94	94	97	83	93	86	85	93	83	93	93	82	93	84	86	92	83	79	96										
97	90	93	87	94	83	92	87	94	96	94	80	93	85	84	93	82	91	90	96	86	92	94	96										
97	91	99	97	82	94	94	94	95	95	95	94	75	92	80	92	89	93	97	93	94	86	79	95										
96	90	99	88	93	95	81	87	92	88	86	93	93	80	93	80	96	97	91	91	79	93	94	96										
96	91	90	93	83	95	95	94	82	93	93	93	93	90	94	93	85	92	91	92	93	93	73	95										
96	86	92	88	88	95	78	95	95	94	94	99	94	90	94	95	94	93	84	86	89	81	93	96										
96	90	90	91	94	96	95	82	94	84	97	89	92	86	94	79	83	95	95	94	80	92	74	95										
96	86	92	88	95	96	95	93	84	94	83	92	87	85	95	94	83	94	95	95	94	94	94	96										
96	90	91	93	81	95	85	91	94	96	94	89	93	93	96	95	84	93	80	94	81	87	80	96										
97	88	93	83	94	96	95	83	95	95	84	98	94	86	95	94	91	94	91	93	94	94	94	96										
96	93	91	93	78	96	96	95	88	84	94	83	92	86	94	82	94	98	93	91	82	94	75	96										
96	92	96	89	94	97	96	94	89	94	96	95	87	88	95	95	94	86	92	86	93	95	95	96										
96	88	92	89	94	96	84	95	99	89	95	95	82	92	83	94	94	85	92	87	93	87	81	96										
97	91	96	95	85	95	94	91	99	88	95	76	94	87	94	87	94	92	94	94	93	89	94	97										
97	92	94	94	96	96	95	93	83	94	96	95	95	83	92	82	94	88	88	92	82	93	76	97										
97	92	94	95	96	95	89	90	93	95	95	83	94	94	84	93	95	94	94	95	94	95	95	98										
97	86	92	87	88	88	93	94	89	88	89	91	87	88	92	87	86	86	86	86	86	85	80	97										
98	97	96	97	96	96	96	96	96	95	95	95	95	96	96	95	95	96	95	96	96	96	97	98										

