PPIx OOB Utility is extension script to open source IPMITOOI which allows system admin to input the PPIx OOB hex codes in human readable verbose format and decode the response to human readable format.

Release Version	Release Date	License Details
1.0	Ww48 2016	BSD 3 Clause


MD5SUM checksum

☐ 6de63c8f5bcaa0cb93c7c1e3a4726914

PPIX OOB Utility Requirements

- ☐ Linux VM or host
- ☐ IPMITOOL (open source BSD license)
- ☐ BMC Configured Purley Generation Server*

Deployment Models



Installation Steps

- Download and install "PPIx_OOB_Script.sh" to Linux VM/host where IPMITOOL is installed
- ☐ Follow the User guide to execute commands.

Supported Use cases:

Use case #	UC Title	
UC 1	Discover TXT/TpM status	
UC 3 (not 2)	Enable TXT/dTPM	
UC 4	dTPM Owner Clear only	
UC 5	dTPM clear+TPM Activation	
UC 6	dTPMClear + TXT/TPM Activation	
UC 11 (not 7)	Enable TXT/PTT	
UC 12	PTT Owner Clear only	
UC 13	PTT Clear+PTT Activation	
UC 14	PTT Clear + TXT +PTT Activation	
UC 15	Disable TXT only	
UC 16	Disable dTPM only (this will not disable TXT)	
UC 17	Disable PTT	

Execution Steps

Use cases	PPIx utility
Discover TXT/TPM status	./ppix_OOB_script discovery —H <bmc ipaddress=""> -U <username> -P <password></password></username></bmc>
Enable TXT/dTPM	./ppix_OOB_script enable-txt-dtpm —H <bmc ipaddress=""> -U <username> -P <password></password></username></bmc>
dTPM Owner Clear only	./ppix_OOB_script clear-dtpm –H <bmc ipaddress=""> -U <username> -P <password></password></username></bmc>
dTPM clear + TPM Activation	./ppix_OOB_script clear-activate-dtpm —H <bmc ipaddress=""> -U <username> -P <password></password></username></bmc>

dTPM Clear + TXT/TPM activation	./ppix_OOB_script clear-activate-dtpm-enable-txt —H <bmc ipaddress=""> -U <username> -P <password></password></username></bmc>
Enable TXT/PTT	./ppix_OOB_script enable-txt-ptt —H <bmc ipaddress=""> -U <username> -P <password></password></username></bmc>
PTT Owner Clear Only	./ppix_OOB_script clear-ptt –H <bmc ipaddress=""> -U <username> -P <password></password></username></bmc>
PTT clear + PTT activation	./ppix_OOB_script clear-activate-ptt –H <bmc ipaddress=""> -U <username> -P <password></password></username></bmc>
PTT clear + TXT+PTT activation	./ppix_OOB_script clear-activate-ptt-enable-txt —H <bmc ipaddress=""> -U <username> -P <password></password></username></bmc>
Disable TXT	./disable-txt —H <bmc ipaddress=""> -U <username> -P <password></password></username></bmc>
Disable dTPM	./disable-dtpm —H <bmc ipaddress=""> -U <username> -P <password></password></username></bmc>
Disable PTT	./disable-ptt —H <bmc ipaddress=""> -U <username> -P <password></password></username></bmc>

```
Proot@oatadolfo: ~/dcg_security-ipmi-ppix-extensions/ppix-script/src/main/script
 oot@oatadolfo:~/dcg_security-ipmi-ppix-extensions/ppix-script/src/main/script# ./ppix_OOB_script.sh
VERSION: 1.0
USAGE:
        ./ppix-script COMMAND -H <BMC IPADDRESS> -U <BMC USERNAME> -P [BMC PASSWORD]
COMMANDS:
           discovery
enable-txt-dtpm
                                         Determines the status of TXT and dTPM features.
Enables TXT and dTPM.
           disable-ptt
                                          Disables PTT
OPTIONS:
                             A valid BMC IP address. This is required Username is required
           -H BMC_IPADDRESS
-U BMC_USERNAME
-P BMC_PASSWORD
                                          Username is required

Password is optional. If not explicitly declared user will be prompted to provide it
 root@oatadolfo:~/dcg_security-ipmi-ppix-extensions/ppix-script/src/main/script#
```

For more details on the PPIx OOB implementation contact: kamalanathan.natesan@intel.com