APP Skin	1/2/3/4	1
Default	0 / 1 / 2 / 3 / 4 /····· / 255	222

Default: System parameters to restore the default value, you need to select 222, and then confirm

Function/ System Info	Range	Default Value
Version	Thred3.13	Thred3.13
Hardware	C100mV1.8	C100mV1.8
APP Name	YM01V1.56G	YM01V1.56G
Firmware	2024052501	2024052501
Update APP	Check Ver	Check Ver

DMX Operation

The system has 16CH and 36CH two channel mode for customers to choose.

1. 16CH channel mode

16CH channel mode is Single pattern mode.

Channel	Function	Value	Description
CH1	RGB Dimmer	0-255	RGB dimmer from 0% to 100%
CH2	Auto Mode Trigger	0-26	Default automatic speed
		27-127	Select the automatic speed
	Sound Active Trigger	128-255	Select the sound active sensitivity
CH3	Pattern Group	0-15	Geometric patterns(0-255)
		16-31	Geometric patterns(0-255)
		32-47	Geometric patterns(0-200)
		48-63	Geometric patterns: Dot type pattern(0-205)
		64-127	Location for the downloaded ILD programs(0-170)
	Effect Group	128-143	Animated programs(0-255)
		144-159	Animated programs(0-72)
		160-175	Animated program: abstract line effect(0-30)
		176-191	Animated program: Circles(0-16)

		192-207	Animated program: dot of line effect(0-40)
		208-255	Animated program(0-255)
CH4	Pattern Selection	0-255	5 digits is for one static pattern
	Effect Selection	0-1	Play all animated programs
		2-255	2 digits is for one animated program
CH5	Color Selection	0-0	Built-in color 1, static patterns are white
		1-3	Built-in color 2
		4-7	White
		8-11	Red
		12-15	Yellow
		16-19	Green
		20-23	Cyan
		24-27	Blue
		28-31	Pink
		32-35	Seven color change effect
		36-39	RGB three color change effect
		40-43	Built-in color change effect
		44-239	Multi-color flow effect, 4 digits is for one color
		240-255	Color drawing effect
CH6	Color Speed	0-3	Color speed closed
		4-127	Color speed is from slow to fast, in the positive direction
		128-255	Color speed is from slow to fast, in the opposite direction
CH7	Line Scanning Speed	0-63	Adjust line scanning speed (effect 1)
		64-127	Adjust line scanning speed (effect 2)
	Dot Scanning Speed	128-255	Adjust dot scanning speed
CH8	Pattern Size XY	0-255	Adjust XY size
		0-0	Default, no rotation

CH9	Z Rotation	1-127	Rotation Z angle Selection
		128-191	Clockwise rotation Z speed selection
		192-255	Counterclockwise rotation Z speed selection
CH10	X rolling-over	0-0	Default, no rolling-over
		1-127	Horizontal rolling-over angle selection
		128-191	Clockwise horizontal rolling-over speed selection
		192-255	Counterclockwise horizontal rolling-over speed selection
CH11	Y rolling-over	0-0	Default, no rolling-over
		1-127	Vertical rolling-over angle selection
		128-191	Clockwise vertical rolling-over speed selection
		192-255	Counterclockwise vertical rolling-over speed selection
CH12	X Move	0-0	Default, no moving
		1-127	Horizontal position selection
		128-159	Move 1 from left to right automatically
		160-191	Move 2 from right to left automatically
		192-223	Move 3 from right to left automatically
		224-255	Move 4 from right and left circularly
CH13	Y Move	0-0	Default, no moving
		1-127	Vertical position selection
		128-159	Move 1 from up to down automatically
		160-191	Move 2 from down to up automatically
		192-223	Move 3 from up to down automatically
		224-255	Move 4 from up and down circularly
CH14	Zoom	0-0	Default, no zoom
		1-127	Pattern size selection
		128-159	Zoom -
		160-191	Zoom +

		192-223	Zoom (+/-) circularly
		224-255	Zoom (+/-) circularly
CH15	Drawing	0-0	Default, no drawing
		1-127	Drawing 1 speed selection, 0~100%
		128-255	Drawing 2 speed selection, 0~100%~0
CH16	X Wave	0-15	X small Wave 1 speed selection
		16-31	X medium Wave 1 speed selection
		32-47	X big Wave 1 speed selection
		48-63	X biggest Wave 1 speed selection
		64-79	X small Wave 2 speed selection
		80-95	X medium Wave 2 speed selection
		96-111	X big Wave 2 speed selection
		112-127	X biggest Wave 2 speed selection
	Y Wave	128-143	Y small Wave 1 speed selection
		144-159	Y medium Wave 1 speed selection
		160-175	Y big Wave 1 speed selection
		176-191	Y biggest Wave 1 speed selection
		192-207	Y small Wave 2 speed selection
		208-223	Y medium Wave 2 speed selection
		224-239	Y big Wave 2 speed selection
		240-255	Y biggest Wave 2 speed selection

2. 36CH channel mode

36CH channel mode is double patterns mode.

Channel 3 to 19 is for pattern 1 controls; channel 20 to 36 is for pattern 2 controls. In 36CH DMX mode, when CH21 value is 0, then pattern 2 is hidden, only pattern 1 appears.

Channel		Function	Value	Description
CH1		RGB Dimmer	0-255	RGB dimmer from 0% to 100%
CH2		Auto Mode Trigger	0-26	Default automatic speed
			27-127	Select the automatic speed
		Sound Active Trigger	128-255	Select the sound active sensitivity
CH3	CH20	Pattern Group	0-15	Geometric patterns(0-255)
			16-31	Geometric patterns(0-255)
			32-47	Geometric patterns(0-200)
			48-63	Geometric patterns: Dot type pattern(0-205)
			64-127	Location for the downloaded ILD programs(0-170)
		Effect Group	128-143	Animated programs(0-255)
			144-159	Animated programs(0-72)
			160-175	Animated program: abstract line pattern programs(0-30)
			176-191	Animated program: Circles(0-16)
			192-207	Animated program: dot of line effect(0-40)
			208-255	Animated program(0-255)
CH4	CH21	Pattern Selection	0-255	5 digits is for one static pattern, when CH21 is 0, then pattern 2 is hidden. Hidden pattern 1 when CH21 is not 0 and CH4 is 0.
		Effect Selection	0-1	Play all animated programs
			2-255	2 digits is for one animated program
CH5	CH22	Pattern Size	0-255	Adjust size
CH6	CH23	X Position	0-255	Adjust X position, 128 in the center

CH7	CH24	Y Position	0-255	Adjust Y position, 128 in the center
CH8	CH25	Color Selection	0-0	Built-in color 1, static patterns are white
			1-3	Built-in color 2
			4-7	White
			8-11	Red
			12-15	Yellow
			16-19	Green
			20-23	Cyan
			24-27	Blue
			28-31	Pink
			32-35	Seven color change effect
			36-39	RGB three color change effect
			40-43	Built-in color change effect
			44-239	Multi-color flow effect, 4 digits is for one color
			240-255	Color drawing effect
CH9	CH26	Color Speed	0-3	Color speed closed
			4-127	Color speed is from slow to fast, in the positive directio
			128-255	Color speed is from slow to fast, in the opposite directi
CH10	CH27	Line Scan Speed	0-63	Adjust line scanning speed (effect 1)
			64-127	Adjust line scanning speed (effect 2)
		Dot Scan Speed	128-255	Adjust dot scanning speed
CH11	CH28	Strobe	0-0	No strobe
			1-255	Auto strobe, strobe speed from low to fast
CH12	CH29	Z Rotation	0-0	Default, no rotation
			1-127	Rotation Z angle Selection
			128-191	Clockwise rotation Z speed selection
			192-255	Counterclockwise rotation Z speed selection
CH13	CH30	X rolling-Over	0-0	Default, no rolling-over
			1-127	Horizontal rolling-over angle selection

			128-191	Clockwise horizontal rolling-over speed selection
			192-255	Counterclockwise horizontal rolling-over speed selection
CH14	CH31	Y rolling-Over	0-0	Default, no rolling-over
			1-127	Vertical rolling-over angle selection
			128-191	Clockwise vertical rolling-over speed selection
			192-255	Counterclockwise vertical rolling-over speed selection
CH15	CH32	X Move	0-0	Default, no moving
			1-127	Horizontal position selection
			128-159	Move 1 from left to right automatically
			160-191	Move 2 from right to left automatically
			192-223	Move 3 from right to left automatically
			224-255	Move 4 from right and left circularly
CH16	CH33	Y Move	0-0	Default, no moving
			1-127	Vertical position selection
			128-159	Move 1 from up to down automatically
			160-191	Move 2 from down to up automatically
			192-223	Move 3 from up to down automatically
			224-255	Move 4 from up and down circularly
CH17	CH34	Zoom	0-0	Default, no zoom
			1-127	Pattern size selection
			128-159	Zoom -
			160-191	Zoom +
			192-223	Zoom (+/-) circularly
			224-255	Zoom (+/-) circularly
CH18	CH35	Drawing	0-0	Default, no drawing
			1-127	Drawing 1 speed selection, 0~100%
			128-255	Drawing 2 speed selection, 0~100%~0
			0-15	X small Wave 1 speed selection
			16-31	X medium Wave 1 speed selection

CH19	CH36	X Wave	32-47	X big Wave 1 speed selection
			48-63	X biggest Wave 1 speed selection
			64-79	X small Wave 2 speed selection
			80-95	X medium Wave 2 speed selection
			96-111	X big Wave 2 speed selection
			112-127	X biggest Wave 2 speed selection
		Y Wave	128-143	Y small Wave 1 speed selection
			144-159	Y medium Wave 1 speed selection
			160-175	Y big Wave 1 speed selection
			176-191	Y biggest Wave 1 speed selection
			192-207	Y small Wave 2 speed selection
			208-223	Y medium Wave 2 speed selection
			224-239	Y big Wave 2 speed selection
			240-255	Y biggest Wave 2 speed selection

Remote Operation

In the APP mode, the remote control mode is invalid. Exit APP mode to use remote control mode

⏻	Laser ON/OFF. The first step is to operate this key, and the other key functions are effective. Invalid in APP mode
Auto	Auto mode, Select the program in Auto mode
Sound	Sound mode, Select the program in Sound mode
DmxS/P	DMX mode, Select standard 16 channel mode or professional 36 channel mode
InvertX	X Invert setting
InvertY	Y Invert setting
Size+/Size-	Pattern size+/-
Speed+/Speed-	Play speed+/-

