



Waveguide Design Process: Core support



















Discussion







Active Region Mode dispersion

Crystal modes dispersion

DOI: 10.5281/zenodo.4148337