Goodman GTST Connected Thermostat Wireless Setup

Connecting to WiFi and Daikin One Cloud

Disclaimers

This material provides technical information that is to only be used by appropriately trained and certified HVAC-R installers and technicians who have agreed to the terms and conditions available here at https://www.daikincity.com/DaikinCityB2BTermsOfUse.html. If you have not agreed to these terms and conditions, you may not use or view this material, and you assume responsibility for any injury or property, system or equipment damage which may result. If you have agreed to these terms, you also agree, by viewing or using this material, that this material, by its nature, cannot include a discussion of everything necessary to effect a proper installation or repair of HVAC-R equipment, nor can it address every possible scenario or environment a technician or installer may encounter. Accordingly, this material should not be considered as recommendations for best practices and will not be considered installation or repair instructions to the extent of any conflict with Daikin- or Goodman-issued manuals and specifications, or industry standards and regulations. Each installer or technician remains fully responsible for ensuring proper installation or repair of the HVAC-R equipment being worked on, and you remain fully responsible for any injury or property, system or equipment damage which may result from your installation. ©2023 Daikin Comfort Technologies North America, Inc., all rights reserved; recording, copying, or distribution of this material is prohibited without express written permission from Daikin.

Wireless Setup: Connecting to WiFi and Daikin One Cloud

Connecting to WiFi
The Goodman homeowner app is needed to configure the WiFi settings of this thermostat.

The Goodman Installer app can configure WiFi settings and send a profile to the thermostat.

From the primary display, holding the FAN button for 5 seconds will enter wireless setup mode.

AP Mode
Press the COOLER button to go into AP Mode.

Depending on the path chosen in the installer app, the app will display available networks to connect to WiFi, or search for connected equipment to send an appropriate profile to the thermostat.

Cloud Account
Press the WARMER button to go to display the PIN needed to link the thermostat to the homeowner app through the cloud.

At any time pressing the MODE button for 2 seconds will return the thermostat UI to the primary screen.

At the end of each setting menu sequence the thermostat will return to the primary screen.

From the primary display, hold the FAN button for 5 seconds to enter wireless setup mode.

When WIRELSS is displayed, pressing the COOLER (down) button will enter access point mode.

Pressing the WARMER (up) button will access cloud setup mode.

FSD cycles through the following until a button is pressed:
WIRELSS
SETUP
MENU
PRESS
COOLER
TOCON-
FIGURE
WIFI
PRESS
WARMER
TO PAIR
WITH
GOODMAN
CLOUD
PRESS
MODE
FOR
INFO

FSD cycles through the following:
AP MODE
ACTIVE

Use the Goodman app to connect the device to wifi. Pressing the WARMER button displays the PIN to be entered in the homeowner app to connect to the Goodman Cloud.

FSD cycles through the following until a button is pressed:
GOODMAN
CLOUD
SETUP
{cloud connect code}

Note: AP Mode is used by the installer app, depending on the path chosen in the app, to connect to WiFi or send a profile to the thermostat.

When connected in AP Mode, either for configuring wifi or sending a profile, the FSD cycles through the following:
CONNEC-
TED

When a Goodman thermostat is linked to a homeowner app account and wireless setup is entered by holding the fan button for 5 seconds, pressing the up (warmer) button, "LINKED" is displayed.

FSD cycles through the following until a button is pressed:
GOODMAN
CLOUD
SETUP
LINKED

Thank goodness for Goodman.®