Multi-Cards Usage

If there are more than one HM610 card on your PC or server, and you want to know which one card is corresponding to which eight adapters. you have to read this document carefully. For example, maybe you can't find which card's cable needed to replace, when you want to change channels of some adapter. This allows you to quickly find out which satellite cable the TV program comes from. Especially in the case of Mode 1, the effect is significant. Next you can do these steps as below to solve it.

- 1. First step: Poweroff your computer, and insert all your cards in your computer's slots.
- 2. You need a LNB cable, one is enough then power on your computer.
- 3. Make sure all adapters are loaded, you can use this command to check: ls/dev/dvb.(6 cards, 0-47 adpters)
- 4. Then use MuMudvb to lock TV channels from adpater0, such as picture as below:



5. Connect LNB cable to all your HM610 cards in turn,the card is


adapter0 (adapter0

纯文本 ▼ 制表符宽度: 8 ▼ 行 2, 列 7 ▼ 插入

adapter7) which

to

MuMudvb locked channels successfully .Then you can mark this




corresponding to



```
test@test-Super-Server: ~
Info:
                            Multicast4 ip: 239.100.8.4:1234
        Autoconf:
Deb0:
        Autoconf:
                               pids: 4479 (PMT), 8191 (PCR),
                            el number : 5, name : "CBBC Channel"
Multicast4 ip : 239.100.8.5:1234
pids : 4671 (PMT), 8191 (PCR),
Info:
        Autoconf:
                     Channel number :
                                                                            service id 4671
        Autoconf:
Info:
Deb0:
        Autoconf:
WARN:
        Logs: Error config_file /var/run/mumudvb/mumudvb_generated_conf_card8_tu
      No such file or directory
ner0:
                         NEW program for channel 0 : "BBC ONE". PMT pid : NEW program for channel 1 : "BBC TWO". PMT pid :
Deb0:
        PAT Rewrite:
                                                                             pid : 4227
Deb0:
        PAT
             Rewrite:
                         NEW program for channel 2:
                                                          "BBC THREE". PMT pid : 4351
Deb0:
        PAT Rewrite:
                                                          "BBC NEWS 24". PMT pid : 4415
                         NEW program for channel 3:
Deb0:
        PAT Rewrite:
                                                           "BBCi". PMT pid : 4479
Deb0:
        PAT Rewrite:
                         NEW program for channel 4:
                                                           "CBBC Channel". PMT pid : 4671
             Rewrite:
Deb0:
        PAT
                         NEW program for channel 5
                         Full SDT updated. section number 0, last_section_number 0
Deb0:
        SDT rewrite:
Deb0:
        Main: The SDT version changed, we force the update of all the channels.
                        NEW program for channel 0 : "BBC ONE". service_id : 4163
NEW program for channel 1 : "BBC TWO". service_id : 4227
NEW program for channel 2 : "BBC THREE". service_id : 4351
Deb0:
        SDT rewrite:
Deb0:
        SDT
            rewrite:
        SDT rewrite:
Deb0:
Deb0:
        SDT rewrite:
                         NEW program for channel 3:
                                                          "BBC NEWS 24". service_id : 441
                         NEW program for channel 4 : "BBCi". service_id : 4479
Deb0:
        SDT rewrite:
                         NEW program for channel 5 : "CBBC Channel". service_id : 46
        SDT rewrite:
Deb0:
71
```

6. As same as step 4,use MuMudvb to lock TV channels from adpater8, such as picture as below:



7. Connect LNB cable to your remainder HM610 cards in turn,the card is corresponding to adapter8(adapter8 to adapter15) which MuMudvb locked channels successfully. Then you can mark this

纯文本 ▼ 制表符宽度:8 ▼

card "card2" on your computer. Such as picture as below:



```
test@test-Super-Server: ~
                                             Multicast4 ip : 239.100.0.4:1234
pids : 4479 (PMT), 8191 (PCR),
Info:
             Autoconf:
Deb0:
             Autoconf:
            Autoconf: Channel number: 5, name: "CBBC Channel" service id 4671
Autoconf: Multicast4 ip: 239.100.0.5:1234
Autoconf: pids: 4671 (PMT), 8191 (PCR),
Logs: Error config_file /var/run/mumudvb/mumudvb_generated_conf_card0_tu
Info:
Info:
Deb0:
WARN:
ner0: No such file or directory
                                       NEW program for channel 0 : "BBC ONE". PMT pid : 4163
NEW program for channel 1 : "BBC TWO". PMT pid : 4227
Deb0:
             PAT Rewrite:
Deb0:
             PAT Rewrite:
                                       NEW program for channel 2 : "BBC THREE". PMT pid : 4351
Deb0:
             PAT Rewrite:
                                                                                             "BBC NEWS 24". PMT pid : 4415
"BBCi". PMT pid : 4479
                                       NEW program for channel 3
NEW program for channel 4
Deb0:
             PAT Rewrite:
Deb0:
             PAT Rewrite:
                                                                                             "CBBC Channel". PMT pid : 4671
Deb0:
             PAT Rewrite:
                                        NEW program for channel 5
                         write: NEW program for channel 3: CBBC Channel . PMT ptd : 46/1
write: Full SDT updated. section number 0, last_section_number 0
The SDT version changed, we force the update of all the channels.
write: NEW program for channel 0: "BBC ONE". service_id: 4163
write: NEW program for channel 1: "BBC TWO". service_id: 4227
write: NEW program for channel 2: "BBC THREE". service_id: 4351
write: NEW program for channel 3: "BBC NEWS 24". service_id: 441
             SDT rewrite:
Deb0:
Deb0:
             Main:
Deb0:
             SDT rewrite:
Deb0:
             SDT rewrite:
Deb0:
             SDT rewrite:
Deb0:
             SDT rewrite:
                                       NEW program for channel 4 : "BBCi". service_id : 4479
NEW program for channel 5 : "CBBC Channel". service_id : 46
Deb0:
             SDT rewrite:
Deb0:
             SDT rewrite:
71
```

8. You can do above steps repeatedly to find correlation of remainder cards and adapters.

ATTENTION:

- 1. Your LNB cable signal must match cards' input type (V/L,V/H,H/L,H/H).
- 2. Adapter 0 to adapter 7 are corresponding to HM610 card 1, and adapter 8 to adapter 15 are corresponding to the HM610 card 2, and the like.
- 3. All cards work at mode0.