

SW1
SW_Push
SW2
SW_Push
U1
ESP32-S3-WROOM-1-N8R8
R1
10k
R2
10k
C1
22uF
C2
0.1uF
C3
1uF
C4
0.1uF
+3.3V
GND
Z_Out_DCC_Signal_A
Z_Out_DCC_Signal_B
USB-
USB+
IC1
MC74VHCT541ADWR2G
IC2
MC74VHCT541ADWR2G
C7
100nF
C8
100nF
+5V_Z
DCC_Signal_A_1
DCC_Signal_A_2
DCC_Signal_A_3
DCC_Signal_A_4
DCC_Signal_A_5
DCC_Signal_A_6
DCC_Signal_A_7
DCC_Signal_A_8
DCC_Signal_B_1
DCC_Signal_B_2
DCC_Signal_B_3
DCC_Signal_B_4
DCC_Signal_B_5
DCC_Signal_B_6
DCC_Signal_B_7
DCC_Signal_B_8
J6
J2
J7
J3
J8
J4
J9
J5
B4B-XH-A_LF__SN_
J1
GSB22120RSKEU
IC3
AZ1117CH-3.3TRG1
D1
PMEG3010ER
C11
10uF
C12
22uF
PS2
R-78E5.0-1.0
PS1
R-78E3.3-0.5
C10
10uF
C9
10uF
C5
10uF
C6
10uF
694106301002
J10
R7
220
R8
220
R9
220
R10
220
R11
220
R12
470
D2
LED
D3
LED
D4
LED
D5
LED
D6
LED
D7
LED
R3
10k
R4
10k
R5
10k
R6
10k
SW3
SW_Push
SW4
SW_Push
SW5
SW_Push
SW6
SW_Push
Sheet: /
File: SYNCHRO_Zentrale.kicad_sch
Title:
Size: A4
Date:
Rev:
KiCad E.D.A. 10.0.6
Id: 1/1