

Required References

For the AcamAddins VBA examples to function properly, the **Alphacam Add-Ins 1.0 Interface** and **Alphacam Add-Ins 1.0 Type Library** objects references must be added to the project. This can be done via the **Tools ► References** menu in the VBA editor and checking on the items shown in the image below.

