

Vacuum Pump P-303 Maintenance Spec

1. Overview

Vacuum pump P-303 is driven by motor M-41 and supported by bearing B-12. The discharge of P-303 connects to condenser CD-2.

2. Inspection Cycle

Item	Cycle	Owner
Bearing B-12 vib.	weekly	mech team
Motor M-41 insul.	monthly	elec team
Seal S-11 leak	daily	ops team

3. Procedure

If bearing B-12 vibration exceeds limit, stop motor M-41 and check lubricant.

If vibration persists, replace bearing B-12. Replacement is done by mech team.