




"Emergency Stop" switch
(Main operation panel)



"Emergency Stop" switch
(Manual pulse generator)



"Emergency Stop" switch (ATC
operation panel)

