

PARAMETER

N00000

000000 SEQ INI ISO TVC

0 0 0 0 0 0 0 0

000001 FCV

0 0 0 0 0 0 0 0

000002 SJZ

0 0 0 0 0 0 0 0

000010 PEC PRM PZS

0 0 0 0 0 0 0 0

000012 RMV MIR

0 0 0 0 0 0 0 0

X
Y
Z
X
X
X
X
X

0 0 0 0 0 0 0 0
0 0 0 0 0 0 0 0
0 0 0 0 0 0 0 0
0 0 0 0 0 0 0 0
0 0 0 0 0 0 0 0
0 0 0 0 0 0 0 0
0 0 0 0 0 0 0 0
0 0 0 0 0 0 0 0

00020 I/O CHANNEL

4

00021 OUT CHANNEL/F. G.

0

00022 INP CHANNEL/B. G.

0

00023 OUT CHANNEL/B. G.

0

00024

0

00100 ENS IOP NCR CRF CTV

0 0 0 0 0 0 0 0

00101 NFD ASI SB2

0 0 0 0 0 0 0 1

00102 IO SELECT CH0

0

00103 BAUDRATE CH0

10

A>_

MDI ****

10:10:23

OUTPUT

PARAME
TER

DIAGNO
SIS

SERVO
GUIDE

SYSTEM

(OPRT)

+