




LS00 Tool Clamp
LS01 Tool Unclamp
LS601 Tool Seating Confirmation
LS602 Tool Presence Confirmation