

TH5 circuit opens when malfunction occurs in Spindle Cooler.

DI: TH5 1→0

Machine Controller detects a malfunction and an alarm is triggered. (Alarm: A062)

- Operation (program) stops.
- Feed axes stop (axis interlocks are applied).
- Spindle stops.
- Chip disposal devices stop.
- Spindle Cooler controller pump stops.