

ATC MAINTENANCE				
MAINTENANCE MODE		:	OFF	/ON
ATC RECOVERY		:	OFF	/ON
SPINDLE TOOL POT		:	11	
MAGAZINE INDEX POT		:	-1	
ATC POSITION		:	0.000	
FEED MODE		:	REF	/INCH/JOG
FEED OVERRIDE		:	100%	/50%/25%/0%
INCHING DATA		:	0.000	
ATC POT CLEAN		:	OFF	/ON
SP. TAPER CLEAN		:	OFF	/ON
TOOL CHANGE POSITION				
			X: -249.890	
			Y: 213.787	
			Z: -150.214	
{INPUT		OFF	ON	